

# Hub and Spoke VPN using the VPN Prosafe Client

This document describes the steps to undertake in configuring a Hub-and-Spoke network over the Internet using VPNs (box-to-box and client-to-box).

In particular it describes how to allow VPN clients (**Spoke**) to access Remote LANs (**Spokes**) via a single VPN connection to a central (**Hub**) Firewall/Router.

The configuration can apply to any of the VPN Firewall/Router from firmware version 3.5.0.24 and above, and VPN clients from version 10.8.3 and above.

The diagram below shows a typical scenario.



## **Table of Contents**

NETWORK SETUP	3
Physical setup	3
Logical setup	3
Configuration of VPN policies on the Firewall/Routers	4
FVX538 VPN Config (Policy name: BoxtoBox)	4
FVS338 VPN Config (Policy name: BoxtoBox)	4
FVX538 VPN Config (Policy name: LAN1toVPN)	5
FVX538 VPN Config (Policy name: LAN2Client)	6
FVS338 VPN Config (Policy name: LAN2Client)	6
VPN client configuration	7
Testing the connection	8

## **NETWORK SETUP**

### Physical setup

FVX538 connected to the Internet via a modem or modem/router

FVS338 connected to the Internet via a modem or modem/router

VPN Client PCs connected Wireless/Wired to the Internet (via a LAN allowing IPSEC traffic)

### Logical setup

FVX538

LAN IP: 172.22.101.101/24 DHCP: 172.22.101.0/24 Mode Config DHCP: 192.168.0.0/24 Firmware version: 3.5.0.24

#### FVS338

LAN IP: 172.22.102.102/24 DHCP: 172.22.102.0/24 Firmware version: 3.5.0.24

VPN Client Version: 10.8.3 NIC IP: 192.168.0.x/24

### VPN configuration

The setup will require the creation of multiple VPN policies:

#### FVX538

- 1x Box-to-box policy from the FVX538 to the FVS338 (Policy name: BoxtoBox)
- 1x Client-to-Box policy on the FVX538 to connect to the VPN clients (Policy name: LAN1toVPN)
- 1x Manual VPN policy using the IKE policy used for the box-to-box connection to allow the VPN clients to connect to the LAN behind the FVS338 (Policy name: LAN2toClient)

#### FVS338

- 1x Box-to-box policy from the FVS338 to the FVX538 (Policy name: **BoxtoBox**)
- 1x Manual VPN policy using the IKE policy used for the box-to-box connection to allow the FVS338 to connect to the VPN clients (Policy name: LAN2toClient)

### **VPN** Client

- 1x Policy connecting to the Public address of the FVS338 specifying as the IP range for the Remote party 172.22.0.0 mask 255.255.0.0 (class full only mask accepted)

### FVX538 VPN Config (Policy name: **BoxtoBox**)

PN Wizard	VPN Wizard Default Valu
# About ¥PN Wizard	() he
The Wizard sets most parameters to defaults as proposed by key, which greatly simplifies setup. After creating the policies parameters through the <u>Policies</u> menu.	the VPN Consortium ( <u>VPNC</u> ), and assumes a pre-shared through the VPN Wizard, you can always update the
This VPN tunnel will conne	ect to the following peers:
<ul> <li>Gateway</li> </ul>	O VPN Client
© Connection Name and Remote IP Type	() he
What is the new Connection Name?	BoxtoBox
What is the pre-shared key?	12345678 (Key Length 8 - 49 Char)
This VPN tunnel will use following local WAN Interface:	Broadband      Dialup
End Point Information	() he
What is the Remote WAN's IP Address or Internet Name?	83.71.251.20
What is the Local WAN's IP Address or Internet Name?	83.71.251.19
Secure Connection Remote Accessibility	(2) he
What is the remote LAN IP Address?	172 .22 .102 .0
What is the remote LAN Subnet Mask?	255 ,255 ,255 ,0
Apply	Reset

- Access the VPN Wizard via the VPN configuration page.
- Configure the Connection name (for admin reasons this will match the FVS338 box as **BoxtoBox**).
- 1 Input the pre-shared key.
- Configure the Public or DNS address of the Remote location, and the LAN details (the Remote LAN IP address is intended as the subnet address).
- Click on Apply

## FVS338 VPN Config (Policy name: BoxtoBox)

YN WIZARO	🥑 VPN Wizard Default Va
# About VPN Wizard	(9 h
The Wizard sets most parameters to defaults as proposed by the VPN Consortium ( <u>VPNC</u> ), e key, which greatly simplifies setup. After creating the policies through the VPN Wizard, you o parameters through the <u>Policies</u> menu.	nd assumes a pre-shared an always update the
This VPN tunnel will connect to the following peers:	
Gateway O VPN Client	
Connection Name and Remote IP Type	<b>@</b> h
What is the new Connection Name? BoxtoBox	
What is the pre-shared key? 12345678	(Key Length 8 - 49 Char)
This VPN tunnel will use following local WAN Interface:   Broadband  Dialup	
# End Point Information	<b>②</b> h
What is the Remote WAN's IP Address or Internet Name? 83.71.251.19	
What is the Local WAN's IP Address or Internet Name? 83.71.251.20	
Secure Connection Remote Accessibility	<b>?</b> h
What is the remote LAN IP Address? 172 22 101 0	
What is the remote LAN Subnet Mask? 255 .255 .0	
Apply Reset	

- Access the VPN Wizard via the VPN configuration page.
- Configure the Connection name (for admin reasons this will match the other box as **BoxtoBox**).
- Input the pre-shared key as at point ①
- Configure the Public or DNS address of the Remote location, and the LAN details (the Remote LAN IP address is intended as the subnet address).
- Click on Apply

PN WIZAPO	VPN Wizard Default	vai
# About ¥PN Wizard	G	? he
The Wizard sets most parameters to defaults as proposed by key, which greatly simplifies setup. After creating the policies parameters through the <u>Policies</u> menu.	the VPN Consortium ( $\underline{VPNC}$ ), and assumes a pre-shared through the VPN Wizard, you can always update the	
This VPN tunnel will conne	ect to the following peers:	
O Gateway	O VPN Client	
Connection Name and Remote IP Type	(	2) he
What is the new Connection Name?	7 LANItoVPN	
What is the pre-shared key?	7 12345678 (Key Length 8 - 49 Char)	
This VPN tunnel will use following local WAN Interface:	: • WAN 1 • WAN 2	
End Point Information	Ó	<u>?)</u> he
What is the Remote Identifier Information?	7 fvx_remote.com	
What is the Local Identifier Information?	? fvx_local.com	
Secure Connection Remote Accessibility	(	2 he
What is the remote LAN IP Address?	7	
What is the remote LAN Subnet Mask?		
Apply	Reset	

- Access the VPN Wizard via the VPN configuration page.
- Create a new VPN client policy named LAN1toVPN (with any pre-shared key)
- Take note of the Remote and Local identifier whether using the default ones or new ones.
- Click on Apply

	Operation succeeded.							
III List of VPN Policies					?help			
	1	Name	Туре	Local	Remote	Auth	Encr	Action
	•	BoxtoBox	Auto Policy	172.22.101.0/255.255.255.0	172.22.102.0/255.255.	255.0 SHA-1	3DES	🙆 edit
	•	LAN1toVPN*	Auto Policy	172.22.101.0/255.255.255.0	Any	SHA-1	3DES	🥝 edit
Cli	ent P	olicy	0	s elect al 🛞 delete 🕒 enable	🔵 disable 💽 add			
Cli	ent P	olicy	0	select al 🛞 delete 🔵 enable	🔵 disable 💽 add			(?) he
Cli	ant P	olicy c Selection	Ø :	select al 🔞 delete 🕒 enable	disable 🙆 add			?he
Ti	ant P	rolicy c Selection Local	Ø:	select al 🕢 delete 💽 enable	disable e add Remote IP: Subne	ut 💌		?he
T	ant P affi S	c Selection Local : tart IP Addre	IP: Any SS: 172,22	relect al @delete enable	disable e add Remote IP: Subne Start IP Address: 192	it 💌 168 .0 .0		? he
Tı	ant P affi S	olicy c Selection Local : tart IP Addre: End IP Addre	(P: Any 172 .22 55: 0 .0	celect al @delete @ enable 	disable add Remote IP: Subne Start IP Address: 192 End IP Address: 0	it ▼ 168 .0 .0 0 .0 .0		(?) he

- Edit the LAN1toVPN.
- Change the Local IP setting to **any** and the Remote IP to **subnet**, modifying the Start IP address to **192.168.0.0** with subnet mask **255.255.255.0**
- Click on Apply

Edit VPN Policy
Operation succeeded.
III General 📀 🖉 🛞
Policy Name:LAN2toClient
Policy Type: Auto Policy 💌
Select Local Gateway: 💿 WAN1 🛛 🔿 WAN2
Remote Endpoint:      IP Address:     83     71     251     20
O FQDN: 83.71.251.20
Enable NetBIOS?
Enable RollOver?
Enable Keepalive: 🔿 Yes 💿 No
Ping IP Address: 0 .0 .0
Detection period: 10 (Seconds)
Reconnect after failure count: 3
III Traffic Selection @he
Local IP: Subnet 💌 Remote IP: Subnet 💌
Start IP Address: 192 168 0 0 Start IP Address: 172 22 102 0
End IP Address: 0 .0 .0 .0 End IP Address: 0 .0 .0 .0
Subnet Mask: 255 255 255 0 Subnet Mask: 255 255 0
Manual Policy Parameters
SPI-Incoming: (Hex, 3-8 Chars) SPI-Outgoing: (Hex, 3-8 Chars)
Encryption Algorithm: 3DES 🗸 Integrity Algorithm: SHA-1 🗸
Key-In:
(DES-8 Char & 3DES-24 Char) (MD5-16 Char & SHA-1-20 Char)
III Auto Policy Parameters
SA Lifetime 3600 Seconds 💙
Encryption Algorithm: 3DES 💌 Integrity Algorithm: SHA-1 💌
PFS Key Group: DH Group 2 (1024 bit) 💌
Select IKE Policy: BoxtoBox 💌 👂 view selected
Analy Davak

- Access the VPN Wizard via the VPN configuration page.
- In the VPN Policy section click on Add (this will create a new manual VPN policy which will use an existing IKE policy)
- Create a new VPN client policy named
   LAN2toClient
- Specify the Remote Endpoint IP address to be the Public address of the FVS338
- Specify the Local IP subnet to be the one of the VPN clients as **192.168.0.0/24** and the Remote IP subnet to be the LAN of the FVS338 as **172.22.102.0/24**
- Ensure that the Select IKE Policy is set to **BoxtoBox**
- Click on Apply

## FVS338 VPN Config (Policy name: LAN2Client)

Consul	
General	
	Policy Name: LANZtoClient
	Policy Type: Auto Policy
	Select Local Gateway: Broadband Obialup
	Remote Endpoint: IP Address: 83 /71 /251 /19
	O FQDN:
	Enable NetBIOS?
	Enable RollOver?
	Enable Keepalive: OYes  No
	Ping IP Address:
	Detection period: 10 (Seconds)
	Reconnect after failure count: 3
Traffic Sele	ion Ø
	cal IP: Subnet V Remote IP: Subnet V
Start IP	ddress: 172 22 102 0 Start IP Address: 192 168 0 0
End IP	idress: End IP Address:
Sub	Mask: 255 255 255 0 Subnet Mask: 255 255 255 0
Manual Poli	Parameters 0
SPI	coming: (Hex, 3-8 Chars) SPI-Outgoing: (Hex, 3-8 Chars)
Encryption	jorithm: 3DES 🗹 Integrity Algorithm: SHA-1 🗹
	Key-In: Key-In:
	ey-Out: Key-Out:
	(DES-8 Char & 3DES-24 Char) (MD5-16 Char & SHA-1-20 Char)
Auto Policy	arameters 0
	SA Lifetime 3600 Seconds V
	ryption Algorithm: 3DES 👻 Integrity Algorithm: SHA-1 👻
	PFS Key Group: DH Group 2 (1024 bit) 💌
	Select IKE Policy: BoxtoBox 🖌 🖉 view selected

- Access the VPN Wizard via the VPN configuration page.
- In the VPN Policy section click on Add (this will create a new manual VPN policy which will use an existing IKE policy)
- Create a new VPN client policy named
   LAN2toClient
- Specify the Remote Endpoint IP address to be the Public address of the FVX538
- Specify the Local IP subnet to be the one of the FVS338 172.22.102.0/24 and the Remote IP subnet to be the VPN clients one 192.168.0.0/24
- Ensure that the Select IKE Policy is set to **BoxtoBox**
- Click on Apply

## **VPN client configuration**

This configuration requires advanced IP address planning. The VPN client policy needs to be able to address both Local Area Network #1 and Local Area Network #2 in the same client policy profile, therefore, the two networks must be presentable as one subnet or one address range.

This has been considered in our scenario.

N Security Policy Editor - NETGEAR ProS	afe VPN Client
File Edit Options Help	
Network Security Policy	NETGEAR 😽
Microsoft IPsec VPN     My Connections     My Connections     My Identity     Security Policy     My Identity     Security Policy     My Americation (Phase 1)	Connection Security Secure Nonsecure Block
Connections	Remote Party Identity and Addressing ID Type IP Subnet Subnet: 172 22.0.0 Mask: 255 255.0.0 Protocol All Pot All
	Use Secure Gateway Tunnel ID Type Domain Name Kvx_local.com 83.71.251.19
,	

- Create a new VPN client policy
- Specify the Remote Party ID type as IP Subnet and the subnet and mask as 172.22.0.0 255.255.255.0 (this will address both LAN1 and LAN2)
- The gateway IP address will be specified at the WAN address of the FVX538 in our case

N Security Policy Editor - NETGEAR ProSe	afe VPN Client 📃 🗖 🗙
File Edit Options Help	
File       Edit       Options       Help         Image: Security Policy       Image: Security Policy         Image: My Identity       Image: Security Policy         Image: Security Policy       Image: Security Policy         Image: Security P	NETGEAR My Identity Select Certificate None D Type Domain Name Fix_remote.com Virtual Adapter Virtual Adapter Internal Interface Name Arry Pot Domain Name Virtual Adapter Name
1	,

- In My identity change the pre-shared key to match the VPN policy LAN1toVPN created on the FVX538 (12345678)
- Set the Virtual adapter as Required as specify a unique value for the Internal network IP address (this will be different on each PC running the VPN client



 In the Security policy section ensure the Phase 1 negotiation mode is set to aggressive, PFS is enabled and Enable Replay Detection is ticked

# **Testing the connection**

## **VPN** Client



- From the VPN client run **ipconfig** to confirm once the VPN is established that the Virtual adapter interface is assigned with the IP address specified in the policy (in this case **192.168.0.1**)
- Test the VPN connection to both the FVX538 and FVS338 by pinging each box LAN IP address

FVS338

Diagnostics I Ping or Trace an IP Address Ping through VPN tunnel? V IP Address: 192 168 0 11 % ping @ traceroute	() help
<pre># Ping 64 bytes from 192.168.0.1: icmp_seq=0 ttl=127 64 bytes from 192.168.0.1: icmp_seq=1 ttl=127 64 bytes from 192.168.0.1: icmp_seq=2 ttl=127 64 bytes from 192.168.0.1: icmp_seq=3 ttl=127</pre>	@help

 From Monitoring, Diagnostic on the FVS338 ping the VPN client IP address 1902.168.0.1