Command Line Interface Reference for the ProSafe 7200 Series Layer-2 Switches, Software Version 6.0

NETGEAR[®]

NETGEAR, Inc. 4500 Great America Parkway Santa Clara, CA 95054 USA

202-10235-01 February 2007 © 2007 by NETGEAR, Inc. All rights reserved. FullManual.

Trademarks

NETGEAR and Auto Uplink are trademarks or registered trademarks of NETGEAR, Inc..

Microsoft, Windows, and Windows NT are registered trademarks of Microsoft Corporation.

Other brand and product names are registered trademarks or trademarks of their respective holders. Portions of this document are copyright Intoto, Inc.

February 2007

Statement of Conditions

In the interest of improving internal design, operational function, and/or reliability, NETGEAR reserves the right to make changes to the products described in this document without notice.

NETGEAR does not assume any liability that may occur due to the use or application of the product(s) or circuit layout(s) described herein.

EN 55 022 Declaration of Conformance

This is to certify that the ProSafe 7200 Series Layer-2 Managed Switch is shielded against the generation of radio interference in accordance with the application of Council Directive 89/336/EEC, Article 4a. Conformity is declared by the application of EN 55 022 Class B (CISPR 22).

Certificate of the Manufacturer/Importer

It is hereby certified that the ProSafe 7200 Series Layer-2 Managed Switch has been suppressed in accordance with the conditions set out in the BMPT-AmtsblVfg 243/1991 and Vfg 46/1992. The operation of some equipment (for example, test transmitters) in accordance with the regulations may, however, be subject to certain restrictions. Please refer to the notes in the operating instructions.

The Federal Office for Telecommunications Approvals has been notified of the placing of this equipment on the market and has been granted the right to test the series for compliance with the regulations.

Bestätigung des Herstellers/Importeurs

Es wird hiermit bestätigt, daß dasProSafe 7200 Series Layer-2 Managed Switch gemäß der im BMPT-AmtsblVfg 243/ 1991 und Vfg 46/1992 aufgeführten Bestimmungen entstört ist. Das vorschriftsmäßige Betreiben einiger Geräte (z.B. Testsender) kann jedoch gewissen Beschränkungen unterliegen. Lesen Sie dazu bitte die Anmerkungen in der Betriebsanleitung.

Das Bundesamt für Zulassungen in der Telekommunikation wurde davon unterrichtet, daß dieses Gerät auf den Markt gebracht wurde und es ist berechtigt, die Serie auf die Erfüllung der Vorschriften hin zu überprüfen.

Voluntary Control Council for Interference (VCCI) Statement

This equipment is in the Class B category (information equipment to be used in a residential area or an adjacent area thereto) and conforms to the standards set by the Voluntary Control Council for Interference by Data Processing Equipment and Electronic Office Machines aimed at preventing radio interference in such residential areas. When used near a radio or TV receiver, it may become the cause of radio interference. Read instructions for correct handling.

Product and Publication Details

Model Number:	FSM72xx/GSM72xx
Publication Date:	February 2007
Product Family:	managed switch
Product Name:	ProSafe 7200 Series Layer-2 Managed Switch
Home or Business Product:	Business
Language:	English
Publication Part Number:	202-10235-01
Publication Version Number	1.0

v1.0, February 2007

Contents

Command Line Interface Reference for the ProSafe 7200 Series Layer-2 Switches, Software Version 6.0

Chapter 1 About This Manual

1.1	Audience	1-1
1.2	Scope	1-1
1.3	Typographical Conventions	1-2
1.4	Special Message Formats	1-2
1.5	How to Use This Manual	1-3
1.6	How to Print this Manual	1-3
1.7	Revision History	1-4
Chapter 2 Overview		
2.1	Scope	2-1
2.2	Product Concept	2-1
2.3	Using the Command-Line Interface	2-2
2.3	.1 Command Syntax	2-2
2.3	.2 Command Conventions	2-3
2.3	.3 Unit-Slot-Port Naming Convention	2-5
2.3	.4 Using the "No" Form of a Command	2-6
2.3	.5 Command Modes	2-6
2.3	.6 Entering CLI Commands	2-9
2.3	.7 Using CLI Help	2-10
2.3	.8 Accessing the CLI	2-11
Chapter 3 Administra	ative Access Commands	
21	Notwork Interface Commande	21

3.1	Netw	rk Interface Commands3-1
3.	1.1	enable

3.	1.2	network parms (parameter)	3-2
3.	1.3	network mgmt_vlan	3-2
3.	1.4	network protocol	3-2
3.	1.5	show network	3-3
3.2	Cont	iguring the Switch Management CPU (ezconfig)	3-5
3.3	Con	sole Port Access Commands	3-7
3.	3.1	configuration	3-7
3.	3.2	lineconfig	3-7
3.	3.3	serial baudrate	3-8
3.	3.4	serial timeout	3-8
3.	3.5	show serial	3-9
3.4	Teln	et Commands	3-10
3.	4.1	telnet	3-10
3.	4.2	transport input telnet	3-10
3.	4.3	transport output telnet	3-11
3.	4.4	session-limit	3-11
3.	4.5	session-timeout	3-12
3.	4.6	telnetcon maxsessions	3-12
3.	4.7	telnetcon timeout	3-13
3.	4.8	show telnet	3-13
3.	4.9	show telnetcon	3-14
3.5	Secu	re Shell (SSH) Command	3-15
3.	5.1	ip ssh	3-15
3.	5.2	ip ssh protocol	3-15
3.	5.3	sshcon maxsessions	3-16
3.	5.4	sshcon timeout	3-16
3.	5.5	show ip ssh	3-17
3.6	Нуре	ertext Transfer Protocol (HTTP) Commands	3-17
3.	6.1	ip http secure-port	3-17
3.	6.2	ip http secure-protocol	3-18
3.	6.3	ip http secure-server	3-18
3.	6.4	ip http server	3-18
3.	6.5	network javamode	3-19
3.	6.6	show ip http	3-19
3.7	Usei	Account Commands	3-20

3.7.1	users name	
3.7.2	users passwd	
3.7.3	users snmpv3 accessmode	
3.7.4	users snmpv3 authentication	
3.7.5	users snmpv3 encryption	
3.7.6	show loginsession	
3.7.7	show users	
3.7.8	disconnect	

Chapter 4 Port and System Setup Commands

4.1	Port	Configuration Commands4-1
	4.1.1	interface4-1
	4.1.2	interface range
	4.1.3	interface vlan4-2
	4.1.4	interface lag4-2
	4.1.5	cablestatus4-2
	4.1.6	auto-negotiate4-3
	4.1.7	auto-negotiate all4-3
	4.1.8	mtu4-4
	4.1.9	shutdown4-4
	4.1.10	shutdown all4-5
	4.1.11	speed4-5
	4.1.12	speed all4-6
	4.1.13	monitor session
	4.1.14	no monitor4-7
	4.1.15	show monitor session
	4.1.16	show port4-7
	4.1.17	show port protocol4-8
	4.1.18	show port status4-9
4.2	Pre-le	ogin Banner and System Prompt Commands4-9
	4.2.1	сору4-9
	4.2.2	set prompt4-9
4.3	Simp	le Network Time Protocol (SNTP) Commands
	4.3.1	sntp broadcast client poll-interval
	4.3.2	sntp client mode

	4.3.10	show sntp client	4-14
	4.3.10	show sntp client	4-14
	4.3.11	show sntp server	4-15
	4.3.12	clock timezone	4-16
4.4	MAC	Address and MAC Database Commands	4-16
	4.4.1	network mac-address	4-17
	4.4.2	network mac-type	4-17
	4.4.3	macfilter	4-18
	4.4.4	macfilter adddest	4-18
	4.4.5	macfilter adddest all	4-19
	4.4.6	macfilter addsrc	4-19
	4.4.7	macfilter addsrc all	4-20
	4.4.8	bridge aging-time	4-21
	4.4.9	show forwardingdb agetime	4-22
	4.4.10	show mac-address-table multicast	4-22
	4.4.11	show mac-address-table static	4-23
	4.4.12	show mac-address-table staticfiltering	4-24
	4.4.13	show mac-address-table stats	4-24
4.5	DNS	Client Commands	4-25
	4.5.1	ip domain-lookup	4-26
	4.5.2	ip domain-name	4-26
	4.5.3	ip name-server	4-26
	4.5.4	ip host	4-27
	4.5.5	clear host	4-27
	4.5.6	show hosts	4-27
Chapte	r 5		
Spanni	ng Tree P	Protocol Commands	

5.1 \$	STP	Configuration Commands	5-1
5.1.1	1	spanning-tree	5-1

	5.1.2	spanning-tree bpdumigrationcheck5-	·2
	5.1.3	spanning-tree configuration name5-	·2
	5.1.4	spanning-tree configuration revision5-	-3
	5.1.5	spanning-tree edgeport5-	.3
	5.1.6	spanning-tree edgeport all5-	-3
	5.1.7	spanning-tree forceversion	-4
	5.1.8	spanning-tree forward-time5-	-4
	5.1.9	spanning-tree hello-time	-5
	5.1.10	spanning-tree max-age	-5
	5.1.11	spanning-tree max-hops	-6
	5.1.12	spanning-tree mst	-6
	5.1.13	spanning-tree mst instance	-7
	5.1.14	spanning-tree mst priority	-8
	5.1.15	spanning-tree mst vlan5-	.9
	5.1.16	spanning-tree port mode5-	.9
	5.1.17	spanning-tree port mode all5-	.9
	5.1.18	spanning-tree bpduforwarding5-1	0
5.2	STP	Show Commands	0
	5.2.1	show spanning-tree5-1	0
	5.2.2	show spanning-tree summary5-1	2
	5.2.3	show spanning-tree interface5-1	3
	5.2.4	show spanning-tree mst port detailed5-1	4
	5.2.5	show spanning-tree mst port summary5-1	6
	5.2.6	show spanning-tree mst summary5-1	6
	5.2.7	show spanning-tree vlan5-1	7
Chapte VLAN (er 6 Command	ds	
6.1	VLAN	N Configuration Commands6-	-1
	6.1.1	vlan database6-	-1
	6.1.2	network mgmt_vlan6	-2

6.1.3	vlan	6-2
6.1.4	vlan acceptframe	6-2
6.1.5	vlan ingressfilter	6-3
6.1.6	vlan makestatic	6-3
6.1.7	vlan name	6-4

	6.1.8	vlan participation	6-4
	6.1.9	vlan participation all	6-5
	6.1.10	vlan port acceptframe all	6-5
	6.1.11	vlan port pvid all	6-6
	6.1.12	vlan port tagging all	6-6
	6.1.13	vlan port ingressfilter all	6-7
	6.1.14	Global Config	6-7
	6.1.15	vlan protocol group	6-7
	6.1.16	vlan protocol group add protocol	6-7
	6.1.17	vlan protocol group remove	6-8
	6.1.18	protocol group	6-8
	6.1.19	protocol vlan group	6-9
	6.1.20	protocol vlan group all	6-9
	6.1.21	vlan pvid	6-10
	6.1.22	vlan tagging	6-10
6.2	VLAN	N Show Commands	6-11
	6.2.1	show vlan	6-11
	6.2.2	show vlan <vlan_id></vlan_id>	6-11
	6.2.3	show vlan port	6-13
6.3	Provi	isioning (IEEE 802.1p) Commands	6-14
	6.3.1	vlan port priority all	6-14
	6.3.2	vlan priority	6-14

Chapter 7 DHCP Commands

7.1	DHC	P Server Commands (DHCP Config Pool Mode)	7-2
	7.1.1	ip dhcp pool	7-2
	7.1.2	client-identifier	7-2
	7.1.3	client-name	7-3
	7.1.4	default-router	7-3
	7.1.5	dns-server	7-4
	7.1.6	hardware-address	7-4
	7.1.7	host	7-4
	7.1.8	lease	7-5
	7.1.9	network	7-6
	7.1.10	bootfile	7-6

	7 1 11	domain-name	7-6
	7 1 12	nethios-nome-server	
	7 1 13	netbios-node-type	
	7.1.13	next-server	
	7.1.14	option	7-0
7.2		P Server Commands (Clobal Config Mode)	
1.2	7.2.1	in dhen eveluded-address	7-9
	7.2.1	in dhen ning packets	7-9
	7.2.2	sorvice doep	7 10
	7.2.3	in dhen hoota automatic	7-10
	7.2.4	in the conflict logging	
73	7.2.3 DHC	P Server Clear and Show Commands	
7.0	731	clear in door binding	7-12
	732	clear in doop server statistics	7-12
	733	clear in door conflict	7-12
	734	show in dhep hinding	7-12
	735	show in dhen global configuration	7-13
	7.3.5	show in dhep pool configuration	7-13
	7.3.0	show in dhen conversitation	7-13
	7.2.0	show in dhen conflict	
74	7.3.0 DUC	P and ROOTP Relay Commands	7-15
7.4	7 / 1	in dhen relay information ontion	7-15
	7.4.1	bestedbesreley	
	7.4.2	bootputicpleiay	
	7.4.3	bootpdncprelay maxhopcount	
	7.4.4	bootpancpreiay minwaitume	
	7.4.5	bootpancpreiay serverip	
Chanta	7.4.6	snow bootpancprelay	
GARP,	r o GVRP, an	nd GMRP Commands	
8.1	GAR	P Commands	8-2
0.1	8.1.1	set garp timer join	
	8.1.2	set garp timer leave	8-3
	8.1.3	set garp timer leaveall	8-4
	814	show garp	8-4
	J		

 8.2
 GVRP Commands
 8-5

	8.2.1	set gvrp adminmode	.8-5
	8.2.2	set gvrp interfacemode	.8-5
	8.2.3	show gvrp configuration	.8-6
8.3	GMR	P Commands	.8-7
	8.3.1	set gmrp adminmode	.8-7
	8.3.2	set gmrp interfacemode	.8-8
	8.3.3	show gmrp configuration	. 8-8 .
	8.3.4	show mac-address-table gmrp	3-10
Chapte	r 9		
Port-Ba	ised Traff	ic Control Commands	
9.1	Port	Security Commands	.9-1
	9.1.1	port-security	.9-2
	9.1.2	port-security max-dynamic	.9-2
	9.1.3	port-security max-static	.9-3
	9.1.4	port-security mac-address	.9-3
	9.1.5	port-security mac-address move	.9-3
	9.1.6	show port-security	.9-4
	9.1.7	show port-security	.9-4
	9.1.8	show port-security dynamic	.9-4
	9.1.9	show port-security static	.9-4
	9.1.10	show port-security violation	.9-5
9.2	Storm	n Control Commands	.9-5
	9.2.1	storm-control broadcast	.9-5
	9.2.2	storm-control multicast all	.9-6
	9.2.3	storm-control unicast all	.9-6
	9.2.4	storm-control broadcast	.9-7
	9.2.5	storm-control multicast	.9-7
	9.2.6	storm-control unicast	.9-8
	9.2.7	storm-control flowcontrol	.9-8
	9.2.8	show storm-control	.9-9
Chapte SNMP (r 10 Commano	ds	

10.1	SNM	IP Configuration Commands	.10-1
10.	1.1	snmp-server	.10-1
10.	1.2	snmp-server community	.10-2

10.1.3	snmp-server community ipaddr	
10.1.4	snmp-server community ipmask	
10.1.5	snmp-server community mode	
10.1.6	snmp-server community ro	10-4
10.1.7	snmp-server community rw	10-4
10.1.8	snmp-server traps violation	10-4
10.1.9	snmp-server traps	10-5
10.1.10	snmp-server traps bcaststorm	10-5
10.1.11	snmp-server traps linkmode	10-6
10.1.12	snmp-server traps multiusers	10-6
10.1.13	snmp-server traps stpmode	10-6
10.1.14	snmptrap	10-7
10.1.15	snmptrap snmpversion	10-8
10.1.16	snmptrap ipaddr	10-8
10.1.17	snmptrap mode	10-8
10.1.18	snmp trap link-status	10-9
10.1.19	snmp trap link-status all	10-9
10.2 SNM	IP Show Commands	10-10
10.2.1	show snmpcommunity	10-10
10.2.2	show snmptrap	
10.2.3	show trapflags	
Chapter 11		
Port-Based Acc	ess and Authentication Commands	
11.1 Port-	-Based Network Access Control Commands	
11.1.1	authentication login	
11.1.2	clear dot1x statistics	11-3
11.1.3	clear radius statistics	
11.1.4	dot1x defaultlogin	
11.1.5	dot1x initialize	
11.1.6	dot1x login	
11.1.7	dot1x max-req	
11.1.8	dot1x port-control	
11.1.9	dot1x port-control all	
11.1.10	dot1x re-authenticate	11-5
11.1.11	dot1x re-authentication	11-6

	11.1.12	dot1x system-auth-control
	11.1.13	dot1x timeout
	11.1.14	dot1x user
	11.1.15	users defaultlogin
	11.1.16	users login
	11.1.17	show authentication11-8
	11.1.18	show authentication users11-9
	11.1.19	show dot1x11-9
	11.1.20	show dot1x users 11-13
	11.1.21	show users authentication
11.2	RAD	IUS Commands 11-13
	11.2.1	radius accounting mode11-13
	11.2.2	radius server host
	11.2.3	radius server key 11-15
	11.2.4	radius server msgauth11-15
	11.2.5	radius server primary11-16
	11.2.6	radius server retransmit
	11.2.7	radius server timeout
	11.2.8	show radius11-17
	11.2.9	show radius accounting11-18
	11.2.10	show radius statistics
Chapter Port-Cha	12 annel/LA	AG (802.3ad) Commands
12.1	Port-	Channel Configuration Commands12-1
· · · · · ·	12.1.1	addport12-2
	12.1.2	deleteport (Interface Config)12-2
	12.1.3	deleteport (Global Config)
	12.1.4	port-channel
	12.1.5	clear port-channel
	12.1.6	port-channel staticcapability
	12.1.7	port lacpmode
	12.1.8	port lacpmode all
	12.1.9	port-channel adminmode12-4
	12.1.10	port-channel name12-5

port-channel linktrap12-5

12.1.11

12.2 F	Port-Channel Show Commands	12-6
12.2.	1 show port-channel	12-6
12.2.	2 show port-channel	12-6
Chapter 13 IGMP Snoop	ing Commands	
13.1 I	GMP Snooping Configuration Commands	13-1
13.1.	1 ip igmpsnooping	13-1
13.1.	2 ip igmpsnooping interfacemode	13-2
13.1.	3 ip igmpsnooping groupmembership-interval	13-3
13.1.	4 ip igmpsnooping maxresponse	13-4
13.1.	5 ip igmpsnooping mcrtexpiretime	13-4
13.1.	6 ip igmp mrouter	13-5
13.1.	7 ip igmp mrouter interface	13-5
13.1.	8 ip igmpsnooping unknown-multicast	13-6
13.2 I	GMP Snooping Show Commands	13-6
13.2.	1 show ip igmp	13-6
13.2.	2 show ip igmp mrouter interface	13-8
13.2.	3 show ip igmp mrouter vlan	13-8
13.2.	4 show mac-address-table igmpsnooping	13-8
13.3 I	GMP Querier Commands	13-9
13.3.	1 ip igmpsnooping querier	13-10
13.3.	2 ip igmpsnooping querier ip-address	13-10
13.3.	3 ip igmpsnooping querier query-interval	13-11
13.3.	4 show ip igmpsnooping querier	13-11
Chapter 14 Quality of Se	ervice (QoS) Commands	
14.1 C	Class of Service (CoS) Commands (GSM7248 only)	14-2
14.1.	1 classofservice dot1p-mapping	14-2
14.1.	2 classofservice ip-precedence-mapping	14-2
14.1.	3 classofservice ip-dscp-mapping	14-3
14.1.	4 classofservice trust	14-3
14.1.	5 cos-queue min-bandwidth	14-4
14.1.	6 cos-queue strict	14-4
14.1.	7 traffic-shape	14-5
14.1.	8 show classofservice dot1p-mapping	14-5

14.1.9	show classofservice ip-precedence-mapping	14-5
14.1.10	show classofservice ip-dscp-mapping	14-6
14.1.11	show classofservice trust	14-6
14.1.12	show interfaces cos-queue	14-7
14.2 Diffe	rentiated Services (DiffServ) Commands	14-8
14.2.1	diffserv	14-9
14.3 DiffS	Serv Class Commands (GSM7248 only)	14-9
14.3.1	class-map	14-10
14.3.2	class-map rename	14-11
14.3.3	match ethertype	14-11
14.3.4	match any	
14.3.5	match class-map	
14.3.6	match cos	14-12
14.3.7	match destination-address mac	14-13
14.3.8	match dstip	14-13
14.3.9	match dstl4port	14-13
14.3.10	match ip dscp	14-14
14.3.11	match ip precedence	14-14
14.3.12	match ip tos	14-15
14.3.13	match protocol	14-16
14.3.14	match source-address mac	14-16
14.3.15	match srcip	14-16
14.3.16	match srcl4port	14-17
14.3.17	match vlan	14-17
14.4 DiffS	Serv Policy Commands (GSM7248 only)	14-17
14.4.1	policy-map	14-18
14.4.2	assign-queue	14-19
14.4.3	drop	14-19
14.4.4	conform-color	14-20
14.4.5	class	14-20
14.4.6	mark cos	14-21
14.4.7	mark ip-dscp	14-21
14.4.8	mark ip-precedence	14-22
14.4.9	police-simple	14-22
14.4.10	policy-map rename	14-23

14.5 E	DiffServ Service Commands (GSM7248 only)	14-23
14.5.	1 service-policy	14-24
14.6 E	DiffServ Show Commands	14-25
14.6.	1 show class-map (GSM7248 only)	14-25
14.6.	2 show diffserv	14-26
14.6.	3 show policy-map (GSM7248 only)	14-27
14.6.	4 show diffserv service (GSM7248 only)	14-29
14.6.	5 show diffserv service brief (GSM7248 only)	14-29
14.6.	6 show policy-map interface (GSM7248 only)	14-30
14.6.	7 show service-policy (GSM7248 only)	14-31
14.7 N	MAC Access Control List (ACL) Commands (GSM7248 only)	14-31
14.7.	1 mac access-list extended	14-31
14.7.	2 mac access-list extended rename	14-32
14.7.	3 {deny permit}	14-32
14.7.	4 mac access-group	14-34
14.7.	5 show mac access-lists	14-34
14.8 II	P Access Control List (ACL) Commands (GSM7248 only)	14-35
14.8.	1 access-list	14-36
14.8.	2 ip access-group	14-37
14.8.	3 show ip access-lists	14-38
14.8.	4 show access-lists	14-38
Chapter 15		
System Mair	ntenance Commands	
15.1 S	System Information and Statistics Commands	15-1
15.1.	1 show arp switch	15-2
15.1.	2 show eventlog	15-2
15.1.	3 show hardware	15-2
15.1.	4 show interface	15-3
15.1.	5 show interface ethernet	15-5
15.1.	6 show logging	15-14
15.1.	7 show mac-addr-table	15-14
15.1.	8 clear mac-addr-table	15-15
15.1.	9 show running-config	15-16
15.1.	10 terminal length	15-16
15.1.	11 show sysinfo	15-16

15.2 Syst	tem Utility Commands15-17
15.2.1	traceroute15-17
15.2.2	clear config15-18
15.2.3	clear counters15-18
15.2.4	clear igmpsnooping15-18
15.2.5	clear pass15-18
15.2.6	enable passwd15-18
15.2.7	clear port-channel15-19
15.2.8	clear traplog15-19
15.2.9	clear vlan15-19
15.2.10	сору15-19
15.2.11	logout15-21
15.2.12	ping15-21
15.2.13	reload15-21
15.3 Log	ging Commands15-22
15.3.1	logging buffered15-22
15.3.2	logging buffered wrap15-22
15.3.3	logging console15-23
15.3.4	logging host15-23
15.3.5	logging host remove15-23
15.3.6	logging port15-24
15.3.7	logging syslog15-24
15.3.8	show logging15-24
15.3.9	show logging buffered15-26
15.3.10	clear logging buffered15-26
15.3.11	show logging hosts15-26
15.3.12	show logging traplogs15-27
15.4 CLI	Command Logging Command15-27
15.4.1	logging cli-command15-27
15.5 Con	figuration Scripting Commands15-28
15.5.1	script apply15-29
15.5.2	script delete
15.5.3	script list15-29
15.5.4	show script15-29
15.5.5	script validate

15.6	Pac	ket Capture	
15.	6.1	capture transmit packet	
15.	6.2	capture receive packet	
15.	6.3	capture all packets	
15.	6.4	capture wrap	
15.	6.5	show capture packets	
15.7	Dum	nping System Information	
15.8	Sett	ing the Output Length of show running-config	
15.	.8.1	terminal length	
15.	8.2	terminal no length	
pondix	^		

Appendix A Command Changes from Release 3 to Release 5

Chapter 1 About This Manual

This chapter introduces the Command Line Interface Reference for the ProSafe 7200 Series Layer-2 Switches, Software Version 6.0. It describes the command-line interface (CLI) commands used to view and configure the 7200 Series Managed Switch software. You can access the CLI by using a direct connection to the serial port or by using telnet or SSH over a remote network connection.

1.1 Audience

This document is for system administrators who configure and operate systems using 7200 Series Managed Switch software. Software engineers who integrate 7200 Series Managed Switch software into their hardware platform can also benefit from a description of the configuration options.

This document assumes that the reader has an understanding of the 7200 Series Managed Switch software base and has read the appropriate specification for the relevant networking device platform. It also assumes that the reader has a basic knowledge of Ethernet and networking concepts.

1.2 Scope

This manual is written for the 7200 Series Managed Switch according to these specifications:

Table 1-1. Manual	Specifications
-------------------	----------------

Product	ProSafe 7200 Series Layer-2 Managed Switch	
Manual Part Number	202-10235-01	
Manual Publication Date	February 2007	



Note: Product updates are available on the NETGEAR Web site at *http://kbserver.netgear.com/products/*.

1.3 Typographical Conventions

This guide uses the following typographical conventions:

Table 1-2. Typographical conventions	Table 1-2.	Typographical	conventions
--------------------------------------	------------	---------------	-------------

italics	Emphasis.
bold	User input.
Small Caps	DOS file and directory names.

1.4 Special Message Formats

This guide uses the following formats to highlight special messages:





Tip: A time-saving or resource-saving procedural step.



Warning: This is a warning of possible damage to the equipment or software malfunction.



Danger: Ignoring this type of warning could result in personal injury or death.

1.5 How to Use This Manual

The HTML version of this manual includes the following:

- Buttons \geq and \leq for browsing forwards or backwards through the manual one page at a time.
- A **TOC** button that displays the table of contents and possibly an **Index** button. Double-click on a link in the table of contents or index to navigate directly to where the topic is described in the manual.
- A Knowledge Base button to access the full NETGEAR, Inc. online knowledge base for the product model.
- Links to PDF versions of the full manual and individual chapters.

1.6 How to Print this Manual

To print this manual, choose one of the following options.

• Printing a Page in the HTML View.

Each page in the HTML version of the manual is dedicated to a major topic. Use the *Print* button on the browser toolbar to print the page contents.

• Printing a Chapter.

Use the *PDF of This Chapter* link at the top left of any page.

Click the *PDF of This Chapter* link at the top right of any page in the chapter you want to print. The PDF version of the chapter you were viewing opens in a browser window.

Your computer must have the free Adobe Acrobat reader installed in order to view and print PDF files. The Acrobat reader is available on the Adobe Web site at *http://www.adobe.com*.

— Click the print icon in the window toolbar.



Tip: If your printer supports printing of two or more pages on a single sheet of paper, you can save paper and printer ink by clicking the printer Properties button and increasing the number of pages per sheet.

• Printing the Full Manual.

Use the *Complete PDF Manual* link at the top left of any page.

- Click the *Complete PDF Manual* link at the top left of any page in the manual. The PDF version of the complete manual opens in a browser window.
- Click the print icon in the window toolbar.



Tip: If your printer supports printing of two or more pages on a single sheet of paper, you can save paper and printer ink by clicking the printer Properties button and increasing the number of pages per sheet.

1.7 Revision History

Table 1-3 lists the revision history of this manual.

Table 1-3. Revision History of This Manual

Document Part Number	Revision	Change Description
202-10235-01	1.0	Document for version 6.0 software release

Chapter 2 Overview

The 7200 Series Managed Switch software has two purposes:

- Assist attached hardware in switching frames, based on Layer 2, 3, or 4 information contained in the frames.
- Provide a complete device management portfolio to the network administrator.

2.1 Scope

7200 Series Managed Switch software encompasses both hardware and software support. It software is partitioned to run in the following processors:

- **CPU**—This code runs the networking device management portfolio and controls the overall networking device hardware. It also assists in frame forwarding, as needed and specified. This code is designed to run on multiple platforms with minimal changes from platform to platform.
- **Networking Device Processor**—This code does the majority of the packet switching, usually at wire speed. This code is platform dependent, and substantial changes might exist across products.

2.2 Product Concept

Fast Ethernet and Gigabit Ethernet switching continues to evolve from high-end backbone applications to desktop switching applications. The price of the technology continues to decline, while performance and feature sets continue to improve. Devices that are capable of switching Layers 2, 3, and 4 are increasingly in demand. 7200 Series Managed Switch software provides a flexible solution to these ever-increasing needs.

The exact functionality provided by each networking device on which the 7200 Series Managed Switch software base runs varies depending upon the platform and requirements of NETGEAR.

7200 Series Managed Switch software includes a set of comprehensive management functions for managing both the switch and the network. You can manage the 7200 Series Managed Switch software by using one of the following three methods:

- Web-based
- VT100 interface
- Simple Network Management Protocol (SNMP)

Each of the management methods enables you to configure, manage, and control the software locally or remotely using in-band or out-of-band mechanisms. Management is standards-based, with configuration parameters and a private MIB providing control for functions not completely specified in the MIBs.

2.3 Using the Command-Line Interface

The command-line interface (CLI) is a text-based way to manage and monitor the system. You can access the CLI by using a direct serial connection or by using a remote logical connection with telnet or SSH.

This section describes the CLI syntax, conventions, and modes. It contains the following topics:

- Section 2.3.1 "Command Syntax" on page 2-2
- Section 2.3.2 "Command Conventions" on page 2-3
- Section 2.3.3 "Unit-Slot-Port Naming Convention" on page 2-5
- Section 2.3.4 "Using the "No" Form of a Command" on page 2-6
- Section 2.3.5 "Command Modes" on page 2-6
- Section 2.3.6 "Entering CLI Commands" on page 2-9
- Section 2.3.7 "Using CLI Help" on page 2-10
- Section 2.3.8 "Accessing the CLI" on page 2-11

2.3.1 Command Syntax

A command is one or more words that might be followed by one or more parameters. Parameters can be required or optional values. Some commands, such as **show network** or **clear vlan**, do not require parameters. Other commands, such as **network parms**, require that you supply a value after the command. You must type the parameter values in a specific order, and optional parameters follow required parameters. The following example describes the **network parms** command syntax:

```
Format network parms <ipaddr> <netmask> [gateway]
```

- **network parms** is the command name.
- <*ipaddr*> and <*netmask*> are parameters and represent required values that you must enter after you type the command keywords.
- [gateway] is an optional parameter, so you are not required to enter a value in place of the parameter.

The CLI Command Reference lists each command by the command name and provides a brief description of the command. Each command reference also contains the following information:

- Format shows the command keywords and the required and optional parameters.
- Mode identifies the command mode you must be in to access the command.
- Default shows the default value, if any, of a configurable setting on the device.

The **show** commands also contain a description of the information that the command displays.

2.3.2 Command Conventions

In this document, the command name is in **bold** font. Parameters are in *italic* font. You must replace the parameter name with an appropriate value, which might be a name or number. Parameters are order dependent.

The parameters for a command might include mandatory values, optional values, or keyword choices. Table 2-1 describes the conventions this document uses to distinguish between value types.

Symbol	Example	Description
<> angle brackets	<value></value>	Indicates that you must enter a value in place of the brackets and text inside them.
[] square brackets	[value]	Indicates an optional parameter that you can enter in place of the brackets and text inside them.

Table	2-1.	Parameter	Conventions
Table	4 -1.	i arameter	Conventions

Symbol	Example	Description
{} curly braces	{choice1 choice2}	Indicates that you must select a parameter from the list of choices.
Vertical bars	choice1 choice2	Separates the mutually exclusive choices.
[{}] Braces within square brackets	[{choice1} choice2}]	Indicate a choice within an optional element.

Table 2-1. Parameter Conventions

2.3.2.1 Common Parameter Values

Parameter values might be names (strings) or numbers. To use spaces as part of a name parameter, enclose the name value in double quotes. For example, the expression "System Name with Spaces" forces the system to accept the spaces. Empty strings ("") are not valid user-defined strings. Table 2-2 describes common parameter values and value formatting.

Parameter	Description
ipaddr	This parameter is a valid IP address. You can enter the IP address in the following formats: a (32 bits) a.b.(8.24 bits) a.b.c.(8.8.16 bits) a.b.c.d (8.8.8.8) In addition to these formats, the CLI accepts decimal, hexidecimal and octal formats through the following input formats (where <i>n</i> is any valid hexidecimal, octal or decimal number): 0xn (CLI assumes hexidecimal format) 0n (CLI assumes octal format with leading zeros) n (CLI assumes decimal format)
macaddr	The MAC address format is six hexadecimal numbers separated by colons, for example 00:06:29:32:81:40.
areaid	Enter area IDs in dotted-decimal notation (for example, 0.0.0.1). An area ID of 0.0.0.0 is reserved for the backbone. Area IDs have the same format as IP addresses but are distinct from IP addresses. You can use the IP network number of the sub-netted network for the area ID.
routerid	Enter the value of <i><routerid></routerid></i> in dotted-decimal notation, such as 0.0.0.1. A router ID of 0.0.0.0 is invalid.
Interface or slot/port	Valid slot and port number separated by forward slashes. For example, 0/1 represents slot number 0 and port number 1.

 Table 2-2. Parameter Descriptions

Parameter	Description
Logical Interface	Logical slot and port number. This is applicable in the case of a port-channel (LAG). You can use the logical slot/port to configure the port-channel.
Character strings	Use double quotation marks to identify character strings, for example, "System Name with Spaces". An empty string ("") is not valid.

Table 2-2. Parameter Descriptions

2.3.3 Unit-Slot-Port Naming Convention

7200 Series Managed Switch software references physical entities such as cards and ports by using a Unit-Slot-Port (USP) naming convention. The software also uses this convention to identify certain logical entities, such as port-channel interfaces.

The slot number has two uses. In the case of physical ports, it identifies the card containing the ports. In the case of logical and CPU ports it also identifies the type of interface or port.

Table 2-3. Type of Slots

Slot Type	Description
Physical slot numbers	Physical slot numbers begin with zero, and are allocated up to the maximum number of physical slots.
Logical slot numbers	Logical slots immediately follow physical slots and identify port- channel (LAG) or router interfaces.
CPU slot numbers	The CPU slots immediately follow the logical slots.

The port identifies the specific physical port or logical interface being managed on a given slot.

Table 2	-4. Туре	of Ports
---------	----------	----------

Port Type	Description
Physical Ports	The physical ports for each slot are numbered sequentially starting from zero.
Logical Interfaces	Port-channel or Link Aggregation Group (LAG) interfaces are logical interfaces that are only used for bridging functions. VLAN routing interfaces are only used for routing functions.
CPU ports	CPU ports are handled by the driver as one or more physical entities located on physical slots.

2.3.4 Using the "No" Form of a Command

The no keyword is a specific form of an existing command and does not represent a new or distinct command. Almost every configuration command has a no form. In general, use the no form to reverse the action of a command or reset a value back to the default. For example, the no shutdown configuration command reverses the shutdown of an interface. Use the command without the keyword no to re-enable a disabled feature or to enable a feature that is disabled by default.

Only the configuration commands are available in the no form.

2.3.5 Command Modes

The CLI groups commands into modes according to the command function. Each of the command modes supports specific 7200 Series Managed Switch software commands. The commands in one mode are not available until you switch to that particular mode, with the exception of the User EXEC mode commands. You can execute the User EXEC mode commands in the Privileged EXEC mode.

The command prompt changes in each command mode to help you identify the current mode. Table 2-5 describes the command modes and the prompts visible in that mode. **Table 2-5. CLI Command Modes**

Command Mode	Prompt	Mode Description
User EXEC	Switch>	Contains a limited set of commands to view basic system information.
Privileged EXEC	Switch#	Allows you to issue any EXEC command, enter the VLAN mode, or enter the Global Configuration mode.
Global Config	Switch (Config)#	Groups general setup commands and permits you to make modifications to the running configuration.
VLAN Config	Switch (Vlan)#	Groups all the VLAN commands.

Command Mode	Prompt	Mode Description
Interface Config	Switch (Interface <unit <br="" slot="">port>)#</unit>	Allows you to enable or modify the operation of an interface and provides access to the router interface configuration commands. Use this mode to set up a physical port for a specific logical connection operation.
Line Config	Switch (line)#	Allows you to configure various telnet settings and the console interface.
Policy Map Config	Switch (Config policy-map)#	Allows you to access the QoS Policy-Map configuration mode to configure the QoS Policy-Map.
Policy Class Config	Switch (Config policy-class-map)#	Consists of class creation, deletion, and matching commands. The class match commands specify Layer 2, Layer 3, and general match criteria.
Class Map Config	Switch (Config class-map)#	Allows you to access the QoS Class-Map configuration mode to configure QoS class maps.
Router OSPF Config	Switch (Config router)#	Allows you to access the router OSPF configuration commands.
Router RIP Config	Switch (Config router)#	Allows you to access the router RIP configuration commands.
MAC Access-list Config	Switch (Config mac-access-list)#	Allows you to create a MAC Access-List and to enter the mode containing Mac Access- List configuration commands.
DHCP Pool Config	Switch (Config dhcp-pool)#	Allows you to access the DHCP Pool configuration.
Stack Global Config Mode	Switch (Config stack)#	Allows you to access the Stack Global Config Mode.

Table 2-5. CLI Command Modes (continued)

Table 2-6 explains how to enter or exit each command mode. Table 2-6. CLI Mode Access and Exit

Command Mode	Access Method	Exit or Access Previous Mode
User EXEC	This is the first level of access.	To exit, enter logout.
Privileged EXEC	From the User EXEC mode, enter enable.	To exit to the User EXEC mode, enter exit or press Ctrl-Z.
Global Config	From the Privileged EXEC mode, enter configure.	To exit to the Privileged EXEC mode, enter exit, or press Ctr1-Z.
VLAN Config	From the Privileged EXEC mode, enter vlan database .	To exit to the Privileged EXEC mode, enter exit, or press Ctr1-Z.
Interface Config	From the Global Config mode, enter interface < <i>slot/port></i> .	To exit to the Global Config mode, enter exit. To return to the Privileged EXEC mode, enter <i>Ctr1-z</i> .
Line Config	From the Global Config mode, enter lineconfig.	To exit to the Global Config mode, enter exit. To return to the Privileged EXEC mode, enter <i>ctr1-z</i> .
Policy-Map Config	From the Global Config mode, enter policy-map.	To exit to the Global Config mode, enter exit. To return to the Privileged EXEC mode, enter <i>ctr1-z</i> .
Policy-Class-Map Config	From the Policy Map mode enter class.	To exit to the Policy Map mode, enter exit. To return to the Privileged EXEC mode, enter <i>ctr1-z</i> .
Class-Map Config	From the Global Config mode, enter class-map.	To exit to the Global Config mode, enter exit. To return to the Privileged EXEC mode, enter <i>ctr1-z</i> .
Router OSPF Config	From the Global Config mode, enter router ospf.	To exit to the Global Config mode, enter exit. To return to the Privileged EXEC mode, enter $Ctr1-z$.
Router RIP Config	From the Global Config mode, enter router rip.	To exit to the Global Config mode, enter exit. To return to the Privileged EXEC mode, enter $Ctr1-Z$.
MAC Access-list Config	From the Global Config mode enter mac access-list extended < <i>name></i> .	To exit to the Global Config mode, enter exit. To return to the Privileged EXEC mode, enter <i>ctr1-z</i> .
DHCP Pool Config	From the Global Config mode, enter ip dhcp pool <name>.</name>	To exit to the Global Config mode, enter exit. To return to the Privileged EXEC mode, enter <i>ctr1-z</i> .
Stack Global Config Mode	From the Global Config mode, enter the stack command.	To exit to the Global Config mode, enter the exit command. To return to the Privileged EXEC mode, enter <i>Ctr1-z</i> .

2.3.6 Entering CLI Commands

The 7200 Series Managed Switch supports several features to help you enter commands.

2.3.6.1 Command Completion and Abbreviation

Command completion finishes spelling the command when you type enough letters of a command to uniquely identify the command keyword. Once you have entered enough letters, press the SPACEBAR or TAB key to complete the word.

Command abbreviation allows you to execute a command when you type enough letters of a command to uniquely identify the command. You must enter all of the required keywords and parameters before you enter the command.

2.3.6.2 CLI Error Messages

If you enter a command and the system is unable to execute it, an error message appears. Table 2-7 describes the most common CLI error messages.

Table 2-7. CLI Error Messages

Message Text	Description
% Invalid input detected at '^' marker.	Indicates that you entered an incorrect or unavailable command. The carat (^) shows where the invalid text is detected. This message also appears if any of the parameters or values are not recognized.
Command not found / Incomplete command. Use ? to list commands.	Indicates that you did not enter the required keywords or values.
Ambiguous command	Indicates that you did not enter enough letters to uniquely identify the command.

2.3.6.3 CLI Line-Editing Conventions

Table 2-8 describes the key combinations you can use to edit commands or increase the speed of command entry. You can access this list from the CLI by entering help from the User or Privileged EXEC modes.

Table 2-8. CLI Editing Conventions

Key Sequence	Description
DEL or Backspace	Delete previous character
Ctrl-A	Go to beginning of line
Ctrl-E	Go to end of line
Ctrl-F	Go forward one character

Key Sequence	Description
Ctrl-B	Go backward one character
Ctrl-D	Delete current character
Ctrl-U, X	Delete to beginning of line
Ctrl-K	Delete to end of line
Ctrl-W	Delete previous word
Ctrl-T	Transpose previous character
Ctrl-P	Go to previous line in history buffer
Ctrl-R	Rewrites or pastes the line
Ctrl-N	Go to next line in history buffer
Ctrl-Y	Prints last deleted character
Ctrl-Q	Enables serial flow
Ctrl-S	Disables serial flow
Ctrl-Z	Return to root command prompt
Tab, <space></space>	Command-line completion
Exit	Go to next lower command prompt
?	List available commands, keywords, or parameters

2.3.7 Using CLI Help

Enter a question mark (?) at the command prompt to display the commands available in the current mode.

(switch) >?

enable	Enter into user privilege mode.
help	Display help for various special keys.
logout	Exit this session. Any unsaved changes are lost.
ping	Send ICMP echo packets to a specified IP address.
show	Display switch options and settings.

Enter a question mark (?) after each word you enter to display available command keywords or parameters.

(switch) #network ?
javamode Enable/Disable.
parms Configure Network Parameters of the router.
protocol Select DHCP, BootP, or None as the network config
protocol.
mgmt_vlan Configure the Management VLAN ID of the switch.

If the help output shows a parameter in angle brackets, you must replace the parameter with a value.

```
(switch) #network parms ?
```

```
<ipaddr>
```

If there are no additional command keywords or parameters, or if additional parameters are optional, the following message appears in the output:

Enter the IP Address.

<cr> Press Enter to execute the command

You can also enter a question mark (?) after typing one or more characters of a word to list the available command or parameters that begin with the letters, as shown in the following example:

```
mac-addr-table mac-address-table monitor
```

2.3.8 Accessing the CLI

(switch) #show m?

You can access the CLI by using a direct console connection or by using a telnet or SSH connection from a remote management host.

For the initial connection, you must use a direct connection to the console port. You cannot access the system remotely until the system has an IP address and subnet mask. You can set the network configuration information manually, or you can configure the system to accept these settings from a BOOTP or DHCP server on your network. For more information, see Section 3.1 "Network Interface Commands" on page 3-1.
Chapter 3 Administrative Access Commands

This section describes the management access and basic port configuration commands available in the 7200 Series Managed Switch CLI.

This section contains the following topics:

- Section 3.1 "Network Interface Commands" on page 3-1
- Section 3.3 "Console Port Access Commands" on page 3-7
- Section 3.4 "Telnet Commands" on page 3-10
- Section 3.5 "Secure Shell (SSH) Command" on page 3-15
- Section 3.6 "Hypertext Transfer Protocol (HTTP) Commands" on page 3-17
- Section 3.7 "User Account Commands" on page 3-20

The commands in this section are divided into two functional groups:

- Show commands display switch settings, statistics, and other information.
- Configuration commands configure features and options of the switch. For every configuration command, there is a show command that displays the configuration setting.

To manage the device by using SNMP, see "SNMP Commands" in Chapter 10.

3.1 Network Interface Commands

This section describes the commands you use to configure a logical interface for management access.

3.1.1 enable

This command gives you access to the Privileged EXEC mode. From the Privileged EXEC mode, you can configure the network interface.

Format	enable
Mode	User EXEC

3.1.2 network parms (parameter)

This command sets the IP Address, subnet mask and gateway of the device. The IP Address and the gateway must be on the same subnet.

Format	network	(parms	parameter)	<ipaddr></ipaddr>	<netmask></netmask>
	[<gatewa< th=""><th>ay>]</th><th></th><th></th><th></th></gatewa<>	ay>]			
Mode	Privilege	d EXEC			

3.1.3 network mgmt_vlan

This command configures the Management VLAN ID.

Default	1
Format	<pre>network mgmt_vlan <1-4069></pre>
Mode	Privileged EXEC

3.1.3.1 no network mgmt_vlan

This command sets the Management VLAN ID to the default.

Format	no network mgmt_vlan
Mode	Privileged EXEC

3.1.4 network protocol

This command specifies the network configuration protocol to be used. If you modify this value, change is effective immediately. If you modify this value, the change is effective immediately. If you use the *bootp* parameter, the switch periodically sends requests to a BootP server until a response is received. If you use the *dhcp* parameter, the switch periodically sends requests to a DHCP server until a response is received. If you use the *none* parameter, you must configure the network information for the switch manually.

Default	none
Format	<pre>network protocol {none bootp dhcp}</pre>
Mode	Privileged EXEC

3.1.5 show network

This command displays configuration settings associated with the switch's network interface. The network interface is the logical interface used for in-band connectivity with the switch via any of the switch's front panel ports. The configuration parameters associated with the switch's network interface do not affect the configuration of the front panel ports through which traffic is switched or routed.

Format	show network
Modes	Privileged EXEC User EXEC
IP Address	The IP address of the interface. The factory default value is 0.0.0.0
Subnet Mask	The IP subnet mask for this interface. The factory default value is 0.0.0.0
Default Gateway	The default gateway for this IP interface. The factory default value is $0.0.0.0$
Burned In MAC Address	The burned in MAC address used for in-band connectivity.
Locally Administered MAC Address	If desired, a locally administered MAC address can be con- figured for in-band connectivity. To take effect, 'MAC Address Type' must be set to 'Locally Administered'. Enter the address as twelve hexadecimal digits (6 bytes) with a colon between each byte. Bit 1 of byte 0 must be set to a 1 and bit 0 to a 0, i.e. byte 0 should have the following mask 'xxxx xx10'. The MAC address used by this bridge when it must be referred to in a unique fashion. It is recommended that this be the numerically smallest MAC address of all ports that belong to this bridge. However it is only required to be unique. When concatenated with dot1dStpPriority a unique BridgeIdentifier is formed which is used in the Spanning Tree Protocol.
MAC Address Type	Specifies which MAC address should be used for in-band connectivity. The choices are the burned in or the Locally Administered address. The factory default is to use the burned in MAC address.

Network Configuration	
Protocol Current	Indicates which network protocol is being used. The options are bootp dhcp none.
Java Mode	Specifies if the switch should allow access to the Java applet in the header frame. Enabled means the applet can be viewed. The factory default is disabled.
Web Mode	Specifies if the switch should allow access to the Web Inter- face.

3.2 Configuring the Switch Management CPU (ezconfig)

Format	ezconfig
Mode	Privileged EXEC

To manage the switch via the web GUI or telnet, an IP address needs to be assigned to the switch management CPU. Whereas there are CLI commands that can be used to do this, **ezconfig** simplifies the task. The tool is applicable to all NETGEAR 7000-series managed switches, and allows you to configure the following parameters:

- 1. The administrator's user password and administrator-enable password
- 2. Management CPU IP address and network mask
- 3. System name and location information

The tool is interactive and uses questions to guide you through the steps required to perform its task. At the end of the session, it will ask you if you want to save the changed information. To see exactly what has been changed by ezconfig at the end of the session, use the **show running-config** command.

To perform any switch configuration other than the items listed above, use other CLI commands or the Web GUI.

The following is an example of an **ezconfig** session.

```
NETGEAR EZ Configuration Utility
_____
Hello and Welcome!
This utility will walk you thru assigning the IP address for the switch
management CPU. It will allow you to save the changes at the end. After
the session, simply use the newly assigned IP address to access the Web
GUI using any public domain Web browser.
Admin password not defined. Do you want to change the password?
(Y/N/Q) y
Enter new password:*******
Confirm new password:*******
Password Changed!
The 'enable' password required for switch configuration via the command
line interface is currently not configured. Do you wish to change it (Y/
N/Q)? y
Enter new password:*******
Confirm new password:*******
Password Changed!
Assigning an IP address to your switch management
Current IP Address Configuration
_____
IP address: 0.0.0.0
Subnet mask: 0.0.0.0
Gateway address: 0.0.0.0
Would you like to assign an IP address now (Y/N/Q)? y
IP Address: 10.10.10.1
Subnet mask: 255.255.255.0
Gateway address: 10.10.10.10
Do you want to assign switch name and location information (Y/N/Q)? y
System Name: testunit1
System Location: testlab
System Contact: Bud Lightyear
```

There are changes detected, do you wish to save the changes permanently (Y/N)? y The configuration changes have been saved succesfully. Please enter 'show running-config' to see the final configuration. Thanks for using EzConfig!

3.3 Console Port Access Commands

This section describes the commands you use to configure the console port. You can use a serial cable to connect a management host directly to the console port of the switch.

3.3.1 configuration

This command gives you access to the Global Config mode. From the Global Config mode, you can configure a variety of system settings, including user accounts. From the Global Config mode, you can enter other command modes, including Line Config mode.

Format	configuration
Mode	Privileged EXEC

3.3.2 lineconfig

This command gives you access to the Line Config mode, which allows you to configure various telnet settings and the console port.

Format	lineconfig
Mode	Global Config

3.3.3 serial baudrate

This command specifies the communication rate of the terminal interface. The supported rates are 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200.

Default	9600
Format	serial baudrate {1200 2400 4800 9600 19200 38400 57600 115200}
Mode	Line Config

3.3.3.1 no serial baudrate

This command sets the communication rate of the terminal interface.

Format	no serial baudrate
Mode	Line Config

3.3.4 serial timeout

This command specifies the maximum connect time (in minutes) without console activity. A value of 0 indicates that a console can be connected indefinitely. The time range is 0 to 160.

Default	5
Format	<pre>serial timeout <0-160></pre>
Mode	Line Config

3.3.4.1 no serial timeout

This command sets the maximum connect time (in minutes) without console activity.

Format	no serial timeout
Mode	Line Config

3.3.5 show serial

This command displays serial communication settings for the switch.

Format	show serial
Modes	Privileged EXEC User EXEC
Serial Port Login Timeout	
(minutes)	Specifies the time, in minutes, of inactivity on a Serial port connection, after which the Switch will close the connection. Any numeric value between 0 and 160 is allowed, the factory default is 5. A value of 0 disables the timeout.
Baud Rate (bps)	The default baud rate at which the serial port will try to con- nect. The available values are 1200, 2400, 4800, 9600, 19200, 38400,57600, and 115200 baud. The factory default is 9600 baud.
Character Size	
(bits)	The number of bits in a character. The number of bits is always 8.
Flow Control	Whether Hardware Flow-Control is enabled or disabled. Hardware Flow Control is always disabled.
Stop Bits	The number of Stop bits per character. The number of Stop bits is always 1.
Parity Type	The Parity Method used on the Serial Port. The Parity Method is always None.

3.4 Telnet Commands

This section describes the commands you use to configure and view telnet settings. You can use telnet to manage the device from a remote management host.

3.4.1 telnet

This command establishes a new outbound telnet connection to a remote host. The *host* value must be a valid IP address. Valid values for *port* should be a valid decimal integer in the range of 0 to 65535, where the default value is 23. If *[debug]* is used, the current telnet options enabled is displayed. The optional *line* parameter sets the outbound telnet operational mode as 'linemode', where by default, the operational mode is 'character mode'. The *noecho* option disables local echo.

Format	telnet	<host></host>	<port></port>	[debug]	[line]	[noecho]
Modes	Privileg User EX	ed EXE0 KEC	C			

3.4.2 transport input telnet

This command regulates new telnet sessions. If sessions are enabled, new telnet sessions can be established until there are no more sessions available. If sessions are disabled, no new telnet sessions are established. An established session remains active until the session is ended or an abnormal network error ends the session.

Default	enabled
Format	transport input telnet
Mode	Line Config

3.4.2.1 no transport input telnet

This command disables telnet sessions. If sessions are disabled, no new telnet sessions are established.

Format	no transport	input	telnet
Mode	Line Config		

3.4.3 transport output telnet

This command regulates new outbound telnet connections. If enabled, new outbound telnet sessions can be established until it reaches the maximum number of simultaneous outbound telnet sessions allowed. If disabled, no new outbound telnet session can be established. An established session remains active until the session is ended or an abnormal network error ends it.

Default	enabled
Format	transport output telnet
Mode	Line Config

3.4.3.1 no transport output telnet

This command disables new outbound telnet connections. If disabled, no new outbound telnet connection can be established.

Format	no transport output telnet
Mode	Line Config

3.4.4 session-limit

This command specifies the maximum number of simultaneous outbound telnet sessions. A value of 0 indicates that no outbound telnet session can be established.

Default	5
Format	<pre>session-limit <0-5></pre>
Mode	Line Config

3.4.4.1 no session-limit

This command sets the maximum number of simultaneous outbound telnet sessions to the default value.

Format	no session-limit
Mode	Line Config

3.4.5 session-timeout

This command sets the telnet session timeout value. The timeout value unit of time is minutes. A value of 0 indicates that a session remains active indefinitely.

Default	0	
Format	session-timeout	<0-160>
Mode	Line Config	

3.4.5.1 no session-timeout

This command sets the telnet session timeout value to the default. The timeout value unit of time is minutes.

Format	no session-timeout
Mode	Line Config

3.4.6 telnetcon maxsessions

This command specifies the maximum number of telnet connection sessions that can be established. A value of 0 indicates that no telnet connection can be established. The range is 0 to 5.

Default	5
Format	telnetcon maxsessions <0-5>
Mode	Privileged EXEC

3.4.6.1 no telnetcon maxsessions

This command sets the maximum number of telnet connection sessions that can be established to the default value.

Format	no telnetcon maxsessions
Mode	Privileged EXEC

3.4.7 telnetcon timeout

This command sets the telnet connection session timeout value, in minutes. A session is active as long as the session has not been idle for the value you set, which ranges from 1-160 minutes.

Note: Changing the timeout value for active sessions does not become effective
until the session is reaccessed. Also, any keystroke activates the new
timeout duration.

Default	5
Format	telnetcon timeout <1-160>
Mode	Privileged EXEC

3.4.7.1 no telnetcon timeout

This command sets the telnet connection session timeout value to the default.



Format	no telnetcon timeout
Mode	Privileged EXEC

3.4.8 show telnet

This command displays the current outbound telnet settings.

Format	show telnet
Modes	Privileged EXEC
	User EXEC
Outbound Telnet	
Login Timeout	Indicates the number of minutes an outbound telnet session is allowed to remain inactive before being logged off.

Maximum Number of Outbound	
Telnet Sessions	Indicates the number of simultaneous outbound telnet connections allowed.
Allow New	
Sessions	Indicates whether outbound telnet sessions are allowed
000010110	indicates whether outbound temet sessions are anowed.

3.4.9 show telnetcon

This command displays telnet settings.

Format	show telnetcon
Modes	Privileged EXEC User EXEC
Remote Connection Login Timeout	
(minutes)	This object indicates the number of minutes a remote connection session is allowed to remain inactive before being logged off. May be specified as a number from 1 to 160. The factory default is 5.
Maximum Number of Remote Connection	
Sessions	This object indicates the number of simultaneous remote con- nection sessions allowed. The factory default is 5.
Allow New Telnet Sessions	Indicates that new telnet sessions will not be allowed when set to no. The factory default value is yes.

3.5 Secure Shell (SSH) Command

This section describes the commands you use to configure SSH access to the switch. Use SSH to access the switch from a remote management host.

Note: The system allows a maximum of 5 SSH sessions.

3.5.1 ip ssh

This command is used to enable SSH.

Default	disabled
Format	ip ssh
Mode	Privileged EXEC

3.5.1.1 no ip ssh

This command is used to disable SSH.

Format	no ip ssh
Mode	Privileged EXEC

3.5.2 ip ssh protocol

This command is used to set or remove protocol levels (or versions) for SSH. Either SSH1 (1), SSH2 (2), or both SSH 1 and SSH 2 (1 and 2) can be set.

Default	1 and 2
Format	ip ssh protocol [1] [2]
Mode	Privileged EXEC

3.5.3 sshcon maxsessions

This command specifies the maximum number of SSH connection sessions that can be established. A value of 0 indicates that no ssh connection can be established. The range is 0 to 5.

Default	5
Format	sshcon maxsessions <0-5>
Mode	Privileged EXEC

3.5.3.1 no sshcon maxsessions

This command sets the maximum number of allowed SSH connection sessions to the default value.

Format	no sshcon maxsessions
Mode	Privileged EXEC

3.5.4 sshcon timeout

This command sets the SSH connection session timeout value, in minutes. A session is active as long as the session has been idle for the value set. The time is a decimal value from 1 to 160.

Changing the timeout value for active sessions does not become effective until the session is re accessed. Also, any keystroke activates the new timeout duration.

Default	5
Format	<pre>sshcon timeout <1-160></pre>
Mode	Privileged EXEC

3.5.4.1 no sshcon timeout

This command sets the SSH connection session timeout value, in minutes, to the default.

Changing the timeout value for active sessions does not become effective until the session is re accessed. Also, any keystroke activates the new timeout duration.

Format	no sshcon timeout
Mode	Privileged EXEC

3.5.5 show ip ssh

This command displays the ssh settings.

Format	show ip ssh
Mode	Privileged EXEC
Administrative	
Mode	This field indicates whether the administrative mode of SSH is enabled or disabled.
Protocol Level	The protocol level may have the values of version 1, version 2 or both versions 1 and version 2.
Connections This	field specifies the current SSH connections.

3.6 Hypertext Transfer Protocol (HTTP) Commands

This section describes the commands you use to configure HTTP access to the switch. Access to the switch by using a Web browser is enabled by default. Everything you can view and configure by using the CLI is also available by using the Web.

3.6.1 ip http secure-port

This command is used to set the SSL port where port can be 1-65535 and the default is port 443.

Default	443
Format	<pre>ip http secure-port <portid></portid></pre>
Mode	Privileged EXEC

3.6.1.1 no ip http secure-port

This command is used to reset the SSL port to the default value.

Format	no ip http secure-port
Mode	Privileged EXEC

3.6.2 ip http secure-protocol

This command is used to set protocol levels (versions). The protocol level can be set to TLS1, SSL3 or to both TLS1 and SSL3.

Default	SSL3 and TLS1		
Format	ip http secure-protocol	[SSL3]	[TLS1]
Mode	Privileged EXEC		

3.6.3 ip http secure-server

This command is used to enable the secure socket layer for secure HTTP.

Default	disabled
Format	ip http secure-server
Mode	Privileged EXEC

3.6.3.1 no ip http secure-server

This command is used to disable the secure socket layer for secure HTTP.

Format	no ip http secure-server
Mode	Privileged EXEC

3.6.4 ip http server

This command enables access to the switch through the Web interface. When access is enabled, you can login to the switch from the Web interface. When access is disabled, you cannot login to the switch's Web server. Disabling the Web interface takes effect immediately and affects all interfaces.

Default	enabled	
Format	ip http server	
Mode	Privileged EXEC	

3.6.4.1 no ip http server

This command disables access to the switch through the Web interface. When access is disabled, you cannot login to the switch's Web server.

Format	no ip http server
Mode	Privileged EXEC

3.6.5 network javamode

This command specifies whether or not the switch should allow access to the Java applet in the header frame of the Web interface. When access is enabled, the Java applet can be viewed from the Web interface. When access is disabled, the user cannot view the Java applet.

Default	enabled
Format	network javamode
Mode	Privileged EXEC

3.6.5.1 no network javamode

This command disallows access to the Java applet in the header frame of the Web interface. When access is disabled, the user cannot view the Java applet.

Format	no network javamode
Mode	Privileged EXEC

3.6.6 show ip http

This command displays the http settings for the switch.

Format	show ip http
Mode	Privileged EXEC
Secure-Server Administrative	
Mode	Indicates whether the administrative mode of secure HTTP is enabled or disabled.
Secure Protocol	
Level	Possible values are SSL3, TSL1, or both SSL3 and TSL1.
Secure Port	This field specifies the port configured for SSLT.
HTTP Mode	This field indicates whether the HTTP mode is enabled or disabled.

3.7 User Account Commands

This section describes the commands you use to add, manage, and delete system users. The 7200 Series Managed Switch has two default users: admin and guest. The admin user can view and configure system settings, and the guest user can view settings.

Note: You cannot delete the admin user, and there is only one user allowed with read/write privileges. You can configure up to five read-only users on the system.

3.7.1 users name

This command adds a new user account, if space permits. The account *<username>* can be up to eight characters in length. You can use alphanumeric characters as well as the dash ('-') and underscore ('_'). The *<username>* is not case-sensitive.

You can define up to six user names.

Format	users name <username></username>
Mode	Global Config

3.7.1.1 no users name

This command removes a user account.

Format	no users name <username></username>
Mode	Global Config



3.7.2 users passwd

Use this command to change a password. Passwords are a maximum of eight alphanumeric characters. If a user is authorized for authentication or encryption is enabled, the password length must be at least eight alphanumeric characters. The username and password are not case-sensitive. When you change a password, a prompt asks for the old password. If there is no password, press enter.

Default	no password	
Format	users passwd <username></username>	
Mode	Global Config	

3.7.2.1 no users passwd

This command sets the password of an existing user to blank. When you change a password, a prompt asks for the old password. If there is no password, press enter.

Format	no users pa	sswd <username></username>
Mode	Global Config	5

3.7.3 users snmpv3 accessmode

This command specifies the snmpv3 access privileges for the specified login user. The valid accessmode values are **readonly** or **readwrite**. The *<username>* is the login user name for which the specified access mode applies. The default is **readwrite** for the "admin" user and **readonly** for all other users

Default	admin - readwrite; other - readonly
Format	<pre>users snmpv3 accessmode <username> {readonly readwrite}</username></pre>
Mode	Global Config

3.7.3.1 no users snmpv3 accessmode

This command sets the snmpv3 access privileges for the specified user as **readwrite** for the "admin" user and **readonly** for all other users. The *<username* > value is the user name for which the specified access mode will apply.

Format	no	users	snmpv3	accessmode	<username></username>
Mode	Glo	obal Co	nfig		

3.7.4 users snmpv3 authentication

This command specifies the authentication protocol to be used for the specified user. The valid authentication protocols are **none**, **md5** or **sha**. If you specify **md5** or **sha**, the login password is also used as the snmpv3 authentication password and therefore must be at least eight characters in length. The *<username>* is the user name associated with the authentication protocol.

Default	no authentication
Format	<pre>users snmpv3 authentication <username> {none md5 sha}</username></pre>
Mode	Global Config

3.7.4.1 no users snmpv3 authentication

This command sets the authentication protocol to be used for the specified user to **none**. The *<username>* is the user name for which the specified authentication protocol is used.

Format	users snmpv3 aut	mentication <username></username>
Mode	Global Config	

3.7.5 users snmpv3 encryption

This command specifies the encryption protocol used for the specified user. The valid encryption protocols are **des** or **none**.

If you select des, you can specify the required key on the command line. The encryption key must be 8 to 64 characters long. If you select the des protocol but do not provide a key, the user is prompted for the key. When you use the des protocol, the login password is also used as the snmpv3 encryption password, so it must be a minimum of eight characters. If you select none, you do not need to provide a key.

The <username> value is the login user name associated with the specified encryption.

Default	no encryption
Format	<pre>users snmpv3 encryption <username> { none des[key] }</username></pre>
Mode	Global Config

3.7.5.1 no users snmpv3 encryption

This command sets the encryption protocol to **none**. The *<username>* is the login user name for which the specified encryption protocol will be used.

Formatno users snmpv3 encryption <username>ModeGlobal Config

3.7.6 show loginsession

This command displays current telnet and serial port connections to the switch.

Format	show loginsession
Mode	Privileged EXEC
ID	Login Session ID
User Name	The name the user will use to login using the serial port or Telnet.
Connection From	IP address of the Telnet client machine or EIA-232 for the serial port connection.
Idle Time	Time this session has been idle.
Session Time	Total time this session has been connected.

3.7.7 show users

This command displays the configured user names and their settings. This command is only available for users with Read/Write privileges. The SNMPv3 fields will only be displayed if SNMP is available on the system.

Format	show users
Mode	Privileged EXEC
User Name	The name the user enters to login using the serial port, Telnet or Web.
Access Mode	Shows whether the user is able to change parameters on the switch (Read/Write) or is only able to view them (Read Only). As a factory default, the "admin" user has Read/Write access and the "guest" has Read Only access. There can only be one Read/Write user and up to five Read Only users.

SNMPv3 Access Mode	This field displays the SNMPv3 Access Mode. If the value is set to ReadWrite , the SNMPv3 user is able to set and retrieve parameters on the system. If the value is set to Rea-donly , the SNMPv3 user is only able to retrieve parameter information. The SNMPv3 access mode may be different than the CLI and Web access mode.
SNMPv3	
Authentication	This field displays the authentication protocol to be used for the specified login user.
SNMPv3	
Encryption	This field displays the encryption protocol to be used for the specified login user.

3.7.8 disconnect

This command closes a telnet session.

Format	<pre>disconnect {<sessionid> all}</sessionid></pre>
Mode	Privileged EXEC

Chapter 4 Port and System Setup Commands

This section describes general port and system setup commands available in the 7200 Series Managed Switch CLI.

This section contains the following topics:

- Section 4.1 "Port Configuration Commands" on page 4-1
- Section 4.2 "Pre-login Banner and System Prompt Commands" on page 4-9
- Section 4.3 "Simple Network Time Protocol (SNTP) Commands" on page 4-11
- Section 4.4 "MAC Address and MAC Database Commands" on page 4-16
- Section 4.5 "DNS Client Commands" on page 4-25

The commands in this section are in one of three functional groups:

- Show commands display switch settings, statistics, and other information.
- Configuration commands configure features and options of the switch. For every configuration command, there is a show command that displays the configuration setting.
- Copy commands transfer or save configuration and informational files to and from the switch.

4.1 Port Configuration Commands

This section describes the commands you use to view and configure port settings.

4.1.1 interface

This command gives you access to the Interface Config mode, which allows you to enable or modify the operation of an interface.

Format	<pre>interface <slot port=""></slot></pre>
Mode	Global Config

4.1.2 interface range

This command gives you access to a range of port interfaces, allowing the same port configuration to be applied to a set of ports.

Formatinterface range <slot/port>-<slot/port>ModeGlobal Config

4.1.3 interface vlan

This command gives you access to to the vlan virtual interface mode, which allows certain port configurations (for example, the IP address) to be applied to the VLAN interface. Type a question mark (?) after entering the interface configuration mode to see the available options.

Format	<pre>interface vlan <vlan< pre=""></vlan<></pre>	id>
Mode	Global Config	

4.1.4 interface lag

This command gives you access to the LAG (link aggregation, or port channel) virtual interface, which allows certain port configurations to be applied to the LAG interface. Type a question mark (?) after entering the interface configuration mode to see the available options.

group.

Format	<pre>interface lag <lag id=""></lag></pre>
Mode	Global Config

4.1.5 cablestatus

This command tests the status of the cable attached to an interface.

Format	cablestatus	<slot port=""></slot>
Mode	Privileged EX	EC

4.1.6 auto-negotiate

This command enables automatic negotiation on a port.

Default	enabled
Format	auto-negotiate
Mode	Interface Config

4.1.6.1 no auto-negotiate

This command disables automatic negotiation on a port.



Note: Automatic sensing is disabled when automatic negotiation is disabled.

Format	no auto-negotiate
Mode	Interface Config

4.1.7 auto-negotiate all

This command enables automatic negotiation on all ports. The default value is enable.

Format	auto-negotiate	all
Mode	Global Config	

4.1.7.1 no auto-negotiate all

This command disables automatic negotiation on all ports.

Format	no auto-negotiate	all
Mode	Global Config	

4.1.8 mtu

This command sets the maximum transmission unit (MTU) size, in bytes, for physical and port-channel (LAG) interfaces. For the standard implementation, the MTU size is a valid integer between 1522 - 9216 for tagged packets and a valid integer between 1518 - 9216 for untagged packets.

Note: To receive and process packets, the Ethernet MTU must include any extra bytes that Layer-2 headers might require. To configure the IP MTU size, which is the maximum size of the IP packet (IP Header + IP payload), see Section 14.2.9 "ip mtu" on page 14-11.

Default	1518 (untagged)
Format	mtu <1518-9216>
Mode	Interface Config

4.1.8.1 no mtu

This command sets the default MTU size (in bytes) for the interface.

Format	no mtu
Mode	Interface Config

4.1.9 shutdown

This command disables a port.



Default	enabled
Format	shutdown
Mode	Interface Config

4.1.9.1 no shutdown

This command enables a port.

Note: You can use the no shutdown command on physical and port-channel (LAG) interfaces, but not on VLAN routing interfaces.

Format	no shutdown
Mode	Interface Config

4.1.10 shutdown all

This command disables all ports.

Note: You can use the shutdown command on physical and port-channel (LAG) interfaces, but not on VLAN routing interfaces.

Default	enabled
Format	shutdown all
Mode	Global Config

4.1.10.1 no shutdown all

This command enables all ports.

Note: You can use the **shutdown** command on physical and port-channel (LAG) interfaces, but not on VLAN routing interfaces.

Formatno shutdown allModeGlobal Config

4.1.11 speed

This command sets the speed and duplex setting for the interface.

Format	<pre>speed {<100 10> <half-duplex full-duplex="" ="">}</half-duplex></pre>
Mode	Interface Config

Acceptable values are:

100h	100BASE-T half duplex
100f	100BASE-T full duplex
10h	10BASE-T half duplex
10f	10BASE-T full duplex

4.1.12 speed all

This command sets the speed and duplex setting for all interfaces.

Format	<pre>speed all {<100 10> <half-duplex full-duplex="" ="">}</half-duplex></pre>
Mode	Global Config

Acceptable values are:

100h	100BASE-T half-duplex
100f	100BASE-T full duplex
10h	10BASE-T half duplex
10f	10BASE-T full duplex

4.1.13 monitor session

This command configures a probe port and a monitored port for monitor session (port monitoring). To enable port monitoring, you must add a source interface, destination interface, and enable the mode. If enabled, the probe port monitors all the traffic received and transmitted on the physical monitored port.

Format	<pre>monitor session <session-id> {source interface</session-id></pre>
	<pre><slot port=""> destination interface <slot port=""> </slot></slot></pre>
	mode }
Mode	Global Config

4.1.13.1 no monitor session

This command removes the monitor session (port monitoring) designation from the source probe port, the destination monitored port and all VLANs. Once the port is removed from the VLAN, the user must manually add the port to any desired VLANs.



Note: This command sets the monitor session (port monitoring) mode to disable and removes the source and destination interfaces.

Format	no monitor session <session-id></session-id>
Mode	Global Config

4.1.14 no monitor

This command removes all the source ports and a destination port and restores the default value for mirroring session mode for all the configured sessions.

Note: This is a stand-alone "no" command. This command does not have a "normal" form.

Default	enabled
Format	no monitor
Mode	Global config

4.1.15 show monitor session

This command displays the port monitoring information for the system. The *sessionid* parameter is an integer.

Format	<pre>show monitor session <sessionid></sessionid></pre>	
Mode	Privileged EXEC	
Session ID	The session identifying number.	
Admin Mode	Indicates whether the Port Monitoring feature is enabled or disabled. The possible values are enable and disable.	
Probe Port	The interface configured as the probe port.	
Mirrored Port	The interface configured as the mirrored port.	

4.1.16 show port

This command displays port information.

Format	<pre>show port {<slot port=""> all}</slot></pre>	
Mode	Privileged EXEC	
Interface	Valid slot and port number separated by forward slashes.	
Туре	If not blank, this field indicates that this port is a special type of port. The possible values are:	

	Mon - this port is a monitoring port. Look at the Port Moni- toring screens to find out more information. Lag - this port is a member of a port-channel (LAG).
	Probe - this port is a probe port.
Admin Mode	Selects the Port control administration state. The port must be enabled in order for it to be allowed into the network May be enabled or disabled. The factory default is enabled.
Physical Mode	Selects the desired port speed and duplex mode. If auto-nego- tiation support is selected, then the duplex mode and speed is set from the auto-negotiation process. Note that the maxi- mum capability of the port (full duplex -100M) is advertised. Otherwise, this object determines the port's duplex mode and transmission rate. The factory default is Auto.
Physical Status	Indicates the port speed and duplex mode.
Link Status	Indicates whether the Link is up or down.
Link Trap	This object determines whether or not to send a trap when link status changes. The factory default is enabled.
LACP Mode	Displays whether LACP is enabled or disabled on this port.

4.1.17 show port protocol

This command displays the Protocol-Based VLAN information for either the entire system, or for the indicated group.

Format	<pre>show port protocol {<groupid> all}</groupid></pre>
Mode	Privileged EXEC
Group Name	This field displays the group name of an entry in the Proto- col-based VLAN table.
Group ID	This field displays the group identifier of the protocol group
Protocol(s)	This field indicates the type of protocol(s) for this group.
VLAN	This field indicates the VLAN associated with this Protocol Group.
Interface(s)	This field lists the slot/port interface(s) that are associated with this Protocol Group.

4.1.18 show port status

This command displays the output with current port attributes and operational status.

Format	<pre>show port status {<slot port=""> all}</slot></pre>	
Mode	Privileged Exec	
Interface	Valid slot and port number separated by forward slashes.	
Media Type	"Copper" or "Fiber" for combo port.	
Physical Mode	Either "Auto" or fixed speed and duplex mode.	
Physical Status	The actual speed and duplex mode	
Link Status	Whether the link is Up or Down.	
Loop Status	Whether the port is in loop state or not.	
Partner Flow Control	Whether the remote side is using flow control or not.	

4.2 Pre-login Banner and System Prompt Commands

This section describes the commands you use configure the pre-login banner and the system prompt. The pre-login banner is the text that displays before you login at the **user**: prompt.

4.2.1 copy

The **copy** command includes the option to upload or download the CLI Banner to or from the switch. You can specify local URLs by using TFTP, Xmodem, Ymodem, or Zmodem.

Default	none
Format	copy <code sample="" variable=""><tftp: <ipaddr="">/<filepath>/<filename>><code sample="" variable=""> nvram:clibanner</code></filename></filepath></tftp:></code>
	<pre>copy nvram:clibanner <code sample="" variable=""><tftp: <ipaddr="">/<filepath>/<filename>><code sample="" variable=""></code></filename></filepath></tftp:></code></pre>
Mode	Privileged EXEC

4.2.2 set prompt

This command changes the name of the prompt. The length of name may be up to 64 alphanumeric characters.

Formatset prompt <prompt_string>ModePrivileged EXEC

4.3 Simple Network Time Protocol (SNTP) Commands

This section describes the commands you use to automatically configure the system time and date by using SNTP.

4.3.1 sntp broadcast client poll-interval

This command sets the poll interval for SNTP broadcast clients in seconds as a power of two where poll-interval> can be a value from 6 to 16.

Default	6
Format	<pre>sntp broadcast client poll-interval <poll-inter- val=""></poll-inter-></pre>
Mode	Global Config

4.3.1.1 no sntp broadcast client poll-interval

This command resets the poll interval for SNTP broadcast client back to the default value.

Format	no sntp broadcast client poll-interval
Mode	Global Config

4.3.2 sntp client mode

This command enables Simple Network Time Protocol (SNTP) client mode and may set the mode to either broadcast or unicast.

Default	disabled
Format	<pre>sntp client mode [broadcast unicast]</pre>
Mode	Global Config

4.3.2.1 sntp client mode

This command disables Simple Network Time Protocol (SNTP) client mode.

Format	no sntp client mode
Mode	Global Config

4.3.3 sntp client port

This command sets the SNTP client port id to a value from 1-65535.

Default	123
Format	<pre>sntp client port <portid></portid></pre>
Mode	Global Config

4.3.3.1 no sntp client port

This command resets the SNTP client port back to its default value.

Format	no sntp client port
Mode	Global Config

4.3.4 sntp unicast client poll-interval

This command sets the poll interval for SNTP unicast clients in seconds as a power of two where *<poll-interval>* can be a value from 6 to 16. When the value of the poll interval is from 17 to 16284, the value is interpreted to be in units of seconds.

Default	6
Format	<pre>sntp unicast client poll-interval <poll-interval></poll-interval></pre>
Mode	Global Config

4.3.4.1 no sntp unicast client poll-interval

This command resets the poll interval for SNTP unicast clients to its default value.

Format	no sntp unicast client poll-interval
Mode	Global Config

4.3.5 sntp unicast client poll-timeout

This command sets the poll timeout for SNTP unicast clients in seconds to a value from 1-30.

Default	5
Format	<pre>sntp unicast client poll-timeout <poll-timeout></poll-timeout></pre>
Mode	Global Config
4.3.5.1 no sntp unicast client poll-timeout

This command resets the poll timeout for SNTP unicast clients to its default value.

Format	no sntp unicast client poll-timeout
Mode	Global Config

4.3.6 sntp unicast client poll-retry

This command will set the poll retry for SNTP unicast clients to a value from 0 to 10.

Default	1
Format	<pre>sntp unicast client poll-retry <poll-retry></poll-retry></pre>
Mode	Global Config

4.3.6.1 no sntp unicast client poll-retry

This command will reset the poll retry for SNTP unicast clients to its default value.

Format	no sntp unicast client poll-retry
Mode	Global Config

4.3.7 sntp multicast client poll-interval

This command will set the poll interval for SNTP multicast clients in seconds as a power of two where *<poll-interval>* can be a value from 6 to 16.

Default	6
Format	<pre>sntp multicast client poll-interval <poll-inter- val=""></poll-inter-></pre>
Mode	Global Config

4.3.7.1 no sntp multicast client poll-interval

This command resets the poll interval for SNTP multicast clients to its default value.

Format	no sntp multicast	client	poll-interval
Mode	Global Config		

4.3.8 sntp server

This command configures an SNTP server (a maximum of three). The optional priority can be a value of 1-3, the version a value of 1-4, and the port id a value of 1-65535.

Format	<pre>sntp server <ipaddress> [<priority> [<version></version></priority></ipaddress></pre>
	[<portid>]]]</portid>
Mode	Global Config

4.3.8.1 no sntp server

This command deletes an server from the configured SNTP servers.

Format	no sntp server remove <ipaddress></ipaddress>
Mode	Global Config

4.3.9 show sntp

This command is used to display SNTP settings and status.

Format	show sntp
Mode	Privileged EXEC
Last Update Time	Time of last clock update.
Last Attempt Time	Time of last transmit query (in unicast mode).
Last Attempt Status	Status of the last SNTP request (in unicast mode) or unsolic- ited message (in broadcast mode).
Broadcast Count	Current number of unsolicited broadcast messages that have been received and processed by the SNTP client since last reboot.
Multicast Count	Current number of unsolicited multicast messages that have been received and processed by the SNTP client since last reboot

4.3.10 show sntp client

This command is used to display SNTP client settings.

Format	show sntp client
Mode	Privileged EXEC

Client Supported	
Modes	Supported SNTP Modes (Broadcast, Unicast, or Multicast).
SNTP Version	The highest SNTP version the client supports
Port	SNTP Client Port
Client Mode	Configured SNTP Client Mode
Poll Interval	Poll interval value for SNTP clients in seconds as a power of
	two.
Poll Timeout	Poll timeout value in seconds for SNTP clients.
Poll Retry	Poll retry value for SNTP clients.

4.3.11 show sntp server

This command is used to display SNTP server settings and configured servers.

Format	show sntp server
Mode	Privileged EXEC
Server IP	
Address	IP Address of configured SNTP Server
Server Type	Address Type of Server.
Server Stratum	Claimed stratum of the server for the last received valid packet.
Server Reference	
ID	Reference clock identifier of the server for the last received valid packet.
Server Mode	SNTP Server mode.
Server Max Entries	Total number of SNTP Servers allowed.
Server Current Entries	Total number of SNTP configured.

For each configured server:

IP Address	IP Address of configured SNTP Server.
Address Type	Address Type of configured SNTP server.
Priority	IP priority type of the configured server.
Version	SNTP Version number of the server. The protocol version used to query the server in unicast mode.

Port	Server Port Number
Last Attempt Time	Last server attempt time for the specified server.
Last Attempt Status	Last server attempt status for the server.
Total Unicast Requests	Number of requests to the server.
Failed Unicast Requests	Number of failed requests from server.

4.3.12 clock timezone

When using SNTP/NTP time servers to update the switch's clock, the time data received from the server is based on Coordinated Universal Time (UTC) which is the same as Greenwich Mean Time (GMT). This may not be the time zone in which the switch is located. Use the **clock timezone** command to configure a time zone specifying the number of hours and optionally the number of minutes difference from UTC. To set the switch clock to UTC, use the **no** form of the command.

Format	<pre>clock timezone zone-name +/-hours-offset [+/-minutes-off- set]</pre>
	[no] clock timezone
Parameters	
	Zone name A name to associate with the time zone
	Hours-offset Number of hours difference with UTC
	Minutes-offset Number of minutes difference with UTC
Mode	Global Config
Default	[no] clock timezone

4.4 MAC Address and MAC Database Commands

This section describes the commands you use to configure and view information about the system MAC address and the MAC address table.

4.4.1 network mac-address

This command sets locally administered MAC addresses. The following rules apply:

- Bit 6 of byte 0 (called the U/L bit) indicates whether the address is universally administered (b'0') or locally administered (b'1').
- Bit 7 of byte 0 (called the I/G bit) indicates whether the destination address is an individual address (b'0') or a group address (b'1').
- The second character, of the twelve character macaddr, must be 2, 6, A or E.

A locally administered address must have bit 6 On (b'1') and bit 7 Off (b'0').

Format	network mac-address $<\!macaddr\!>$
Mode	Privileged EXEC

4.4.2 network mac-type

This command specifies whether the switch uses the burned in MAC address or the locally-administered MAC address.

Default	burnedin
Format	network mac-type $\{local \mid burnedin\}$
Mode	Privileged EXEC

4.4.2.1 no network mac-type

This command resets the value of MAC address to its default.

Format	no network mac-type		
Mode	Privileged EXE		

4.4.3 macfilter

This command adds a static MAC filter entry for the MAC address <macaddr> on the VLAN <vlanid>. The <macaddr> parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

The restricted MAC Addresses are: 00:00:00:00:00:00, 01:80:C2:00:00:00 to 01:80:C2:00:00:0F, 01:80:C2:00:00:20 to 01:80:C2:00:00:21, and FF:FF:FF:FF:FF:FF.

The <vlanid> parameter must identify a valid VLAN.

Up to 100 static MAC filters may be created.

Format	<pre>macfilter <macaddr> <vlanid></vlanid></macaddr></pre>
Mode	Global Config

4.4.3.1 no macfilter

This command removes all filtering restrictions and the static MAC filter entry for the MAC address <macaddr> on the VLAN <vlanid>. The <macaddr> parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

The <vlanid> parameter must identify a valid VLAN.

Format	no macfilter	<macaddr></macaddr>	<vlanid></vlanid>
Mode	Global Confi	g	

4.4.4 macfilter adddest

This command adds the interface to the destination filter set for the MAC filter with the given <macaddr> and VLAN of <vlanid>. The <macaddr> parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

The <vlanid> parameter must identify a valid VLAN.

Format	macfilter adddest	<macaddr></macaddr>	<vlanid></vlanid>
Mode	Interface Config		

4.4.4.1 no macfilter adddest

This command removes a port from the destination filter set for the MAC filter with the given <macaddr> and VLAN of <vlanid>. The <macaddr> parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

The <vlanid> parameter must identify a valid VLAN.

Format	no macfilter adddest	<macaddr></macaddr>	<vlanid></vlanid>
Mode	Interface Config		

4.4.5 macfilter adddest all

This command adds all interfaces to the destination filter set for the MAC filter with the given <macaddr> and VLAN of <vlanid>. The <macaddr> parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

The <vlanid> parameter must identify a valid VLAN.

Format	macfilter adddest all
Mode	Global Config

4.4.5.1 no macfilter adddest all

This command removes all ports from the destination filter set for the MAC filter with the given <macaddr> and VLAN of <vlanid>. The <macaddr> parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

The <vlanid> parameter must identify a valid VLAN.

Format	no macfilter adddest all		
Mode	Global Config		

4.4.6 macfilter addsrc

This command adds the interface to the source filter set for the MAC filter with the MAC address of <macaddr> and VLAN of <vlanid>. The <macaddr> parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

The <vlanid> parameter must identify a valid VLAN.

Format	macfilter	addsrc	<macaddr></macaddr>	<vlanid></vlanid>
Mode	Interface Co	onfig		

4.4.6.1 no macfilter addsrc

This command removes a port from the source filter set for the MAC filter with the MAC address of <macaddr> and VLAN of <vlanid>. The <macaddr> parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

The <vlanid> parameter must identify a valid VLAN.

Format	no macfilter	addsrc	<macaddr></macaddr>	<vlanid></vlanid>
Mode	Interface Confi	g		

4.4.7 macfilter addsrc all

This command adds all interfaces to the source filter set for the MAC filter with the MAC address of <macaddr> and <vlanid>. You must specify the <macaddr> parameter as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6. The <vlanid> parameter must identify a valid VLAN.

Format	macfilter	addsrc	all
Mode	Global Con	fig	

4.4.7.1 no macfilter addsrc all

This command removes a port from the source filter set for the MAC filter with the MAC address of <macaddr> and VLAN of <vlanid>. The <macaddr> parameter must be specified as a 6-byte hexadecimal number in the format of b1:b2:b3:b4:b5:b6.

The <vlanid> parameter must identify a valid VLAN.

Format	no macfilter	addsrc	all
Mode	Global Config		

4.4.8 bridge aging-time

This command configures the forwarding database address aging timeout in seconds. In an IVL system, the [fdbid / all] parameter is required.

Default	300
Format	<pre>bridge aging-time <10-1,000,000> [fdbid all]</pre>
Mode	Global Config
Seconds	The <i><seconds></seconds></i> parameter must be within the range of 10 to 1,000,000 seconds.
Forwarding	
Database ID	The forwarding database ID (<i>fdbid</i>) indicates which for- warding database's aging timeout is being configured. Use the <i>all</i> option to configure the agetime of all forwarding databases.

4.4.8.1 no bridge aging-time

This command sets the forwarding database address aging timeout to 300 seconds. In an IVL system, the [fdbid | all] parameter is required.

Format	no bridge aging-time [fdbid all]
Mode	Global Config
Forwarding	
Database ID	Fdbid (Forwarding database ID) indicates which forwarding
	database's aging timeout is being configured. All is used to
	configure all forwarding database's agetime.

4.4.9 show forwardingdb agetime

This command displays the timeout for address aging. In an IVL system, the [fdbid | all] parameter is required.

Default	all
Format	<pre>show forwardingdb agetime [fdbid all]</pre>
Mode	Privileged EXEC
Forwarding DB ID	Forwarding database ID indicates the forwarding database whose aging timeout is to be shown. The all option is used to display the aging timeouts associated with all forwarding databases.
Agetime	In an IVL system, this parameter displays the address aging timeout for the associated forwarding database.

4.4.10 show mac-address-table multicast

This command displays the Multicast Forwarding Database (MFDB) information. If you enter the command with no parameter, the entire table is displayed. You can display the table entry for one MAC Address by specifying the MAC address as an optional parameter.

Format	<pre>show mac-address-table multicast <macaddr></macaddr></pre>
Mode	Privileged EXEC
MAC Address	A multicast MAC address for which the switch has forward- ing and or filtering information. The format is two-digit hexa- decimal numbers separated by colons, for example 01:23:45:67:89:AB. In an IVL system the MAC address will be displayed as a MAC address and VLAN ID combination of 8 bytes.
Туре	This displays the type of the entry. Static entries are those that are configured by the end user. Dynamic entries are added to the table as a result of a learning process or protocol.
Component	The component that is responsible for this entry in the Multi- cast Forwarding Database. Possible values are IGMP Snoop- ing, GMRP, and Static Filtering.
Description	The text description of this multicast table entry.

Interfaces	The list of interfaces that are designated for forwarding (Fwd:) and filtering (Flt:).
Forwarding	
Interfaces	The resultant forwarding list is derived from combining all the component's forwarding interfaces and removing the interfaces that are listed as the static filtering interfaces.

4.4.11 show mac-address-table static

This command displays the Static MAC Filtering information for all Static MAC Filters. If you select <all>, all the Static MAC Filters in the system are displayed. If you supply a value for <macaddr>, you must also enter a value for <vlanid>, and the system displays Static MAC Filter information only for that MAC address and VLAN.

Format	<pre>show mac-address-table static {<macaddr> <vlanid></vlanid></macaddr></pre>
Mode	Privileged EXEC
MAC Address	Is the MAC Address of the static MAC filter entry.
VLAN ID	Is the VLAN ID of the static MAC filter entry.
Source Port(s)	Indicates the source port filter set's slot and port(s).
Destination Port(s)	Indicates the destination port filter set's slot and port(s).

4.4.12 show mac-address-table staticfiltering

This command displays the Static Filtering entries in the Multicast Forwarding Database (MFDB) table.

Format	show mac-address-table staticfiltering
Mode	Privileged EXEC
Mac Address	A unicast MAC address for which the switch has forwarding and or filtering information. The format is 6 or 8 two-digit hexadecimal numbers that are separated by colons, for exam- ple 01:23:45:67:89:AB. In an IVL system the MAC address will be displayed as 8 bytes.
Туре	Displays the type of the entry. Static entries are those that are configured by the end user. Dynamic entries are added to the table as a result of a learning process or protocol.
Description	The text description of this multicast table entry.
Interfaces	The list of interfaces that are designated for forwarding (Fwd:) and filtering (Flt:).

4.4.13 show mac-address-table stats

This command displays the Multicast Forwarding Database (MFDB) statistics.

Format	show mac-address-table stats
Mode	Privileged EXEC
Total Entries	Displays the total number of entries that can possibly be in the Multicast Forwarding Database table.
Most MFDB Entries Ever	
Used	Displays the largest number of entries that have been present in the Multicast Forwarding Database table. This value is also known as the MFDB high-water mark.
Current Entries	Displays the current number of entries in the MFDB.

4.5 DNS Client Commands

The Domain Name System (DNS) is an Internet directory service. DNS is used to translate domain names to IP addresses. A DNS Client (often referred to as a resolver) uses a defined protocol to obtain resource data from name servers on its network.

The DNS Client component must be globally enabled or disabled. When the client is enabled, it provides a hostname lookup service to other components in the switch. The client contacts one or more DNS servers to resolve a hostname to an IP address. The DNS servers list is configured by providing an IP address for each DNS name server, and server precedence is determined by the order in which the servers are added to this list. A default domain name can be configured, which defines the domain to use when performing a lookup on an unqualified hostname. Static hostname-to-address mappings can be added and removed from the local cache.

The DNS client supports 128 entries in the DNS cache. Any application component requiring a DNS lookup may request services from the DNS client. When the DNS client is administratively disabled the local cache is purged. Changes to the name server configuration do not affect the cache. If a stacking switchover occurs, the new Master unit begins with a cleared cache.

The following applications support domain name in addition to the IP address format:

Radius DHCP Relay SNTP SNMP TFTP SYSLOG Ping UDP Relay

4.5.1 ip domain-lookup

To enable the IP Domain Naming System (DNS)-based host name-to-address translation, use the **ip domain-lookup** global configuration command. To disable the DNS, use the **no** form of this command

Format	[no] ip domain-lookup
Mode	Global Config
Default	enabled

4.5.2 ip domain-name

To define a default domain name (*<name>*) that the software uses to complete unqualified host names (names without a dotted-decimal domain name), use the **ip domain-name** global configuration command. To remove default domain name, use the **no** form of this command.

Default domain used to complete unqualified host names. Do not include the initial period that separates an unqualified name from the domain name.

<name> is a string of 1 to 255 characters.

Format	ip domain-name name		
	no ip domain-name		
Mode	Global Config		

4.5.3 ip name-server

To set the available name servers, use the **ip name-server** global configuration command. *<server-address>* is IP addresses of the name server. Up to 8 servers can be defined in one command, or by using multiple commands. The preference of the servers is determined by the order they were entered. To remove a name server, use the **no** form of this command.

Format	<pre>[no] ip name-server server-address1 [server-address2 server-address8]</pre>
Mode	Global Config

4.5.4 ip host

To define static host name *<name>* to IP address *<address>* mapping in the host cache, use the **ip host** global configuration command. The *<name>* string is from 1 to 255 characters. To remove the name-to-address mapping, use the **no** form of this command.

Format	[no] ip host name address
Mode	Global Config

4.5.5 clear host

To delete entries from the host name-to-address cache, use the **clear host** Privileged EXEC command.

Format	clear host $[name \mid *]$
Mode	Privileged EXEC Mode

4.5.6 show hosts

To display the default domain name, a list of name server hosts, the static and the cached list of host names and addresses, use the **show hosts** EXEC command.

Format	show hosts [name]	
Mode	Privileged EXEC Mode	

Chapter 5 Spanning Tree Protocol Commands

This section describes the spanning tree protocol (STP) commands available in the 7200 Series Managed Switch CLI. STP helps prevent network loops, duplicate messages, and network instability.

The STP Commands section includes the following topics:

- Section 5.1 "STP Configuration Commands" on page 5-1
- Section 5.2 "STP Show Commands" on page 5-10

The commands in this section are in one of two functional groups:

- Show commands display switch settings, statistics, and other information.
- Configuration commands configure features and options of the switch. For every configuration command, there is a show command that displays the configuration setting.

5.1 STP Configuration Commands

This section describes the commands you use to configure Spanning Tree Protocol (STP).

Note: STP is enabled by default. If STP is disabled, the system does not generate BPDU messages.

5.1.1 spanning-tree

 \rightarrow

This command sets the spanning-tree operational mode to enabled.

DefaultenabledFormatspanning-treeModeGlobal Config

5.1.1.1 no spanning-tree

This command sets the spanning-tree operational mode to disabled. While disabled, the spanning-tree configuration is retained and can be changed, but is not activated.

Format	no spanning-tree	
Mode	Global Config	

5.1.2 spanning-tree bpdumigrationcheck

This command enables BPDU migration check on a given interface. The **all** option enables BPDU migration check on all interfaces.

Format	<pre>spanning-tree bpdumigrationcheck {<slot port=""> </slot></pre>
	all}
Mode	Global Config

5.1.2.1 no spanning-tree bpdumigrationcheck

This command disables BPDU migration check on a given interface. The **all** option disables BPDU migration check on all interfaces.

Format	<pre>no spanning-tree bpdumigrationcheck {<slot port=""> all}</slot></pre>
Mode	Global Config

5.1.3 spanning-tree configuration name

This command sets the Configuration Identifier Name for use in identifying the configuration that this switch is currently using. The *<name>* is a string of up to 32 characters.

Default	base MAC address in hexadecimal notation		
Format	<pre>spanning-tree configuration name <name></name></pre>		
Mode	Global Config		

5.1.3.1 no spanning-tree configuration name

This command resets the Configuration Identifier Name to its default.

Format	no spanning-tree	configuration	name
Mode	Global Config		

5.1.4 spanning-tree configuration revision

This command sets the Configuration Identifier Revision Level for use in identifying the configuration that this switch is currently using. The Configuration Identifier Revision Level is a number in the range of 0 to 65535.

Default	0
Format	<pre>spanning-tree configuration revision <0-65535></pre>
Mode	Global Config

5.1.4.1 no spanning-tree configuration revision

This command sets the Configuration Identifier Revision Level for use in identifying the configuration that this switch is currently using to the default value, i.e. 0.

Format	no spanning-tree	configuration	revision
Mode	Global Config		

5.1.5 spanning-tree edgeport

This command specifies that this port is an Edge Port within the common and internal spanning tree. This allows this port to transition to Forwarding State without delay.

Format	spanning-tree edgeport
Mode	Interface Config

5.1.5.1 no spanning-tree edgeport

This command specifies that this port is not an Edge Port within the common and internal spanning tree.

Format	no spanning-tree	edgeport
Mode	Interface Config	

5.1.6 spanning-tree edgeport all

This command specifies that every port is an Edge Port within the common and internal spanning tree. This allows all ports to transition to Forwarding State without delay.

Format	spanning-tree	edgeport	all
Mode	Global Config		

5.1.6.1 no spanning-tree edgeport all

This command disables Edge Port mode for all ports within the common and internal spanning tree.

Format	<pre>spanning-tree</pre>	edgeport	all
Mode	Global Config		

5.1.7 spanning-tree forceversion

This command sets the Force Protocol Version parameter to a new value. The Force Protocol Version can be one of the following:

- 802.1d ST BPDUs are transmitted rather than MST BPDUs (IEEE 802.1d functionality supported)
- 802.1w RST BPDUs are transmitted rather than MST BPDUs (IEEE 802.1w functionality supported)
- 802.1s MST BPDUs are transmitted (IEEE 802.1s functionality supported)

Default	802.1s
Format	<pre>spanning-tree forceversion <802.1d 802.1w </pre>
	802.1s>
Mode	Global Config

5.1.7.1 no spanning-tree forceversion

This command sets the Force Protocol Version parameter to the default value, i.e. 802.1s.

Format	no spanning-tree	forceversion
Mode	Global Config	

5.1.8 spanning-tree forward-time

This command sets the Bridge Forward Delay parameter to a new value for the common and internal spanning tree. The forward-time value is in seconds within a range of 4 to 30, with the value being greater than or equal to "(Bridge Max Age / 2) + 1".

Default	15
Format	<pre>spanning-tree forward-time <4-30></pre>
Mode	Global Config

5.1.8.1 no spanning-tree forward-time

This command sets the Bridge Forward Delay parameter for the common and internal spanning tree to the default value of 15.

Format	no spanning-tree	forward-time
Mode	Global Config	

5.1.9 spanning-tree hello-time

This command sets the Admin Hello Time parameter to a new value for the common and internal spanning tree. The hello time *<value>* is in whole seconds within a range of 1 to 10, with the value being less than or equal to (*Bridge Max Age / 2*) - 1.

Default	2	
Format	spanning-tree hello-time	<1-10>
Mode	Interface Config	

5.1.9.1 no spanning-tree hello-time

This command sets the admin Hello Time parameter for the common and internal spanning tree to the default value.

Format	no spanning-tree hello-time
Mode	Interface Config

5.1.10 spanning-tree max-age

This command sets the Bridge Max Age parameter to a new value for the common and internal spanning tree. The max-age value is in seconds within a range of 6 to 40, with the value being less than or equal to 2 x (*Bridge Forward Delay - 1*).

Default	20
Format	<pre>spanning-tree max-age <6-40></pre>
Mode	Global Config

5.1.10.1 no spanning-tree max-age

This command sets the Bridge Max Age parameter for the common and internal spanning tree to the default value of 20.

Format	no spanning-tree max-age
Mode	Global Config

5.1.11 spanning-tree max-hops

This command sets the MSTP Max Hops parameter to a new value for the common and internal spanning tree. The max-hops value is a range from 1 to 127.

Default	20	
Format	spanning-tree max-hops	<1-127>
Mode	Global Config	

5.1.11.1 no spanning-tree max-hops

This command sets the Bridge Max Hops parameter for the common and internal spanning tree to the default value.

Format	no spanning-tree max-hops
Mode	Global Config

5.1.12 spanning-tree mst

This command sets the Path Cost or Port Priority for this port within the multiple spanning tree instance or in the common and internal spanning tree. If you specify an *<mstid>* parameter that corresponds to an existing multiple spanning tree instance, the configurations are done for that multiple spanning tree instance. If you specify 0 (defined as the default CIST ID) as the *<mstid>*, the configurations are done for the common and internal spanning tree instance.

If you specify the **cost** option, the command sets the path cost for this port within a multiple spanning tree instance or the common and internal spanning tree instance, depending on the *mstid>* parameter. You can set the path cost as a number in the range of 1 to 200000000 or **auto**. If you select **auto** the path cost value is set based on Link Speed.

If you specify the **external-cost** option, this command sets the external-path cost for MST instance '0' i.e. CIST instance. You can set the external cost as a number in the range of 1 to 200000000 or **auto**. If you specify auto, the external path cost value is set based on Link Speed.

If you specify the **port-priority** option, this command sets the priority for this port within a specific multiple spanning tree instance or the common and internal spanning tree instance, depending on the *<mstid>* parameter. The port-priority value is a number in the range of 0 to 240 in increments of 16.

Default	cost: auto; external-cost: auto; port-priority: 128
Format	<pre>spanning-tree mst <mstid> {{cost <1-20000000> auto} </mstid></pre>

{external-cost <1-20000000> | auto}| port-priority <0-240>}

Interface Config

5.1.12.1 no spanning-tree mst

Mode

This command sets the Path Cost or Port Priority for this port within the multiple spanning tree instance, or in the common and internal spanning tree to the respective default values. If you specify an *<mstid>* parameter that corresponds to an existing multiple spanning tree instance, you are configuring that multiple spanning tree instance. If you specify 0 (defined as the default CIST ID) as the *<mstid>*, you are configuring the common and internal spanning tree instance.

If the you specify **cost**, this command sets the path cost for this port within a multiple spanning tree instance or the common and internal spanning tree instance, depending on the *<mstid>* parameter, to the default value, i.e. a path cost value based on the Link Speed.

If you specify **external-cost**, this command sets the external path cost for this port for mst '0' instance, to the default value, i.e. a path cost value based on the Link Speed.

If you specify **port-priority**, this command sets the priority for this port within a specific multiple spanning tree instance or the common and internal spanning tree instance, depending on the *<mstid>* parameter, to the default value, i.e. 128.

Format	<pre>no spanning-tree mst <mstid> <cost external-cost="" port-priority="" =""></cost></mstid></pre>
Mode	Interface Config

5.1.13 spanning-tree mst instance

This command adds a multiple spanning tree instance to the switch. The parameter *(mstid)* is a number within a range of 1 to 4094, that corresponds to the new instance ID to be added. The maximum number of multiple instances supported by the switch is 4.

Format	spanning-tree mst	instance	<mstid></mstid>
Mode	Global Config		

5.1.13.1 no spanning-tree mst instance

This command removes a multiple spanning tree instance from the switch and reallocates all VLANs allocated to the deleted instance to the common and internal spanning tree. The parameter $\langle mstid \rangle$ is a number that corresponds to the desired existing multiple spanning tree instance to be removed.

Format	no spanning-tree mst	<pre>instance <mstid></mstid></pre>
Mode	Global Config	

5.1.14 spanning-tree mst priority

This command sets the bridge priority for a specific multiple spanning tree instance. The parameter $\langle mstid \rangle$ is a number that corresponds to the desired existing multiple spanning tree instance. The priority value is a number within a range of 0 to 61440 in increments of 4096.

If you specify 0 (defined as the default CIST ID) as the *mstid>*, this command sets the Bridge Priority parameter to a new value for the common and internal spanning tree. The bridge priority value is a number within a range of 0 to 61440. The twelve least significant bits are masked according to the 802.1s specification. This causes the priority to be rounded down to the next lower valid priority.

Default	32768	
Format	<pre>spanning-tree mst priority <mstid> <0-6</mstid></pre>	51440>
Mode	Global Config	

5.1.14.1 no spanning-tree mst priority

This command sets the bridge priority for a specific multiple spanning tree instance to the default value, i.e. 32768. The parameter *<mstid>* is a number that corresponds to the desired existing multiple spanning tree instance.

If 0 (defined as the default CIST ID) is passed as the *mstid>*, this command sets the Bridge Priority parameter for the common and internal spanning tree to the default value, i.e. 32768.

Format	spanning-tree mst ;	<pre>priority <mstid></mstid></pre>
Mode	Global Config	

5.1.15 spanning-tree mst vlan

This command adds an association between a multiple spanning tree instance and a VLAN so that the VLAN is no longer associated with the common and internal spanning tree.

The parameter *<mstid>* is a number that corresponds to the desired existing multiple spanning tree instance. The *<vlanid>* corresponds to an existing VLAN ID.

Format	spanning-tree mst vlan	<mstid></mstid>	<vlanid></vlanid>
Mode	Global Config		

5.1.15.1 no spanning-tree mst vlan

This command removes an association between a multiple spanning tree instance and a VLAN so that the VLAN is again be associated with the common and internal spanning tree. The parameter *<mstid>* is a number that corresponds to the desired existing multiple spanning tree instance. The *<vlanid>* corresponds to an existing VLAN ID.

Format	no spanning-tree mst vlar	• <mstid> <vlanid></vlanid></mstid>
Mode	Global Config	

5.1.16 spanning-tree port mode

This command sets the Administrative Switch Port State for this port to enabled.

Default	disabled
Format	spanning-tree port mode
Mode	Interface Config

5.1.16.1 no spanning-tree port mode

This command sets the Administrative Switch Port State for this port to disabled.

Format	no spanning-tree port mode
Mode	Interface Config

5.1.17 spanning-tree port mode all

This command sets the Administrative Switch Port State for all ports to enabled.

Default	disabled
Format	spanning-tree port mode all
Mode	Global Config

5.1.17.1 no spanning-tree port mode all

This command sets the Administrative Switch Port State for all ports to disabled.

Format	no spanning-tree port mode all
Mode	Global Config

5.1.18 spanning-tree bpduforwarding

Normally a switch will not forward Spanning Tree Protocol (STP) BPDU packets if STP is disabled. However, if in some network setup, the user wishes to forward BDPU packets received from other network devices, this command can be used to enable the forwarding.

Default	disabled
Format	spanning-tree bpduforwarding
Mode	Global Config

5.1.18.1 no spanning-tree bpduforwarding

This command will cause the STP BPDU packets received from the network to be dropped if STP is disabled.

Format	no spanning-tree bpduforwarding
Mode	Global Config

5.2 STP Show Commands

This section describes the commands you use to view information about STP configuration and status.

5.2.1 show spanning-tree

This command displays spanning tree settings for the common and internal spanning tree, when the optional parameter "brief" is not included in the command. The following details are displayed.

Format	<pre>show spanning-tree <brief></brief></pre>
Modes	Privileged EXEC
	User EXEC

Bridge Priority	Specifies the bridge priority for the Common and Internal Spanning tree (CST). The value lies between 0 and 61440. It is displayed in multiples of 4096.
Bridge Identifier	The bridge identifier for the CST. It is made up using the bridge priority and the base MAC address of the bridge.
Time Since Topology Change	Time in seconds.
Topology Change Count	Number of times changed.
Topology Change	Boolean value of the Topology Change parameter for the switch indicating if a topology change is in progress on any port assigned to the common and internal spanning tree.
Designated Root	The bridge identifier of the root bridge. It is made up from the bridge priority and the base MAC address of the bridge.
Root Path Cost	Value of the Root Path Cost parameter for the common and internal spanning tree.
Root Port Identifier	Identifier of the port to access the Designated Root for the CST.
Root Port Max Age	Derived value.
Root Port Bridge Forward Delay	Derived value.
Hello Time	Configured value of the parameter for the CST.
Bridge Hold Time	Minimum time between transmission of Configuration Bridge Protocol Data Units (BPDUs)
Bridge Max Hops	Bridge max-hops count for the device.
CST Regional Root	Bridge Identifier of the CST Regional Root. It is made up using the bridge priority and the base MAC address of the bridge.
Regional Root Path Cost	Path Cost to the CST Regional Root.

Associated FIDs	List of forwarding database identifiers currently associated with this instance.
Associated VLANs	List of VLAN IDs currently associated with this instance.

When you include the **brief** keyword, this command displays spanning tree settings for the bridge and the following information appears.

Bridge Priority	Configured value.
Bridge Identifier	The bridge identifier for the selected MST instance. It is made up using the bridge priority and the base MAC address of the bridge.
Bridge Max Age	Configured value.
Bridge Max Hops	Bridge max-hops count for the device.
Bridge Hello Time	Configured value.
Bridge Forward Delay	Configured value.
Bridge Hold Time	Minimum time between transmission of Configuration Bridge Protocol Data Units (BPDUs)

5.2.2 show spanning-tree summary

This command displays spanning tree settings and parameters for the switch. The following details are displayed on execution of the command.

show spanning-tree summary
Privileged EXEC User EXEC
Enabled or disabled.
Version of 802.1 currently supported (IEEE 802.1s, IEEE 802.1w, or IEEE 802.1d) based upon the Force Protocol Version parameter.
Identifier used to identify the configuration currently being used.

Configuration Revision Level	Identifier used to identify the configuration currently being used.
Configuration Digest Key	Identifier used to identify the configuration currently being used.
MST Instances	List of all multiple spanning tree instances configured on the switch

5.2.3 show spanning-tree interface

This command displays the settings and parameters for a specific switch port within the common and internal spanning tree. The *<slot/port>* is the desired switch port. The following details are displayed on execution of the command.

<pre>show spanning-tree interface <slot port=""></slot></pre>
Privileged EXEC User EXEC
Admin hello time for this port.
Enabled or disabled.
Time since port was reset, displayed in days, hours, minutes, and seconds.
Spanning Tree Protocol Bridge Protocol Data Units sent
Spanning Tree Protocol Bridge Protocol Data Units received.
Rapid Spanning Tree Protocol Bridge Protocol Data Units sent
Rapid Spanning Tree Protocol Bridge Protocol Data Units received.
Multiple Spanning Tree Protocol Bridge Protocol Data Units sent

 MSTP BPDUs

 Received
 Multiple Spanning Tree Protocol Bridge Protocol Data Units received.

5.2.4 show spanning-tree mst port detailed

This command displays the detailed settings and parameters for a specific switch port within a particular multiple spanning tree instance. The parameter *<mstid>* is a number that corresponds to the desired existing multiple spanning tree instance. The *<slot/port>* is the desired switch port.

<pre>show spanning-tree mst port detailed <mstid> <slot port=""></slot></mstid></pre>
Privileged EXEC User EXEC
The ID of the existing MST instance.
The port identifier for the specified port within the selected MST instance. It is made up from the port priority and the interface number of the port.
The priority for a particular port within the selected MST instance. The port priority is displayed in multiples of 16.
Current spanning tree state of this port.
Each enabled MST Bridge Port receives a Port Role for each spanning tree. The port role is one of the following values: Root Port, Designated Port, Alternate Port, Backup Port, Master Port or Disabled Port
This indicates whether auto calculation for port path cost is enabled.
Configured value of the Internal Port Path Cost parameter.
This indicates whether auto calculation for external port path cost is enabled.
Configured value of the external Port Path Cost parameter.
The Identifier of the designated root for this port.

Designated Port	
Cost	Path Cost offered to the LAN by the Designated Port
Designated Bridge	Bridge Identifier of the bridge with the Designated Port.
Designated Port Identifier	Port on the Designated Bridge that offers the lowest cost to the LAN.

If you specify 0 (defined as the default CIST ID) as the *stid*, this command displays the settings and parameters for a specific switch port within the common and internal spanning tree. The *slot/port* is the desired switch port. In this case, the following are displayed.

Port Identifier	The port identifier for this port within the CST.	
Port Priority	The priority of the port within the CST.	
Port Forwarding State	The forwarding state of the port within the CST.	
Port Role	The role of the specified interface within the CST.	
Port Path Cost	The configured path cost for the specified interface.	
Designated Root	Identifier of the designated root for this port within the CST.	
Designated Port Cost	Path Cost offered to the LAN by the Designated Port.	
Designated Bridge	The bridge containing the designated port	
Designated Port Identifier	Port on the Designated Bridge that offers the lowest cost to the LAN	
Topology Change Acknowledgement	Value of flag in next Configuration Bridge Protocol Data Unit (BPDU) transmission indicating if a topology change is in progress for this port.	
Hello Time	The hello time in use for this port.	
Edge Port	The configured value indicating if this port is an edge port.	
Edge Port Status	The derived value of the edge port status. True if operating as an edge port; false otherwise.	

Point To Point MAC Status	Derived value indicating if this port is part of a point to point
CST Regional Root	The regional root identifier in use for this port.
CST Port Cost	The configured path cost for this port.

5.2.5 show spanning-tree mst port summary

This command displays the settings of one or all ports within the specified multiple spanning tree instance. The parameter *(mstid)* indicates a particular MST instance. The parameter *(<slot/port> / all)* indicates the desired switch port or all ports.

If you specify 0 (defined as the default CIST ID) as the *<mstid>*, the status summary displays for one or all ports within the common and internal spanning tree.

Format	<pre>show spanning-tree mst port summary <mstid> {<slot port=""> all}</slot></mstid></pre>
Modes	Privileged EXEC User EXEC
MST Instance ID	The MST instance associated with this port.
Interface	Valid slot and port number separated by forward slashes.
Туре	Currently not used.
STP State	The forwarding state of the port in the specified spanning tree instance
Port Role	The role of the specified port within the spanning tree.
Link Status	The operational status of the link. Possible values are "Up" or "Down".
Link Trap	The link trap configuration for the specified interface.

5.2.6 show spanning-tree mst summary

This command displays summary information about all multiple spanning tree instances in the switch. On execution, the following details are displayed.

Format	show spanning-tree mst summary
Modes	Privileged EXEC
	User EXEC

MST Instance ID List	List of multiple spanning trees IDs currently configured.
For each MSTID:	
Associated FIDs	List of forwarding database identifiers associated with this instance.
Associated VLANs	List of VLAN IDs associated with this instance.

5.2.7 show spanning-tree vlan

This command displays the association between a VLAN and a multiple spanning tree instance. The *<vlanid>* corresponds to an existing VLAN ID.

Format	<pre>show spanning-tree vlan <vlanid></vlanid></pre>	
Modes	Privileged EXEC User EXEC	
VLAN Identifier	The VLANs associated with the selected MST instance.	
Associated Instance	Identifier for the associated multiple spanning tree instance of "CST" if associated with the common and internal spanning tree.	

Chapter 6 VLAN Commands

This section describes the VLAN commands available in the 7200 Series Managed Switch CLI. VLANs allow users located on different physical networks to be on the same logical network.

The VLAN Commands section includes the following topics:

- Section 6.1 "VLAN Configuration Commands" on page 6-1
- Section 6.2 "VLAN Show Commands" on page 6-11
- Section 6.3 "Provisioning (IEEE 802.1p) Commands" on page 6-14

The commands in this section are in one of two functional groups:

- Show commands display switch settings, statistics, and other information.
- Configuration commands configure features and options of the switch. For every configuration command, there is a show command that displays the configuration setting.

6.1 VLAN Configuration Commands

This section describes the commands you use to configure VLAN settings.

6.1.1 vlan database

This command gives you access to the VLAN Config mode, which allows you to configure VLAN characteristics.

Format	vlan database
Mode	Privileged EXEC

6.1.2 network mgmt_vlan

This command configures the Management VLAN ID.

Default	1
Format	<pre>network mgmt_vlan <1-4069></pre>
Mode	Privileged EXEC

6.1.2.1 no network mgmt_vlan

This command sets the Management VLAN ID to the default.

Format	no network mgmt_vlan
Mode	Privileged EXEC

6.1.3 vlan

This command creates a new VLAN and assigns it an ID. The ID is a valid VLAN identification number (ID 1 is reserved for the default VLAN). VLAN range is 2-4094.

Format	vlan <2-4094>
Mode	VLAN Config

6.1.3.1 no vlan

This command deletes an existing VLAN. The ID is a valid VLAN identification number (ID 1 is reserved for the default VLAN). The VLAN range is 2-4094.

Format	no vlan <2-4094>
Mode	VLAN Config

6.1.4 vlan acceptframe

This command sets the frame acceptance mode per interface. For VLAN Only mode, untagged frames or priority frames received on this interface are discarded. For Admit All mode, untagged frames or priority frames received on this interface are accepted and assigned the value of the interface VLAN ID for this port. With either option, VLAN tagged frames are forwarded in accordance with the IEEE 802.1Q VLAN Specification.

Default	all
Format	<pre>vlan acceptframe {vlanonly all}</pre>
Mode	Interface Config
6.1.4.1 no vlan acceptframe

This command sets the frame acceptance mode per interface to Admit All. For Admit All mode, untagged frames or priority frames received on this interface are accepted and assigned the value of the interface VLAN ID for this port. With either option, VLAN tagged frames are forwarded in accordance with the IEEE 802.1Q VLAN Specification.

Format	vlan acceptframe	$\{vlanonly \mid$	all}
Mode	Interface Config		

6.1.5 vlan ingressfilter

This command enables ingress filtering. If ingress filtering is disabled, frames received with VLAN IDs that do not match the VLAN membership of the receiving interface are admitted and forwarded to ports that are members of that VLAN.

Default	disabled
Format	vlan ingressfilter
Mode	Interface Config

6.1.5.1 no vlan ingressfilter

This command disables ingress filtering. If ingress filtering is disabled, frames received with VLAN IDs that do not match the VLAN membership of the receiving interface are admitted and forwarded to ports that are members of that VLAN.

Format	no vlan ingressfilter
Mode	Interface Config

6.1.6 vlan makestatic

This command changes a dynamically created VLAN (one that is created by GVRP registration) to a static VLAN (one that is permanently configured and defined). The ID is a valid VLAN identification number. VLAN range is 2-4094.

Format	vlan makestatic <2-4094>
Mode	VLAN Config

6.1.7 vlan name

This command changes the name of a VLAN. The name is an alphanumeric string of up to 32 characters, and the ID is a valid VLAN identification number. ID range is 1-4094.

Default	VLAN ID 1 - default; other VLANS - blank string
Format	vlan name <2-4094> <name></name>
Mode	VLAN Config

6.1.7.1 no vlan name

This command sets the name of a VLAN to a blank string.

Format	no vlan name <2-4094>
Mode	VLAN Config

6.1.8 vlan participation

This command configures the degree of participation for a specific interface in a VLAN. The ID is a valid VLAN identification number, and the interface is a valid interface number.

Format	<pre>vlan participation {exclude include auto} <1- 4094></pre>
Mode	Interface Config
Participation options are:	
include	The interface is always a member of this VLAN. This is equivalent to registration fixed.
exclude	The interface is never a member of this VLAN. This is equivalent to registration forbidden.
auto	The interface is dynamically registered in this VLAN by GVRP. The interface will not participate in this VLAN unless a join request is received on this interface. This is equivalent to registration normal.

6.1.9 vlan participation all

This command configures the degree of participation for all interfaces in a VLAN. The ID is a valid VLAN identification number.

Format	<pre>vlan participation all {exclude include auto} <1-4094></pre>
Mode	Global Config
Participation options are:	
include	The interface is always a member of this VLAN. This is equivalent to registration fixed.
exclude	The interface is never a member of this VLAN. This is equivalent to registration forbidden.
auto	The interface is dynamically registered in this VLAN by GVRP. The interface will not participate in this VLAN unless a join request is received on this interface. This is equivalent to registration normal.

6.1.10 vlan port acceptframe all

This command sets the frame acceptance mode for all interfaces. The modes defined as follows:

- VLAN Only mode Untagged frames or priority frames received on this interface are discarded.
- Admit All mode Untagged frames or priority frames received on this interface are accepted and assigned the value of the interface VLAN ID for this port.

With either option, VLAN tagged frames are forwarded in accordance with the IEEE 802.1Q VLAN Specification.

Default	all
Format	<pre>vlan port acceptframe all {vlanonly all}</pre>
Mode	Global Config

6.1.10.1 no vlan port acceptframe all

This command sets the frame acceptance mode for all interfaces to Admit All. For Admit All mode, untagged frames or priority frames received on this interface are accepted and assigned the value of the interface VLAN ID for this port. With either option, VLAN tagged frames are forwarded in accordance with the IEEE 802.1Q VLAN Specification.

Format	no vlan port acceptframe all
Mode	Global Config

6.1.11 vlan port pvid all

This command changes the VLAN ID for all interface.

Default	1
Format	vlan port pvid all <1-4094>
Mode	Global Config

6.1.11.1 no vlan port pvid all

This command sets the VLAN ID for all interfaces to 1.

Format	no vlan port pvid all
Mode	Global Config

6.1.12 vlan port tagging all

This command configures the tagging behavior for all interfaces in a VLAN to enabled. If tagging is enabled, traffic is transmitted as tagged frames. If tagging is disabled, traffic is transmitted as untagged frames. The ID is a valid VLAN identification number.

Format	<pre>vlan port tagging all <1-4094></pre>
Mode	Global Config

6.1.12.1 no vlan port tagging all

This command configures the tagging behavior for all interfaces in a VLAN to disabled. If tagging is disabled, traffic is transmitted as untagged frames. The ID is a valid VLAN identification number.

Format	no vlan port tagging all
Mode	Global Config

6.1.13 vlan port ingressfilter all

This command enables ingress filtering for all ports. If ingress filtering is disabled, frames received with VLAN IDs that do not match the VLAN membership of the receiving interface are admitted and forwarded to ports that are members of that VLAN.

Default	disabled
Format	vlan port ingressfilter all
Mode	Global Config

6.1.13.1 no vlan port ingressfilter all

This command disables ingress filtering for all ports. If ingress filtering is disabled, frames received with VLAN IDs that do not match the VLAN membership of the receiving interface are admitted and forwarded to ports that are members of that VLAN.

Format no vlan port ingressfilter all Mode 6.1.14 Global Config

6.1.15 vlan protocol group

This command adds protocol-based VLAN group to the system. The *groupName* is a character string of 1 to 16 characters. When it is created, the protocol group will be assigned a unique number that will be used to identify the group in subsequent commands.

Format	<pre>vlan protocol group <groupname></groupname></pre>
Mode	Global Config

6.1.16 vlan protocol group add protocol

This command adds the *<protocol>* to the protocol-based VLAN identified by *<groupid>*. A group may have more than one protocol associated with it. Each interface and protocol combination can only be associated with one group. If adding a protocol to a group causes any conflicts with interfaces currently associated with the group, this command will fail and the protocol will not be added to the group. The possible values for protocol are *ip*, *arp*, and *ipx*.

Default	none
Format	<pre>vlan protocol group add protocol <groupid> <proto- col></proto- </groupid></pre>
Mode	Global Config

6.1.16.1 no vlan protocol group add protocol

This command removes the *<protocol>* from this protocol-based VLAN group that is identified by this *<groupid>*. The possible values for protocol are *ip*, *arp*, and *ipx*.

Format	no vlan protocol group add protocol	<groupid></groupid>
	<protocol></protocol>	
Mode	Global Config	

6.1.17 vlan protocol group remove

This command removes the protocol-based VLAN group that is identified by this *<groupid>*.

Formatvlan protocol group remove <groupid>ModeGlobal Config

6.1.18 protocol group

This command attaches a *<vlanid>* to the protocol-based VLAN identified by *<groupid>*. A group may only be associated with one VLAN at a time, however the VLAN association can be changed.

The referenced VLAN should be created prior to the creation of the protocol-based VLAN except when GVRP is expected to create the VLAN.

Default	none
Format	<pre>protocol group <groupid> <vlanid></vlanid></groupid></pre>
Mode	VLAN Config

6.1.18.1 no protocol group

This command removes the *<vlanid>* from this protocol-based VLAN group that is identified by this *<groupid>*.

Format	no protocol group	<groupid></groupid>	<vlanid></vlanid>
Mode	VLAN Config		

6.1.19 protocol vlan group

This command adds the physical interface to the protocol-based VLAN identified by *<groupid>*. You can associate multiple interfaces with a group, but you can only associate each interface and protocol combination with one group. If adding an interface to a group causes any conflicts with protocols currently associated with the group, this command fails and the interface(s) are not added to the group.

Create the referenced VLAN before you create the protocol-based VLAN except when you configure GVRP to create the VLAN.

Format	protocol vlan group <g< th=""><th>groupid></th></g<>	groupid>
Mode	Interface Config	

6.1.19.1 no protocol vlan group

This command removes the interface from this protocol-based VLAN group that is identified by this *groupid*.

Format	no protocol vlan group <groupid></groupid>
Mode	Interface Config

6.1.20 protocol vlan group all

This command adds all physical interfaces to the protocol-based VLAN identified by *<groupid>*. You can associate multiple interfaces with a group, but you can only associate each interface and protocol combination with one group. If adding an interface to a group causes any conflicts with protocols currently associated with the group, this command will fail and the interface(s) will not be added to the group.

Create the referenced VLAN before you create the protocol-based VLAN except when you configure GVRP to create the VLAN.

Format	<pre>protocol vlan group all <groupid></groupid></pre>
Mode	Global Config

6.1.20.1 no protocol vlan group all

This command removes all interfaces from this protocol-based VLAN group that is identified by this *groupid*>.

Format	no protocol	vlan	group	all	<groupid></groupid>
Mode	Global Config	Ś			

6.1.21 vlan pvid

This command changes the VLAN ID per interface. When an untagged packet comes to the switch, it will be tagged with the PVID value as the VLAN ID for further processing. By default, every port belongs to VLAN 1 and the PVID value is set to 1.

Default	1
Format	vlan pvid <1-4094>
Mode	Interface Config

6.1.21.1 no vlan pvid

This command sets the VLAN ID per interface to 1.

Format	no vlan pvid
Mode	Interface Config

6.1.22 vlan tagging

This command configures the tagging behavior for a specific interface in a VLAN to enabled. If tagging is enabled, traffic is transmitted as tagged frames. If tagging is disabled, traffic is transmitted as untagged frames. The ID is a valid VLAN identification number.

Format	<pre>vlan tagging <1-4094></pre>
Mode	Interface Config

6.1.22.1 no vlan tagging

This command configures the tagging behavior for a specific interface in a VLAN to disabled. If tagging is disabled, traffic is transmitted as untagged frames. The ID is a valid VLAN identification number.

Format	no vlan tagging <1-4094>
Mode	Interface Config

6.2 VLAN Show Commands

This section describes the commands you use to view VLAN settings.

6.2.1 show vlan

This command displays a list of all configured VLANs.

Format	show vlan
Modes	Privileged EXEC User EXEC
VLAN ID	There is a VLAN Identifier (vlanid) associated with each VLAN. The range of the VLAN ID is 1 to 4094.
VLAN Name	A string associated with this VLAN as a convenience. It can be up to 32 alphanumeric characters long, including blanks. The default is blank. VLAN ID 1 always has a name of "Default." This field is optional.
VLAN Type	Type of VLAN, which can be Default (VLAN $ID = 1$) or static (one that is configured and permanently defined), or a Dynamic (one that is created by GVRP registration).

6.2.2 show vlan <vlan_id>

This command displays detailed information, including interface information, for a specific VLAN. The ID is a valid VLAN identification number.

Format	<pre>show vlan <vlanid></vlanid></pre>
Modes	Privileged EXEC
	User EXEC
VLAN ID	There is a VLAN Identifier (VID) associated with each VLAN. The range of the VLAN ID is 1 to 4094.
VLAN Name	A string associated with this VLAN as a convenience. It can be up to 32 alphanumeric characters long, including blanks. The default is blank. VLAN ID 1 always has a name of "Default." This field is optional.
VLAN Type	Type of VLAN, which can be Default (VLAN $ID = 1$) or static (one that is configured and permanently defined), or Dynamic (one that is created by GVRP registration).

Interface	Valid slot and port number separated by forward slashes. It is possible to set the parameters for all ports by using the selec- tors on the top line.
Current	Determines the degree of participation of this port in this VLAN. The permissible values are:
	Include - This port is always a member of this VLAN. This is equivalent to registration fixed in the IEEE 802.1Q standard. Exclude - This port is never a member of this VLAN. This is equivalent to registration forbidden in the IEEE 802.1Q stan- dard.
	Autodetect - Specifies to allow the port to be dynamically registered in this VLAN via GVRP. The port will not partici- pate in this VLAN unless a join request is received on this port. This is equivalent to registration normal in the IEEE 802.1Q standard.
Configured	Determines the configured degree of participation of this port in this VLAN. The permissible values are:
	Include - This port is always a member of this VLAN. This is equivalent to registration fixed in the IEEE 802.1Q standard. Exclude - This port is never a member of this VLAN. This is equivalent to registration forbidden in the IEEE 802.1Q stan- dard.
	Autodetect - Specifies to allow the port to be dynamically registered in this VLAN via GVRP. The port will not partici- pate in this VLAN unless a join request is received on this port. This is equivalent to registration normal in the IEEE 802.1Q standard.
Tagging	Select the tagging behavior for this port in this VLAN.
	Tagged - specifies to transmit traffic for this VLAN as tagged frames.
	Untagged - specifies to transmit traffic for this VLAN as untagged frames.

6.2.3 show vlan port

This command displays VLAN port information.

Format	<pre>show vlan port {<slot port=""> all}</slot></pre>
Modes	Privileged EXEC User EXEC
Interface	Valid slot and port number separated by forward slashes. It is possible to set the parameters for all ports by using the selec- tors on the top line.
Port VLAN ID	The VLAN ID that this port will assign to untagged frames or priority tagged frames received on this port. The value must be for an existing VLAN. The factory default is 1.
Acceptable Frame	
Types	Specifies the types of frames that may be received on this port. The options are 'VLAN only' and 'Admit All'. When set to 'VLAN only', untagged frames or priority tagged frames received on this port are discarded. When set to 'Admit All', untagged frames or priority tagged frames received on this port are accepted and assigned the value of the Port VLAN ID for this port. With either option, VLAN tagged frames are forwarded in accordance to the 802.1Q VLAN specification.
Ingress Filtering	May be enabled or disabled. When enabled, the frame is dis- carded if this port is not a member of the VLAN with which this frame is associated. In a tagged frame, the VLAN is iden- tified by the VLAN ID in the tag. In an untagged frame, the VLAN is the Port VLAN ID specified for the port that received this frame. When disabled, all frames are forwarded in accordance with the 802.1Q VLAN bridge specification. The factory default is disabled.
GVRP	May be enabled or disabled.
Default Priority	The 802.1p priority assigned to tagged packets arriving on the port.

6.3 Provisioning (IEEE 802.1p) Commands

This section describes the commands you use to configure provisioning, which allows you to prioritize ports.

6.3.1 vlan port priority all

This command configures the port priority assigned for untagged packets for all ports presently plugged into the device. The range for the priority is 0-7. Any subsequent per port configuration will override this configuration setting.

Format	vlan port priority all	<priority></priority>
Mode	Global Config	

6.3.2 vlan priority

This command configures the default 802.1p port priority assigned for untagged packets for a specific interface. The range for the priority is 0-7

Default	0
Format	<pre>vlan priority <priority></priority></pre>
Mode	Interface Config

Chapter 7 DHCP Commands

This section describes the DHCP commands available in the 7200 Series Managed Switch CLI. DHCP automatically allocates and manages client TCP/ IP configurations. DHCP uses UDP as its transport protocol and supports a number of features that facilitate in administration address allocations.

The DHCP Server Commands section includes the following topics:

- Section 7.1 "DHCP Server Commands (DHCP Config Pool Mode)" on page 7-2
- Section 7.2 "DHCP Server Commands (Global Config Mode)" on page 7-9
- Section 7.3 "DHCP Server Clear and Show Commands" on page 7-12
- Section 7.4 "DHCP and BOOTP Relay Commands" on page 7-15

The commands in this section are in one of three functional groups:

- Configuration Commands are used to configure features and options of the switch. For every configuration command there is a show command that will display the configuration setting.
- Show commands are used to display switch settings, statistics and other information.
- Clear commands clear some or all of the settings to factory defaults.

7.1 DHCP Server Commands (DHCP Config Pool Mode)

This section describes the commands you to configure the DHCP server settings for the switch.

7.1.1 ip dhcp pool

This command configures a DHCP address pool name on a DHCP server and enters DHCP pool configuration mode.

DefaultnoneFormatip dhcp pool <name>ModeGlobal Config

Note: The CLI mode changes to DHCP Pool Config mode when you successfully execute this command.

7.1.1.1 no ip dhcp pool

This command removes the DHCP address pool. The name should be previously configured pool name.

Format	<pre>no ip dhcp pool <name></name></pre>	
Mode	Global Config	

7.1.2 client-identifier

This command specifies the unique identifier for a DHCP client. Unique-identifier is a valid notation in hexadecimal format. In some systems, such as Microsoft DHCP clients, the client identifier is required instead of hardware addresses. The unique-identifier is a concatenation of the media type and the MAC address. For example, the Microsoft client identifier for Ethernet address c819.2488.f177 is 01c8.1924.88f1.77 where 01 represents the Ethernet media type. For more information, refer to the "Address Resolution Protocol Parameters" section of RFC 1700, Assigned Numbers for a list of media type codes.

Default	none	
Format	client-identifier	<uniqueidentifier></uniqueidentifier>
Mode	DHCP Pool Config	

7.1.2.1 no client-identifier

This command deletes the client identifier.

Format	no client-identifier
Mode	DHCP Pool Config

7.1.3 client-name

This command specifies the name for a DHCP client. Name is a string consisting of standard ASCII characters.

Default	none
Format	<pre>client-name <name></name></pre>
Mode	DHCP Pool Config

7.1.3.1 no client-name

This command removes the client name.

Format	no client-name
Mode	DHCP Pool Config

7.1.4 default-router

This command specifies the default router list for a DHCP client. {*address1, address2... address8*} are valid IP addresses, each made up of four decimal bytes ranging from 0 to 255. IP address 0.0.0.0 is invalid.

Default	none
Format	default-router <address1> [<address2><address8>]</address8></address2></address1>
Mode	DHCP Pool Config

7.1.4.1 no default-router

This command removes the default router list.

Format	no default-router
Mode	DHCP Pool Config

7.1.5 dns-server

This command specifies the IP servers available to a DHCP client. Address parameters are valid IP addresses; each made up of four decimal bytes ranging from 0 to 255. IP address 0.0.0.0 is invalid.

Default	none
Format	dns-server <address1> [<address2><address8>]</address8></address2></address1>
Mode	DHCP Pool Config

7.1.5.1 no dns-server

This command removes the DNS Server list.

Format	no dns-server
Mode	DHCP Pool Config

7.1.6 hardware-address

This command specifies the hardware address of a DHCP client. Hardware-address is the MAC address of the hardware platform of the client consisting of 6 bytes in dotted hexadecimal format. Type indicates the protocol of the hardware platform. It is 1 for 10 MB Ethernet and 6 for IEEE 802.

Default	ethernet		
Format	hardware-address	<hardwareaddress></hardwareaddress>	[type]
Mode	DHCP Pool Config		

7.1.6.1 no hardware-address

This command removes the hardware address of the DHCP client.

Format	no hardware-address
Mode	DHCP Pool Config

none

7.1.7 host

This command specifies the IP address and network mask for a manual binding to a DHCP client. Address and Mask are valid IP addresses; each made up of four decimal bytes ranging from 0 to 255. IP address 0.0.0.0 is invalid. The prefix-length is an integer from 0 to 32

Format	<pre>host <address> [mask prefix-length]</address></pre>
Mode	DHCP Pool Config

7.1.7.1 no host

This command removes the IP address of the DHCP client.

Format	no host
Mode	DHCP Pool Config

7.1.8 lease

This command configures the duration of the lease for an IP address that is assigned from a DHCP server to a DHCP client. The overall lease time should be between 1-86400 minutes. If *infinite* is specified, lease is set for 60 days. *Days* is an integer from 0 to 59. *Hours* is an integer from 0 to 1439. *Minutes* is an integer from 0 to 86399.

Default	1 (day)
Format	<pre>lease {[<days> [hours] [minutes]] [infinite]}</days></pre>
Mode	DHCP Pool Config

7.1.8.1 no lease

This command restores the default value of the lease time for DHCP Server.

Format	no lease
Mode	DHCP Pool Config

7.1.9 network

Use this command to configure the subnet number and mask for a DHCP address pool on the server. Network-number is a valid IP address, made up of four decimal bytes ranging from 0 to 255. IP address 0.0.0.0 is invalid. Mask is the IP subnet mask for the specified address pool. The prefix-length is an integer from 0 to 32.

Default	none
Format	<pre>network <networknumber> [mask prefixlength]</networknumber></pre>
Mode	DHCP Pool Config

7.1.9.1 no network

This command removes the subnet number and mask.

Format	no network
Mode	DHCP Pool Config

7.1.10 bootfile

The command specifies the name of the default boot image for a DHCP client. The *<filename>* specifies the boot image file.

Default	none
Format	<pre>bootfile <filename></filename></pre>
Mode	DHCP Pool Config

7.1.10.1 no bootfile

This command deletes the boot image name.

Format	no bootfile
Mode	DHCP Pool Config

7.1.11 domain-name

This command specifies the domain name for a DHCP client. The *<domain>* specifies the domain name string of the client.

Default	none
Format	<pre>domain-name <domain></domain></pre>
Mode	DHCP Pool Config

7.1.11.1 no domain-name

This command removes the domain name.

Format	no domain-name
Mode	DHCP Pool Config

7.1.12 netbios-name-server

This command configures NetBIOS Windows Internet Naming Service (WINS) name servers that are available to DHCP clients.

One IP address is required, although one can specify up to eight addresses in one command line. Servers are listed in order of preference (address1 is the most preferred server, address2 is the next most preferred server, and so on).

Default	none
Format	netbios-name-server <address> [<address2><address8>]</address8></address2></address>
Mode	DHCP Pool Config

7.1.12.1 no netbios-name-server

This command removes the NetBIOS name server list.

Format	no netbios-name-server
Mode	DHCP Pool Config

7.1.13 netbios-node-type

The command configures the NetBIOS node type for Microsoft Dynamic Host Configuration Protocol (DHCP) clients.type Specifies the NetBIOS node type. Valid types are:

- b-node—Broadcast
- p-node—Peer-to-peer
- m-node—Mixed
- h-node—Hybrid (recommended)

Default	none	
Format	netbios-node-type	<type></type>
Mode	DHCP Pool Config	

7.1.13.1 no netbios-node-type

This command removes the NetBIOS node Type.

Format	no netbios-node-type
Mode	DHCP Pool Config

7.1.14 next-server

This command configures the next server in the boot process of a DHCP client.

Address is the IP address of the next server in the boot process, which is typically a TFTP server.

Default	inbound interface helper addresses
Format	<pre>next-server <address></address></pre>
Mode	DHCP Pool Config

7.1.14.1 no next-server

This command removes the boot server list.

Format	no next-server
Mode	DHCP Pool Config

7.1.15 option

The command configures DHCP Server options. The *<code>* parameter specifies the DHCP option code. Ascii string specifies an NVT ASCII character string. ASCII character strings that contain white space must be delimited by quotation marks. Hex string specifies hexadecimal data. in hexadecimal character strings is two hexadecimal digits—each byte can be separated by a period, colon, or white space.

Example:a3:4f:22:0c / a3 4f 22 0c / a34f.220c.9fed

Default	none
Format	<pre>option <code> {ascii string hex <string1> [<string2><string8>] ip <address1> [<address2><address8>]}</address8></address2></address1></string8></string2></string1></code></pre>
Mode	DHCP Pool Config

7.1.15.1 no option

This command removes the options.

Format	no option <code></code>
Mode	DHCP Pool Config

7.2 DHCP Server Commands (Global Config Mode)

This section describes the commands you to configure the DHCP server settings for the switch. You must be in Global Config mode to execute these commands.

7.2.1 ip dhcp excluded-address

This command specifies the IP addresses that a DHCP server should not assign to DHCP clients. Low-address and high-address are valid IP addresses; each made up of four decimal bytes ranging from 0 to 255. IP address 0.0.0.0 is invalid.

Default	none
Format	<pre>ip dhcp excluded-address <lowaddress> [highad- dress]</lowaddress></pre>
Mode	Global Config

7.2.1.1 no ip dhcp excluded-address

This command removes the excluded IP addresses for a DHCP client. Low-address and high-address are valid IP addresses; each made up of four decimal bytes ranging from 0 to 255. IP address 0.0.0.0 is invalid.

Format	<pre>no ip dhcp excluded-address dress]</pre>	<lowaddress></lowaddress>	[highad-
Mode	Global Config		

7.2.2 ip dhcp ping packets

This command is used to specify the number, in a range from 2-10, of packets a DHCP server sends to a pool address as part of a ping operation. By default the number of packets sent to a pool address is 2 (the smallest allowed number when sending packets). Setting the number of packets to 0 disables this command.

Note: The no form of this command sets the number of packets sent to a pool address to 0 and therefore prevents the server from pinging pool addresses.

Default	2
Format	ip dhcp ping packets <0,2-10>
Mode	Global Config

7.2.2.1 no ip dhcp ping packets

This command prevents the server from pinging pool addresses and sets the number of packets to 0.

Default	0
Format	no ip dhcp ping packets
Mode	Global Config

7.2.3 service dhcp

This command enables the DHCP server.

Default	disabled
Format	service dhcp
Mode	Global Config

7.2.3.1 no service dhcp

This command disables the DHCP server.

Format	no service dhcp
Mode	Global Config

7.2.4 ip dhcp bootp automatic

This command enables the allocation of the addresses to the bootp client. The addresses are from the automatic address pool.

Default	disabled
Format	ip dhcp bootp automatic
Mode	Global Config

7.2.4.1 no ip dhcp bootp automatic

This command disables the allocation of the addresses to the bootp client. The address are from the automatic address pool.

Formatno ip dhcp bootp automaticModeGlobal Config

7.2.5 ip dhcp conflict logging

This command enables conflict logging on DHCP server.

Default	enabled
Format	ip dhcp conflict logging
Mode	Global Config

7.2.5.1 no ip dhcp conflict logging

This command disables conflict logging on DHCP server.

Format	no ip dhcp conflict logging
Mode	Global Config

7.3 DHCP Server Clear and Show Commands

This section describes the commands you to delete various DHCP information and the commands you use to view DHCP configuration information and statistics.

7.3.1 clear ip dhcp binding

This command deletes an automatic address binding from the DHCP server database. If "*" is specified, the bindings corresponding to all the addresses are deleted. *<address>* is a valid IP address made up of four decimal bytes ranging from 0 to 255. IP address 0.0.0.0 is invalid.

Default	none
Format	<pre>clear ip dhcp binding {address *}</pre>
Mode	Privileged EXEC

7.3.2 clear ip dhcp server statistics

This command clears DHCP server statistics counters.

Format	clear ip dhcp server statistics
Mode	Privileged EXEC

7.3.3 clear ip dhcp conflict

The command is used to clear an address conflict from the DHCP Server database. The server detects conflicts using a ping. DHCP server clears all conflicts If the asterisk (*) character is used as the address parameter.

Default	none
Format	<pre>clear ip dhcp conflict {<address> / *}</address></pre>
Mode	Privileged EXEC

7.3.4 show ip dhcp binding

This command displays address bindings for the specific IP address on the DHCP server. If no IP address is specified, the bindings corresponding to all the addresses are displayed.

Format	<pre>show ip dhcp binding [address]</pre>
Modes	Privileged EXEC User EXEC

IP address	The IP address of the client.
Hardware	
Address	The MAC Address or the client identifier.
Lease expiration	The lease expiration time of the IP Address assigned to the client.
Туре	The manner in which IP Address was assigned to the client.

7.3.5 show ip dhcp global configuration

This command displays address bindings for the specific IP address on the DHCP server. If no IP address is specified, the bindings corresponding to all the addresses are displayed.

Format	show ip dhcp global configuration
Modes	Privileged EXEC User EXEC
Service DHCP	The field to display the status of dhcp protocol.
Number of Ping	
Packets	The maximum number of Ping Packets that will be sent to verify that an ip address id not already assigned.
Conflict Logging	Shows whether conflict logging is enabled or disabled.
BootP Automatic	Shows whether BootP for dynamic pools is enabled or dis- abled.

7.3.6 show ip dhcp pool configuration

This command displays pool configuration. If **all** is specified, configuration for all the pools is displayed.

Format	<pre>show ip dhcp pool configuration {<name> all}</name></pre>
Modes	Privileged EXEC User EXEC
Pool Name	The name of the configured pool.
Pool Type	The pool type.
Lease Time	The lease expiration time of the IP Address assigned to the client.
DNS Servers	The list of DNS servers available to the DHCP client
Default Routers	The list of the default routers available to the DHCP client

The following additional field is displayed for Dynamic pool type:

Network The network number and the mask for the DHCP address pool.

The following additional fields are displayed for Manual pool type:

Client Name	The name of a DHCP client.
Client Identifier	The unique identifier of a DHCP client.
Hardware Address	The hardware address of a DHCP client.
Hardware Address Type	The protocol of the hardware platform.
Host	The IP address and the mask for a manual binding to a DHCP client.

7.3.7 show ip dhcp server statistics

This command displays DHCP server statistics.

Format	show ip dhcp server statistics
Modes	Privileged EXEC User EXEC
Automatic Bindings	The number of IP addresses that have been automatically mapped to the MAC addresses of hosts that are found in the DHCP database.
Expired Bindings Malformed	The number of expired leases.
Bindings	The number of truncated or corrupted messages that were received by the DHCP server.
Message Received:	
DHCP	
DISCOVER	The number of DHCPDISCOVER messages the server has received.
DHCP REQUEST	The number of DHCPREQUEST messages the server has received.
DHCP DECLINE	The number of DHCPDECLINE messages the server has received.

DHCP RELEASE	The number of DHCPRELEASE messages the server has received.
DHCP INFORM	The number of DHCPINFORM messages the server has received.
Message Sent:	
DHCP OFFER	The number of DHCPOFFER messages the server sent.
DHCP ACK	The number of DHCPACK messages the server sent.
DHCP NACK	The number of DHCPNACK messages the server sent.

7.3.8 show ip dhcp conflict

This command displays address conflicts logged by the DHCP Server. If no IP address is specified, all the conflicting addresses are displayed.

P server.
re found
P se ere

7.4 DHCP and BOOTP Relay Commands

This section describes the commands you use to configure BootP/DHCP Relay on the switch. A DHCP relay agent operates at Layer 3 and forwards DHCP requests and replies between clients and servers when they are not on the same physical subnet.

7.4.1 ip dhcp relay information option

This command enables option 82 (RFC 3046) for BootP/DHCP Relay on the system. Once enabled, the DHCP request forwarded to the DHCP server will contain two optional fields: Circuit ID and Remote ID. The circuit ID option contains the port information where the DHCP client request originated. The remote ID option contains the MAC address of the relay agent (the switch management CPU's own MAC address).

Default	disabled
Format	ip dhcp relay information option
Mode	Global Config

7.4.1.1 no ip dhcp relay information option

This command disables the relay information option mode for BootP/DHCP Relay on the system.

Format	no ip dho	p relay	information	option
Mode	Global Co	nfig		

7.4.2 bootpdhcprelay

This command enables the forwarding of relay requests for BootP/DHCP Relay on the system.

Default	disabled
Format	bootpdhcprelay
Mode	Global Config

7.4.2.1 no bootpdhcprelay enable

This command disables the forwarding of relay requests for BootP/DHCP Relay on the system.

Format	no bootpdhcprelay enable
Mode	Global Config

7.4.3 bootpdhcprelay maxhopcount

This command configures the maximum allowable relay agent hops for BootP/DHCP Relay on the system. The <hops> parameter has a range of 1 to 16.

Default	4
Format	bootpdhcprelay maxhopcount <1-16>
Mode	Global Config

7.4.3.1 no bootpdhcprelay maxhopcount

This command configures the default maximum allowable relay agent hops for BootP/DHCP Relay on the system.

Format	no bootpdhcprelay maxhopcount
Mode	Global Config

7.4.4 bootpdhcprelay minwaittime

This command configures the minimum wait time in seconds for BootP/DHCP Relay on the system. When the BOOTP relay agent receives a BOOTREQUEST message, it MAY use the seconds-since-client-began-booting field of the request as a factor in deciding whether to relay the request or not. The parameter has a range of 0 to 100 seconds.

Default	0	
Format	bootpdhcprelay minwaittime	<0-100>
Mode	Global Config	

7.4.4.1 no bootpdhcprelay minwaittime

This command configures the default minimum wait time in seconds for BootP/DHCP Relay on the system.

Format	no bootpdhcprelay minwaittime
Mode	Global Config

7.4.5 bootpdhcprelay serverip

This command configures the server IP Address for BootP/DHCP Relay on the system. The *<ipaddr>* parameter is an IP address in a 4-digit dotted decimal format.

Default	0.0.0.0
Format	<pre>bootpdhcprelay serverip <ipaddr></ipaddr></pre>
Mode	Global Config

7.4.5.1 no bootpdhcprelay serverip

This command configures the default server IP Address for BootP/DHCP Relay on the system.

Format	no bootpdhcprelay serverip
Mode	Global Config

7.4.6 show bootpdhcprelay

This command displays the BootP/DHCP Relay information.

Format	show bootpdhcprelay
Modes	Privileged EXEC
	User EXEC
Maximum Hop Count	Is the maximum allowable relay agent hops.
Minimum Wait Time (Seconds)	Is the minimum wait time.
Admin Mode	Represents whether relaying of requests is enabled or dis- abled.
Server IP Address	Is the IP Address for the BootP/DHCP Relay server.
Circuit Id Option Mode	Is the DHCP circuit Id option which may be enabled or dis abled.
Requests Received	Is the number or requests received.
Requests Relayed	Is the number of requests relayed.
Packets Discarded	Is the number of packets discarded.
Default	

Chapter 8 GARP, GVRP, and GMRP Commands

This section describes the Generic Attribute Registration Protocol (GARP), GARP VLAN Registration Protocol (GVRP), and Garp Multicast Registration Protocol (GVMP) commands available in the 7200 Series Managed Switch CLI. GARP is a protocol that allows client stations to register with the switch for membership in VLANS (by using GVMP) or multicast groups (by using GMRP).

This section contains the following topics:

- Section 8.1 "GARP Commands" on page 8-2
- Section 8.2 "GVRP Commands" on page 8-5
- Section 8.3 "GMRP Commands" on page 8-7

The commands in this section are in one of two functional groups:

- Show commands display switch settings, statistics, and other information.
- Configuration commands configure features and options of the switch. For every configuration command, there is a show command that displays the configuration setting.

8.1 GARP Commands

This section describes the commands you use to configure GARP and view GARP status. The commands in this section affect both GVMP and GMRP.

8.1.1 set garp timer join

This command sets the GVRP join time for one or all ports and per GARP. Join time is the interval between the transmission of GARP Protocol Data Units (PDUs) registering (or reregistering) membership for a VLAN or multicast group.

This command has an effect only when GVRP is enabled. The time is from 10 to 100 (centiseconds). The value 20 centiseconds is 0.2 seconds.

Default	20	
Format	set garp timer join <10-100>	
Modes	Interface Config	
	Global Colling	

8.1.1.1 no set garp timer join

This command sets the GVRP join time (for one or all ports and per GARP) to the default.



Format	no set garp timer join
Modes	Interface Config Global Config

8.1.2 set garp timer leave

This command sets the GVRP leave time. Leave time is the time to wait after receiving an unregister request for a VLAN or a multicast group before deleting the VLAN entry. This can be considered a buffer time for another station to assert registration for the same attribute in order to maintain uninterrupted service.time is 20 to 600 (centiseconds). The value 60 centiseconds is 0.6 seconds.



8.1.2.1 no set garp timer leave

This command sets the GVRP leave time to the default.

Note: This command has an effect only when GVRP is enabled.

Format	no set garp timer leave
Modes	Interface Config
	Global Config

8.1.3 set garp timer leaveall

This command sets how frequently *Leave All PDUs* are generated. A *Leave All PDU* indicates that all registrations will be unregistered. Participants would need to rejoin in order to maintain registration. The value applies per port and per GARP participation. The time may range from 200 to 6000 (centiseconds). The value 1000 centiseconds is 10 seconds.



Default	1000
Format	set garp timer leaveall <200-6000>
Modes	Interface Config
	Global Config

8.1.3.1 no set garp timer leaveall

This command sets how frequently Leave All PDUs are generated the default.

Note: This command has an effect only when GVRP is enabled.

Formatno set garp timer leaveal1ModesInterface Config
Global Config

8.1.4 show garp

This command displays GARP information.

show garp
Privileged EXEC
User EXEC
This displays the administrative mode of GMRP for the system.

GVRP Admin Mode This displays the administrative mode of GVRP for the system

8.2 GVRP Commands

This section describes the commands you use to configure and view GARP VLAN Registration Protocol (GVRP) information. GVRP-enabled switches exchange VLAN configuration information, which allows GVRP to provide dynamic VLAN creation on trunk ports and automatic VLAN pruning.



Note: If GVRP is disabled, the system does not forward GVRP messages.

8.2.1 set gvrp adminmode

This command enables GVRP.

Default	disabled
Format	set gvrp adminmode
Mode	Privileged EXEC

8.2.1.1 no set gvrp adminmode

This command disables GVRP.

Formatno set gvrp adminmodeModePrivileged EXEC

8.2.2 set gvrp interfacemode

This command enables GVRP.

Default	disabled
Format	set gvrp interfacemode
Modes	Interface Config
	Global Config

8.2.2.1 no set gvrp interfacemode

This command disables GVRP. If GVRP is disabled, Join Time, Leave Time and Leave All Time have no effect.

Format	no set gvrp interfacemode
Modes	Interface Config
	Global Config

8.2.3 show gvrp configuration

This command displays Generic Attributes Registration Protocol (GARP) information for one or all interfaces.

Format	<pre>show gvrp configuration {<slot port=""> all}</slot></pre>
Modes	Privileged EXEC User EXEC
Interface	Valid slot and port number separated by forward slashes.
Join Timer	Specifies the interval between the transmission of GARP PDUs registering (or re-registering) membership for an attribute. Current attributes are a VLAN or multicast group. There is an instance of this timer on a per-Port, per-GARP participant basis. Permissible values are 10 to 100 centisec- onds (0.1 to 1.0 seconds). The factory default is 20 centisec- onds (0.2 seconds). The finest granularity of specification is one centisecond (0.01 seconds).
Leave Timer	Specifies the period of time to wait after receiving an unreg- ister request for an attribute before deleting the attribute. Cur- rent attributes are a VLAN or multicast group. This may be considered a buffer time for another station to assert registra- tion for the same attribute in order to maintain uninterrupted service. There is an instance of this timer on a per-Port, per- GARP participant basis. Permissible values are 20 to 600 centiseconds (0.2 to 6.0 seconds). The factory default is 60 centiseconds (0.6 seconds).
LeaveAll Timer	This Leave All Time controls how frequently LeaveAll PDUs are generated. A LeaveAll PDU indicates that all registra- tions will shortly be deregistered. Participants will need to rejoin in order to maintain registration. There is an instance of this timer on a per-Port, per-GARP participant basis. The
	Leave All Period Timer is set to a random value in the range of LeaveAllTime to 1.5*LeaveAllTime. Permissible values are 200 to 6000 centiseconds (2 to 60 seconds). The factory default is 1000 centiseconds (10 seconds).
----------------	--
Port GMRP Mode	Indicates the GARP Multicast Registration Protocol (GMRP) administrative mode for the port, which is enabled or dis- abled (default). If this parameter is disabled, Join Time, Leave Time and Leave All Time have no effect.

8.3 GMRP Commands

This section describes the commands you use to configure and view GARP Multicast Registration Protocol (GMRP) information. Like IGMP snooping, GMRP helps control the flooding of multicast packets. GMRP-enabled switches dynamically register and deregister group membership information with the MAC networking devices attached to the same segment. GMRP also allows group membership information to propagate across all networking devices in the bridged LAN that support Extended Filtering Services.



Note: If GMRP is disabled, the system does not forward GMRP messages.

8.3.1 set gmrp adminmode

This command enables GARP Multicast Registration Protocol (GMRP) on the system. The default value is disable.

Format	set gmrp adminmode
Mode	Privileged EXEC

8.3.1.1 no set gmrp adminmode

This command disables GARP Multicast Registration Protocol (GMRP) on the system.

Formatno set gmrp adminmodeModePrivileged EXEC

8.3.2 set gmrp interfacemode

This command enables GARP Multicast Registration Protocol. If an interface which has GARP enabled is enabled for routing or is enlisted as a member of a port-channel (LAG), GARP functionality is disabled on that interface. GARP functionality is subsequently reenabled if routing is disabled and port-channel (LAG) membership is removed from an interface that has GARP enabled.

Default	disabled
Format	set gmrp interfacemode
Modes	Interface Config
	Global Config

8.3.2.1 no set gmrp interfacemode

This command disables GARP Multicast Registration Protocol. If an interface which has GARP enabled is enabled for routing or is enlisted as a member of a port-channel (LAG), GARP functionality is disabled. GARP functionality is subsequently re-enabled if routing is disabled and port-channel (LAG) membership is removed from an interface that has GARP enabled.

Format	no set gmrp interfacemode
Modes	Interface Config
	Global Config

8.3.3 show gmrp configuration

This command displays GARP information for one or all interfaces.

Format	<pre>show gmrp configuration {<slot port=""> all}</slot></pre>
Modes	Privileged EXEC User EXEC
Interface	This displays the slot/port of the interface that this row in the table describes.
Join Timer	Specifies the interval between the transmission of GARP PDUs registering (or re-registering) membership for an attribute. Current attributes are a VLAN or multicast group. There is an instance of this timer on a per-port, per-GARP participant basis. Permissible values are 10 to 100 centisec- onds (0.1 to 1.0 seconds). The factory default is 20 centisec-

onds (0.2 seconds). The finest granularity of specification is 1 centisecond (0.01 seconds).

Leave Timer	Specifies the period of time to wait after receiving an unreg- ister request for an attribute before deleting the attribute. Cur- rent attributes are a VLAN or multicast group. This may be considered a buffer time for another station to assert registra- tion for the same attribute in order to maintain uninterrupted service. There is an instance of this timer on a per-Port, per- GARP participant basis. Permissible values are 20 to 600 centiseconds (0.2 to 6.0 seconds). The factory default is 60 centiseconds (0.6 seconds).
LeaveAll Timer	This Leave All Time controls how frequently LeaveAll PDUs are generated. A LeaveAll PDU indicates that all registra- tions will shortly be deregistered. Participants will need to rejoin in order to maintain registration. There is an instance of this timer on a per-Port, per-GARP participant basis. The Leave All Period Timer is set to a random value in the range of LeaveAllTime to 1.5*LeaveAllTime. Permissible values are 200 to 6000 centiseconds (2 to 60 seconds). The factory default is 1000 centiseconds (10 seconds).

Port GMRP Mode Indicates the GMRP administrative mode for the port. It may be enabled or disabled. If this parameter is disabled, Join Time, Leave Time and Leave All Time have no effect.

8.3.4 show mac-address-table gmrp

This command displays the GMRP entries in the Multicast Forwarding Database (MFDB) table.

Format show mac-add	iress-table gmrp
Mode	Privileged EXEC
Mac Address	A unicast MAC address for which the switch has forwarding and or filtering information. The format is 6 or 8 two-digit hexadecimal numbers that are separated by colons, for exam- ple 01:23:45:67:89:AB. In an IVL system the MAC address is displayed as 8 bytes.
Туре	Displays the type of the entry. Static entries are those that are configured by the end user. Dynamic entries are added to the table as a result of a learning process or protocol.
Description	The text description of this multicast table entry.
Interfaces	The list of interfaces that are designated for forwarding (Fwd:) and filtering (Flt:).

Chapter 9 Port-Based Traffic Control Commands

This section describes the port-based traffic control commands available in the 7200 Series Managed Switch CLI.

This section includes the following topics:

- Section 9.1 "Port Security Commands" on page 9-1
- Section 9.2 "Storm Control Commands" on page 9-5

This section provides a detailed explanation of the security commands. The commands are divided into the following groups:

- Configuration commands are used to configure features and options of the switch. For every configuration command there is a show command that will display the configuration setting.
- Show commands are used to display switch settings, statistics and other information.

9.1 Port Security Commands

This section describes the command you use to configure Port Security on the switch. Port security, which is also known as port MAC locking, allows you to secure the network by locking allowable MAC addresses on a given port. Packets with a matching source MAC address are forwarded normally, and all other packets are discarded.

Note: To enable the SNMP trap specific to port security, see Section 10.1.8 "snmp-server traps violation" on page 10-4.

 \rightarrow

9.1.1 port-security

This command enables port locking at the system level (Global Config) or port level (Interface Config)

Default	disabled
Format	port-security
Modes	Global Config
	Interface Config

9.1.1.1 no port-security

This command disables port locking at the system level (Global Config) or port level (Interface Config).

Format	no port-security
Modes	Global Config
	Interface Config

9.1.2 port-security max-dynamic

This command sets the maximum of dynamically locked MAC addresses allowed on a specific port.

Default	600
Format	<pre>port-security max-dynamic <maxvalue></maxvalue></pre>
Mode	Interface Config

9.1.2.1 no port-security max-dynamic

This command resets the maximum of dynamically locked MAC addresses allowed on a specific port to its default value.

Format	no port-security max-dynamic
Mode	Interface Config

9.1.3 port-security max-static

This command sets the maximum number of statically locked MAC addresses allowed on a specific port.

Default	20
Format	<pre>port-security max-static <maxvalue></maxvalue></pre>
Mode	Interface Config

9.1.3.1 no port-security max-static

This command resets the maximum of statically locked MAC addresses allowed on a specific port to its default value.

Format	no port-security	max-static
Mode	Interface Config	

9.1.4 port-security mac-address

This command adds a MAC address to the list of statically locked MAC addresses. The <vid> is the VLAN ID.

Format	port-security mac-address	<mac-address></mac-address>	<vid></vid>
Mode	Interface Config		

9.1.4.1 no port-security mac-address

This command removes a MAC address from the list of statically locked MAC addresses.

Format	<pre>no port-security mac-address <mac-address></mac-address></pre>	<vid></vid>
Mode	Interface Config	

9.1.5 port-security mac-address move

This command converts dynamically locked MAC addresses to statically locked addresses.

Format	port-security mac-address move
Mode	Interface Config

9.1.6 show port-security

This command displays the port-security settings for the entire system.

Format	show port-security
Mode	Privileged EXEC
Admin Mode	Port Locking mode for the entire system

9.1.7 show port-security

This command displays the port-security settings for a particular interface or all interfaces.

Format	<pre>show port-security <interface all="" =""></interface></pre>
Mode	Privileged EXEC
Interface Admin Mode	Port Locking mode for the Interface.
Dynamic Limit	Maximum dynamically allocated MAC Addresses.
Static Limit	Maximum statically allocated MAC Addresses.
Violation Trap Mode	Whether violation traps are enabled.

9.1.8 show port-security dynamic

This command displays the dynamically locked MAC addresses for port.

Format	<pre>show port-security dynamic <interface></interface></pre>
Mode	Privileged EXEC
MAC Address	MAC Address of dynamically locked MAC.

9.1.9 show port-security static

This command displays the statically locked MAC addresses for port.

Format	<pre>show port-security static <interface></interface></pre>
Mode	Privileged EXEC
MAC Address	MAC Address of statically locked MAC.

9.1.10 show port-security violation

This command displays the source MAC address of the last packet that was discarded on a locked port.

Format	<pre>show port-security violation <interface></interface></pre>
Mode	Privileged EXEC
MAC Address	MAC Address of discarded packet on locked port.

9.2 Storm Control Commands

This section describes commands you use to configure storm control and view stormcontrol configuration information. The storm-control feature measures traffic activity on the physical ports and blocks traffic on the port when the amount of traffic reaches the threshold. Blocking the port helps maintain network performance.

9.2.1 storm-control broadcast

This command enables broadcast storm recovery mode. If the mode is enabled, broadcast storm recovery with high and low thresholds is implemented.

The threshold implementation follows a percentage pattern. If the broadcast traffic on any Ethernet port exceeds the high threshold percentage (as represented in Table 9-1) of the link speed, the switch discards the broadcasts traffic until the broadcast traffic returns to the low threshold percentage or less. The full implementation is depicted in Table 9-1.

Link Speed	High	Low
10M	20	10
100M	5	2
1000M	5	2
Default enabled		
Format s	nat storm-control broadcast	
Mode (Config	

 Table 9-1. Broadcast Storm Recovery Thresholds

9.2.1.1 no storm-control broadcast

This command disables broadcast storm recovery mode.

The threshold implementation follows a percentage pattern. If the broadcast traffic on any Ethernet port exceeds the high threshold percentage (as represented in Table 9-1) of the link speed, the switch discards the broadcasts traffic until the broadcast traffic returns to the low threshold percentage or less. The full implementation is depicted in the Table 9-1.

Format	no storm-control broadcast
Mode	Global Config

9.2.2 storm-control multicast all

This command enables multicast storm recovery mode. If the mode is enabled, multicast storm recovery with hight and low thresholds is implemented. The thresholds are defined in the same way as for broadcast.

Default	disable
Format	storm-control multicast all
Mode	Config

9.2.2.1 no storm-control multicast all

This command disables multicast storm recovery mode.

Format	no storm-control	multicast	all
Mode	Global Config		

9.2.3 storm-control unicast all

This command enables unknown unicast packet storm recovery mode. If the mode is enabled, the unknown storm recovery with high and low thresholds is implemented. The thresholds are defined same as the one for broadcast.

Default	disable
Format	storm-control unicast all
Mode	Config

9.2.3.1 no storm-control unicast all

This command disables multicast storm recovery mode.

Format	no storm-control unicast all
Mode	Global Config

9.2.4 storm-control broadcast

This command enables broadcast storm recovery mode in per-port level. If the mode is enabled, broadcast storm recovery with high and low thresholds is implemented. The $\langle level \rangle$ value is in a range of 0 to 100 (in percentage). A value of 0 means no storm control. If the $\langle level \rangle$ value is not specified, the thresholds are defined the same as the ones for broadcast storm control in Global mode.

Default	enable
Format	<pre>storm-contol broadcast [<level>]</level></pre>
Mode	Interface Config

9.2.4.1 no storm-control broadcast

This command disables broadcast storm recovery mode.

Format	no storm-control	broadcast	[<level>]</level>
Mode	Interface Config		

9.2.5 storm-control multicast

This command enables multicast packet storm recovery mode on the port level. If the mode is enabled, multicast storm recovery with high and low thresholds is implemented. The $\langle level \rangle$ value is in a range of 0 to 100 (in percentage). Value of 0 means no storm control. If $\langle level \rangle$ value is not specified, the thresholds are defined same as the ones for broadcast storm control in Global mode.

Default	enable
Format	<pre>storm-control multicast [<level>]</level></pre>
Mode	Interface Config

9.2.5.1 no storm-control multicast

This command disables multicast storm recovery mode.

Format	no storm-control	multicast	[<level>]</level>
Mode	Interface Config		

9.2.6 storm-control unicast

This command enables unknown unicast packet storm recovery mode in per-port level. If the mode is enabled, storm recovery with high and low thresholds is implemented. The <level> value is in a range of 0 to 100 (in percentage). A value of 0 means no storm control. If the <level> value is not specified, the thresholds are defined the same as the ones for broadcast storm control in Global mode.

Default	enable
Format	storm-control unicast [<level>]</level>
Mode	Interface Config

9.2.6.1 no storm-control unicast

This command disables unicast storm recovery mode.

Format	no storm-control	unicast	[<level>]</level>
Mode	Interface Config		

9.2.7 storm-control flowcontrol

This command enables 802.3x flow control for the switch and only applies to full-duplex mode ports.

Note: 802.3x flow control works by pausing a port when the port becomes oversubscribed and dropping all traffic for small bursts of time during the congestion condition. This can lead to high-priority and/or network control traffic loss.

Default	disabled
Format	storm-control flowcontrol
Mode	Global Config

9.2.7.1 no storm-control flowcontrol

This command disables 802.3x flow control for the switch.

Note: This command only applies to full-duplex mode ports.

Format	no storm-control	flowcontrol
Mode	Global Config	

9.2.8 show storm-control

This command displays switch configuration information.

Format	show storm-control
Mode	Privileged EXEC
Broadcast Storm Recovery Mode	May be enabled or disabled. The factory default is disabled.
802.3x Flow Control Mode	May be enabled or disabled. The factory default is disabled.

Chapter 10 SNMP Commands

This section describes the SNMP commands available in the 7200 Series Managed Switch CLI. You can configure the switch to act as a Simple Network Management Protocol (SNMP) agent so that it can communicate with SNMP managers on your network.

The SNMP Commands section contains the following topics:

- Section 10.1 "SNMP Configuration Commands" on page 10-1
- Section 10.2 "SNMP Show Commands" on page 10-10

The commands in this section are in one of two functional groups:

- Show commands display switch settings, statistics, and other information.
- Configuration commands configure features and options of the switch. For every configuration command, there is a show command that displays the configuration setting.

10.1 SNMP Configuration Commands

This section describes the commands you use to configure SNMP on switch.

10.1.1 snmp-server

This command sets the name and the physical location of the switch, and the organization responsible for the network. The range for *<name>*, *<loc>* and *<con>* is from 1 to 31 alphanumeric characters.

Default	none
Format	<pre>snmp-server {sysname <name> location <loc> contact <con>}</con></loc></name></pre>
Mode	Global Config

10.1.2 snmp-server community

This command adds (and names) a new SNMP community. A community *<name>* is a name associated with the switch and with a set of SNMP managers that manage it with a specified privileged level. The length of *<name>* can be up to 16 case-sensitive characters.

Note: Community names in the SNMP Community Table must be unique. When making multiple entries using the same community name, the first entry is kept and processed and all duplicate entries are ignored.

Default	public and private, which you can rename; default values for the remaining four community names are blank
Format	<pre>snmp-server community <name></name></pre>
Mode	Global Config

10.1.2.1 no snmp-server community

This command removes this community name from the table. The *<name>* is the community name to be deleted.

Format	no snmp-server community	<name></name>
Mode	Global Config	

10.1.3 snmp-server community ipaddr

This command sets a client IP address for an SNMP community. The address is the associated community SNMP packet sending address and is used along with the client IP mask value to denote a range of IP addresses from which SNMP clients may use that community to access the device. A value of 0.0.0.0 allows access from any IP address. Otherwise, this value is ANDed with the mask to determine the range of allowed client IP addresses. The name is the applicable community name.

Default	0.0.00				
Format	snmp-server	community	ipaddr	<ipaddr></ipaddr>	<name></name>
Mode	Global Config	5			

10.1.3.1 no snmp-server community ipaddr

This command sets a client IP address for an SNMP community to 0.0.0.0. The name is the applicable community name.

Format	no	snmp-server	community	ipaddr	<name></name>
Mode	Gl	obal Config			

10.1.4 snmp-server community ipmask

This command sets a client IP mask for an SNMP community. The address is the associated community SNMP packet sending address and is used along with the client IP address value to denote a range of IP addresses from which SNMP clients may use that community to access the device. A value of 255.255.255.255 will allow access from only one station, and will use that machine's IP address for the client IP Address. A value of 0.0.0.0 will allow access from any IP address. The name is the applicable community name.

Default	0.0.0.0				
Format	snmp-server	community	ipmask	<ipmask></ipmask>	<name></name>
Mode	Global Config	5			

10.1.4.1 no snmp-server community ipmask

This command sets a client IP mask for an SNMP community to 0.0.0.0. The name is the applicable community name. The community name may be up to 16 alphanumeric characters.

Format	no snmp-server co	ommunity i	ipmask	<name></name>
Mode	Global Config			

10.1.5 snmp-server community mode

This command activates an SNMP community. If a community is enabled, an SNMP manager associated with this community manages the switch according to its access right. If the community is disabled, no SNMP requests using this community are accepted. In this case the SNMP manager associated with this community cannot manage the switch until the Status is changed back to Enable.

Default	private and public communities - enabled; other four - dis- abled
Format	<pre>snmp-server community mode <name></name></pre>
Mode	Global Config

10.1.5.1 no snmp-server community mode

This command deactivates an SNMP community. If the community is disabled, no SNMP requests using this community are accepted. In this case the SNMP manager associated with this community cannot manage the switch until the Status is changed back to Enable.

Formatno snmp-server community mode <name>ModeGlobal Config

10.1.6 snmp-server community ro

This command restricts access to switch information. The access mode is read-only (also called public).

Formatsnmp-server community ro <name>ModeGlobal Config

10.1.7 snmp-server community rw

This command restricts access to switch information. The access mode is read/write (also called private).

Format	snmp-server	community	rw	<name></name>
Mode	Global Config	r		

10.1.8 snmp-server traps violation

This command enables the sending of new violation traps designating when a packet with a disallowed MAC address is received on a locked port.



Note: For other port security commands, see Section 9.1 "Port Security Commands" on page 9-1.

DefaultdisabledFormatsnmp-server traps violationModeInterface Config

10.1.8.1 no snmp-server traps violation

This command disables the sending of new violation traps.

Format	no snmp-server traps violation
Mode	Interface Config

10.1.9 snmp-server traps

This command enables the Authentication Flag.

Default	enabled
Format	snmp-server traps
Mode	Global Config

10.1.9.1 no snmp-server traps

This command disables the Authentication Flag.

Format	no snmp-server traps
Mode	Global Config

10.1.10 snmp-server traps bcaststorm

This command enables the broadcast storm trap. When enabled, broadcast storm traps are sent only if the broadcast storm recovery mode setting associated with the port is enabled.

Default	enabled			
Format	snmp-server traps bcaststorm			
Mode	Global Config			

10.1.10.1 no snmp-server traps bcaststorm

This command disables the broadcast storm trap. When enabled, broadcast storm traps are sent only if the broadcast storm recovery mode setting associated with the port is enabled.

Format	no snmp-server traps bcaststorm
Mode	Global Config

10.1.11 snmp-server traps linkmode

This command enables Link Up/Down traps for the entire switch. When enabled, link traps are sent only if the Link Trap flag setting associated with the port is enabled. Section 10.1.18 "snmp trap link-status" on page 10-9

Default	enabled
Format	snmp-server traps linkmode
Mode	Global Config

10.1.11.1 no snmp-server traps linkmode

This command disables Link Up/Down traps for the entire switch.

Format	no snmp-server	traps	linkmode
Mode	Global Config		

10.1.12 snmp-server traps multiusers

This command enables Multiple User traps. When the traps are enabled, a Multiple User Trap is sent when a user logs in to the terminal interface (EIA 232 or telnet) and there is an existing terminal interface session.

Default	enabled
Format	snmp-server traps multiusers
Mode	Global Config

10.1.12.1 no snmp-server traps multiusers

This command disables Multiple User traps.

Format	no snmp-server traps multiusers
Mode	Global Config

10.1.13 snmp-server traps stpmode

This command enables the sending of new root traps and topology change notification traps.

Default	enabled
Format	snmp-server traps stpmode
Mode	Global Config

10.1.13.1 no snmp-server traps stpmode

This command disables the sending of new root traps and topology change notification traps.

Format	no snmp-server traps stpmode
Mode	Global Config

10.1.14 snmptrap

This command adds an SNMP trap receiver. The maximum length of *<name>* is 16 casesensitive alphanumeric characters. The *<snmpversion>* is the version of SNMP. The version parameter options are snmpv1 or snmpv2.

The *<name>* parameter does not need to be unique, however; the *<name>* and *<ipaddr>* pair must be unique. Multiple entries can exist with the same *<name>* as long as they are associated with a different *<ipaddr>*.

The reverse scenario is also acceptable. The *<name>* is the community name used when sending the trap to the receiver, but the *<name>* is not directly associated with the SNMP Community Table. For more information, see Section 10.1.2 "snmp-server community" on page 10-2.

Default	snmpv2
Format	<pre>snmptrap <name> <ipaddr> [snmpversion <snmpver- sion>]</snmpver- </ipaddr></name></pre>
Mode	Global Config

10.1.14.1 no snmptrap

This command deletes trap receivers for a community.

Format	<pre>no snmptrap <name> <ipaddr></ipaddr></name></pre>
Mode	Global Config

10.1.15 snmptrap snmpversion

This command modifies the SNMP version of a trap. The maximum length of *<name>* is 16 case-sensitive alphanumeric characters. The *<snmpversion>* can be snmpv1 or snmpv2.

	Note: This command does not support a "no" form.					
Def	fault	snmpv2				
Foi	rmat	<pre>snmptrap snmpversion <name> <ipaddr> <snmpversion></snmpversion></ipaddr></name></pre>				
Мо	de	Global Config				

10.1.16 snmptrap ipaddr

This command assigns an IP address to a specified community name. The maximum length of name is 16 case-sensitive alphanumeric characters.



Note: IP addresses in the SNMP trap receiver table must be unique. If you make multiple entries using the same IP address, the first entry is retained and processed. All duplicate entries are ignored.

Format	snmptrap	ipaddr	<name></name>	<ipaddrold></ipaddrold>	<ipaddrnew></ipaddrnew>
Mode	Global Co	nfig			

10.1.17 snmptrap mode

This command activates or deactivates an SNMP trap. Enabled trap receivers are active (able to receive traps). Disabled trap receivers are inactive (not able to receive traps).

Format	snmptrap	mode	<name></name>	<ipaddr></ipaddr>
Mode	Global Co	nfig		

10.1.17.1 no snmptrap mode

This command deactivates an SNMP trap. Disabled trap receivers are inactive.

Format	no snmptrap mode <	name> <ipaddr></ipaddr>
Mode	Global Config	

10.1.18 snmp trap link-status

This command enables link status traps by interface.

Note: This command is valid only when the Link Up/Down Flag is enabled. See 'snmp-server enable traps linkmode' command.

Format	snmp trap link-status
Mode	Interface Config

10.1.18.1 no snmp trap link-status

This command disables link status traps by interface.

Note: This command is valid only when the Link Up/Down Flag is enabled. See 'snmp-server enable traps linkmode' command).

Format	no snmp trap link-status
Mode	Interface Config

10.1.19 snmp trap link-status all

This command enables link status traps for all interfaces.

Note: This command is valid only when the Link Up/Down Flag is enabled. See Section 10.1.11 "snmp-server traps linkmode" on page 10-6

Format Mode

snmp trap link-status all Global Config

10.1.19.1 no snmp trap link-status all

This command disables link status traps for all interfaces.

Note: This command is valid only when the Link Up/Down Flag is enabled. See Section 10.1.11 "snmp-server traps linkmode" on page 10-6

Formatno snmp trap link-status allModeGlobal Config

10.2 SNMP Show Commands

This section describes the commands you use to view SNMP status and configuration information.

10.2.1 show snmpcommunity

This command displays SNMP community information. Six communities are supported. You can add, change, or delete communities. The switch does not have to be reset for changes to take effect.

The SNMP agent of the switch complies with SNMP Versions 1, 2 or 3. For more information about the SNMP specification, see the SNMP RFCs. The SNMP agent sends traps through TCP/IP to an external SNMP manager based on the SNMP configuration (the trap receiver and other SNMP community parameters).

Format	show snmpcommunity
Mode	Privileged EXEC
SNMP Community	
Name	The community string to which this entry grants access. A valid entry is a case-sensitive alphanumeric string of up to 16 characters. Each row of this table must contain a unique community name.
Client IP Address	An IP address (or portion thereof) from which this device will accept SNMP packets with the associated community. The requesting entity's IP address is ANDed with the Subnet Mask before being compared to the IP Address. Note: If the

	Subnet Mask is set to 0.0.0.0, an IP Address of 0.0.0.0 matches all IP addresses. The default value is 0.0.0.0
Client IP Mask	A mask to be ANDed with the requesting entity's IP address before comparison with IP Address. If the result matches with IP Address then the address is an authenticated IP address. For example, if the IP Address = 9.47.128.0 and the corresponding Subnet Mask = 255.255.255.0 a range of incoming IP addresses would match, i.e. the incoming IP Address could equal 9.47.128.0 - 9.47.128.255. The default value is 0.0.0.0
Access Mode	The access level for this community string.
Status	The status of this community access entry.

10.2.2 show snmptrap

This command displays SNMP trap receivers. Trap messages are sent across a network to an SNMP Network Manager. These messages alert the manager to events occurring within the switch or on the network. Six trap receivers are simultaneously supported.

Format	show snmptrap
Mode	Privileged EXEC
SNMP Trap Name	The community string of the SNMP trap packet sent to the trap manager. The string is case sensitive and can be up to 16 alphanumeric characters.
IP Address	The IP address to receive SNMP traps from this device.
Status	Indicates the receiver's status (enabled or disabled).

10.2.3 show trapflags

This command displays trap conditions. Configure which traps the switch should generate by enabling or disabling the trap condition. If a trap condition is enabled and the condition is detected, the SNMP agent on the switch sends the trap to all enabled trap receivers. You do not have to reset the switch to implement the changes. Cold and warm start traps are always generated and cannot be disabled.

Format	show trapflags
Mode	Privileged EXEC

Authentication	
Flag	Can be enabled or disabled. The factory default is enabled. Indicates whether authentication failure traps will be sent.
Link Un/Down	1
Flag	Can be enabled or disabled. The factory default is enabled.
	Indicates whether link status traps will be sent.
Multiple Users	-
Flag	Can be enabled or disabled. The factory default is enabled. Indicates whether a trap will be sent when the same user ID is logged into the switch more than once at the same time (either via telnet or serial port).
Spanning Tree	
Flag	Can be enabled or disabled. The factory default is enabled. Indicates whether spanning tree traps will be sent.
Broadcast Storm	
Flag	Can be enabled or disabled. The factory default is enabled. Indicates whether broadcast storm traps will be sent.
DVMRP Traps	Can be enabled or disabled. The factory default is disabled. Indicates whether DVMRP traps will be sent.
OSPF Traps	Can be enabled or disabled. The factory default is disabled. Indicates whether OSPF traps will be sent.
PIM Traps	Can be enabled or disabled. The factory default is disabled. Indicates whether PIM traps are sent.

Chapter 11 Port-Based Access and Authentication Commands

This section describes the port-based access and authentication commands available in the 7200 Series Managed Switch CLI.

The Port-Based Access and Authentication Commands section includes the following topics:

- Section 11.1 "Port-Based Network Access Control Commands" on page 11-1
- Section 11.2 "RADIUS Commands" on page 11-13

The commands in this section lie in one of two functional groups:

- Configuration commands are used to configure features and options of the switch. For every configuration command there is a show command that will display the configuration setting.
- Show commands are used to display switch settings, statistics and other information.

11.1 Port-Based Network Access Control Commands

This section describes the commands you use to configure port-based network access control (802.1x). Port-based network access control allows you to permit access to network services only to and devices that are authorized and authenticated.

11.1.1 authentication login

This command creates an authentication login list. The *listname* is any character string and is not case sensitive. Up to 10 authentication login lists can be configured on the switch. When a list is created, the authentication method "local" is set as the first method.

When the optional parameters "Option1", "Option2" and/or "Option3" are used, an ordered list of methods are set in the authentication login list. If the authentication login list does not exist, a new authentication login list is first created and then the authentication methods are set in the authentication login list. The maximum number of authentication login methods is three. The possible method values are local, radius and reject.

The value of local indicates that the user's locally stored ID and password are used for authentication. The value of radius indicates that the user's ID and password will be authenticated using the RADIUS server. The value of reject indicates the user is never authenticated.

To authenticate a user, the first authentication method in the user's login (authentication login list) is attempted. The 7200 Series Managed Switch software does not utilize multiple entries in the user's login. If the first entry returns a timeout, the user authentication attempt fails.

Note: The default login list included with the default configuration can not be changed.

Format	authentication	<pre>login <listname></listname></pre>	[method1	[method2
	[method3]]]			
Mode	Global Config			

11.1.1.1 no authentication login

This command deletes the specified authentication login list. The attempt to delete fails if any of the following conditions are true:

- The login list name is invalid or does not match an existing authentication login list
- The specified authentication login list is assigned to any user or to the non configured user for any component
- The login list is the default login list included with the default configuration and was not created using 'authentication login'. The default login list cannot be deleted.

Format	no authentication	login	<listname></listname>
Mode	Global Config		

11.1.2 clear dot1x statistics

This command resets the 802.1x statistics for the specified port or for all ports.

Format	<pre>clear dot1x statistics {<slot port=""> all}</slot></pre>
Mode	Privileged EXEC

11.1.3 clear radius statistics

This command is used to clear all RADIUS statistics.

Format	clear radius statistics
Mode	Privileged EXEC

11.1.4 dot1x defaultlogin

This command assigns the authentication login list to use for non-configured users for 802.1x port security. This setting is over-ridden by the authentication login list assigned to a specific user if the user is configured locally. If this value is not configured, users will be authenticated using local authentication only.

Format	dot1x defaultlogin	<listname></listname>
Mode	Global Config	

11.1.5 dot1x initialize

This command begins the initialization sequence on the specified port. This command is only valid if the control mode for the specified port is 'auto'. If the control mode is not 'auto' an error will be returned.

Format	<pre>dot1x initialize <slot port=""></slot></pre>
Mode	Privileged EXEC

11.1.6 dot1x login

This command assigns the specified authentication login list to the specified user for 802.1x port security. The *<user>* parameter must be a configured user and the *<listname>* parameter must be a configured authentication login list.

Format	<pre>dot1x login <user> <listname></listname></user></pre>
Mode	Global Config

11.1.7 dot1x max-req

This command sets the maximum number of times the authenticator state machine on this port will transmit an EAPOL EAP Request/Identity frame before timing out the supplicant. The *<count>* value must be in the range 1 - 10.

Default	2
Format	<pre>dot1x max-req <count></count></pre>
Mode	Interface Config

11.1.7.1 no dot1x max-req

This command sets the maximum number of times the authenticator state machine on this port will transmit an EAPOL EAP Request/Identity frame before timing out the supplicant.

Format	no dot1x max-req
Mode	Interface Config

11.1.8 dot1x port-control

This command sets the authentication mode to be used on the specified port. The control mode may be one of the following.

force-unauthorized: The authenticator PAE unconditionally sets the controlled port to unauthorized.

force-authorized: The authenticator PAE unconditionally sets the controlled port to authorized.

auto: The authenticator PAE sets the controlled port mode to reflect the outcome of the authentication exchanges between the supplicant, authenticator and the authentication server.

Default	auto
Format	<pre>dot1x port-control {force-unauthorized force- authorized auto}</pre>
Mode	Interface Config

11.1.8.1 no dot1x port-control

This command sets the authentication mode to be used on the specified port to 'auto'.

Format	no dot1x port-control
Mode	Interface Config

11.1.9 dot1x port-control all

This command sets the authentication mode to be used on all ports. The control mode may be one of the following modes:

- **force-unauthorized** The authenticator PAE unconditionally sets the controlled port to unauthorized.
- **force-authorized** The authenticator PAE unconditionally sets the controlled port to authorized.
- **auto** The authenticator PAE sets the controlled port mode to reflect the outcome of the authentication exchanges between the supplicant, authenticator and the authentication server.

Default	auto
Format	dotlx port-control all {force-unauthorized force-authorized auto}
Mode	Global Config

11.1.9.1 no dot1x port-control all

This command sets the authentication mode to be used on all ports to 'auto'.

Format	no dot1x port-control all
Mode	Global Config

11.1.10 dot1x re-authenticate

This command begins the re-authentication sequence on the specified port. This command is only valid if the control mode for the specified port is 'auto'. If the control mode is not 'auto' an error will be returned.

Format	dot1x re-authenticate	<slot port=""></slot>
Mode	Privileged EXEC	

11.1.11 dot1x re-authentication

This command enables re-authentication of the supplicant for the specified port.

Default	disabled
Format	dot1x re-authentication
Mode	Interface Config

11.1.11.1 no dot1x re-authentication

This command disables re-authentication of the supplicant for the specified port.

Format	no dot1x re-authentication
Mode	Interface Config

11.1.12 dot1x system-auth-control

This command is used to enable the dot1x authentication support on the switch. By default, the authentication support is disabled. While disabled, the dot1x configuration is retained and can be changed, but is not activated.

Default	disabled
Format	dot1x system-auth-control
Mode	Global Config

11.1.12.1 no dot1x system-auth-control

This command is used to disable the dot1x authentication support on the switch.

Format	no dot1x system-auth-control
Mode	Global Config

11.1.13 dot1x timeout

This command sets the value, in seconds, of the timer used by the authenticator state machine on this port. Depending on the token used and the value (in seconds) passed, various timeout configurable parameters are set. The following tokens are supported.

reauth-period: Sets the value, in seconds, of the timer used by the authenticator state machine on this port to determine when re-authentication of the supplicant takes place. The reauth-period must be a value in the range 1 - 65535.

quiet-period: Sets the value, in seconds, of the timer used by the authenticator state machine on this port to define periods of time in which it will not attempt to acquire a supplicant. The quiet-period must be a value in the range 0 - 65535.

tx-period: Sets the value, in seconds, of the timer used by the authenticator state machine on this port to determine when to send an EAPOL EAP Request/Identity frame to the supplicant. The quiet-period must be a value in the range 1 - 65535.

supp-timeout: Sets the value, in seconds, of the timer used by the authenticator state machine on this port to timeout the supplicant. The supp-timeout must be a value in the range 1 - 65535.

server-timeout: Sets the value, in seconds, of the timer used by the authenticator state machine on this port to timeout the authentication server. The supp-timeout must be a value in the range 1 - 65535.

Default	reauth-period: 3600 seconds quiet-period: 60 seconds
	tx-period: 30 seconds
	supp-timeout: 30 seconds
	server-timeout: 30 seconds
Format	<pre>dot1x timeout {{reauth-period <seconds>} {quiet- period <seconds>} {tx-period <seconds>} {supp- timeout <seconds>} {server-timeout <seconds>}}</seconds></seconds></seconds></seconds></seconds></pre>
Mode	Interface Config

11.1.13.1 no dot1x timeout

This command sets the value, in seconds, of the timer used by the authenticator state machine on this port to the default values. Depending on the token used, the corresponding default values are set.

Format	<pre>no dot1x timeout {reauth-period quiet-period </pre>
	<pre>tx-period supp-timeout server-timeout}</pre>
Mode	Interface Config

11.1.14 dot1x user

This command adds the specified user to the list of users with access to the specified port or all ports. The *<user>* parameter must be a configured user.

Format	<pre>dot1x user <user> {<slot port<="" pre=""></slot></user></pre>	:> all}
Mode	Global Config	

11.1.14.1 no dot1x user

This command removes the user from the list of users with access to the specified port or all ports.

Format	no dot1x user <user:< th=""><th>> {<slot port=""> all;</slot></th></user:<>	> { <slot port=""> all;</slot>
Mode	Global Config	

11.1.15 users defaultlogin

This command assigns the authentication login list to use for non-configured users when attempting to log in to the system. This setting is overridden by the authentication login list assigned to a specific user if the user is configured locally. If this value is not configured, users will be authenticated using local authentication only.

Format	users defaultlogin	<listname></listname>
Mode	Global Config	

11.1.16 users login

This command assigns the specified authentication login list to the specified user for system login. The *<user>* must be a configured *<user>* and the *<listname>* must be a configured login list.

If the user is assigned a login list that requires remote authentication, all access to the interface from all CLI, web, and telnet sessions will be blocked until the authentication is complete.

Note that the login list associated with the 'admin' user can not be changed to prevent accidental lockout from the switch.

Format	<pre>users login <user></user></pre>	<listname></listname>
Mode	Global Config	

11.1.17 show authentication

This command displays the ordered authentication methods for all authentication login lists.

Format	show authentication
Mode	Privileged EXEC
Authentication	
Login List	This displays the authentication login listname.

Method 1	This displays the first method in the specified authentication login list, if any.
Method 2	This displays the second method in the specified authentica- tion login list, if any.
Method 3	This displays the third method in the specified authentication login list, if any.

11.1.18 show authentication users

This command displays information about the users assigned to the specified authentication login list. If the login is assigned to non-configured users, the user "default" will appear in the user column.

Format	<pre>show authentication users <listname></listname></pre>
Mode	Privileged EXEC
User	This field displays the user assigned to the specified authenti- cation login list.
Component	This field displays the component (User or 802.1x) for which the authentication login list is assigned.

11.1.19 show dot1x

This command is used to show a summary of the global dot1x configuration, summary information of the dot1x configuration for a specified port or all ports, the detailed dot1x configuration for a specified port and the dot1x statistics for a specified port - depending on the tokens used.

Format	<pre>show dot1x [{summary {<slot port=""> all} {detail</slot></pre>
	<slot port="">} {statistics <slot port="">}]</slot></slot>
Mode	Privileged EXEC

If none of the optional parameters are used, the global dot1x configuration summary is displayed.

Administrative	
mode	Indicates whether authentication control on the switch is enabled or disabled.
you use the optional La	ummary (calot (parts / all)) parameter the dotly

If you use the optional [summary {<slot/port> | all}] parameter, the dot1x configuration for the specified port or all ports are displayed.

Port The interface whose configuration is displayed.

Control Mode	The configured control mode for this port. Possible values are force-unauthorized force-authorized auto.
Operating Control Mode	The control mode under which this port is operating. Possible values are authorized unauthorized.
Reauthentication Enabled	Indicates whether re-authentication is enabled on this port.
Key Transmission Enabled	Indicates if the key is transmitted to the supplicant for the specified port.

If you use the optional [detail <slot/port>] parameter, the detailed dot1x configuration for the specified port are displayed.

Port	The interface whose configuration is displayed.
Protocol Version	The protocol version associated with this port. The only possible value is 1, corresponding to the first version of the dot1x specification.
PAE Capabilities	The port access entity (PAE) functionality of this port. Possible values are Authenticator or Supplicant.
Authenticator PAE State	Current state of the authenticator PAE state machine. Possible values are Initialize, Disconnected, Connecting, Authenticat- ing, Authenticated, Aborting, Held, ForceAuthorized, and ForceUnauthorized.
Backend Authentication	
State	Current state of the backend authentication state machine. Possible values are Request, Response, Success, Fail, Time- out, Idle, and Initialize.
Quiet Period	The timer used by the authenticator state machine on this port to define periods of time in which it will not attempt to acquire a supplicant. The value is expressed in seconds and will be in the range 0 and 65535.
Transmit Period	The timer used by the authenticator state machine on the specified port to determine when to send an EAPOL EAP Request/Identity frame to the supplicant. The value, in seconds has a range of 1, 65535
Supplicant	
-------------------	---
Timeout	The timer used by the authenticator state machine on this port to timeout the supplicant. The value, in seconds, has a range of 1 - 65535.
Server Timeout	The timer used by the authenticator on this port to timeout the authentication server. The value, in seconds, has a range of 1 - 65535.
Maximum	
Requests	The maximum number of times the authenticator state machine on this port will retransmit an EAPOL EAP Request/Identity before timing out the supplicant. The value will be in the range of 1 and 10.
Reauthentication	
Period	The timer used by the authenticator state machine on this port to determine when reauthentication of the supplicant takes place. The value, in seconds, has a range of 1 - 65535.
Reauthentication	
Enabled	Indicates if reauthentication is enabled on this port. Possible values are 'True' or 'False'.
Key Transmission	
Enabled	Indicates if the key is transmitted to the supplicant for the specified port. Possible values are True or False.
Control Direction	Indicates the control direction for the specified port or ports. Possible values are both or in.

If you use the optional parameter [statistics <slot/port>], the following dot1x statistics for the specified port appear.

Port	The interface whose statistics are displayed.	
EAPOL Frames Received	The number of valid EAPOL frames of any type that have been received by this authenticator.	
EAPOL Frames Transmitted	The number of EAPOL frames of any type that have been transmitted by this authenticator.	
EAPOL Start Frames Received	The number of EAPOL start frames that have been received by this authenticator.	

EAPOL Logoff Frames Received	The number of EAPOL logoff frames that have been received by this authenticator.
Last EAPOL Frame Version	The protocol version number carried in the most recently received EAPOL frame.
Last EAPOL Frame Source	The source MAC address carried in the most recently received EAPOL frame.
EAP Response/Id Frames Received	The number of EAP response/identity frames that have been received by this authenticator.
EAP Response Frames Received	The number of valid EAP response frames (other than resp/id frames) that have been received by this authenticator.
EAP Request/Id Frames Transmitted	The number of EAP request/identity frames that have been
nansmitteu	transmitted by this authenticator.
EAP Request Frames	
Transmitted	The number of EAP request frames (other than request/iden- tity frames) that have been transmitted by this authenticator.
Invalid EAPOL Frames Received	The number of EAPOL frames that have been received by this authenticator in which the frame type is not recognized.
EAP Length Error Frames Received	The number of EAPOL frames that have been received by this authenticator in which the frame type is not recognized.

11.1.20 show dot1x users

This command displays 802.1x port security user information for locally configured users.

Format	<pre>show dot1x users <slot port=""></slot></pre>
Mode	Privileged EXEC
User	Users configured locally to have access to the specified port.

11.1.21 show users authentication

This command displays all user and all authentication login information. It also displays the authentication login list assigned to the default user.

Format	show users authentication
Mode	Privileged EXEC
User	Lists every user that has an authentication login list assigned.
System Login	Displays the authentication login list assigned to the user for system login.
802.1x Port	
Security	Displays the authentication login list assigned to the user for 802.1x port security.

11.2 RADIUS Commands

This section describes the commands you use to configure the 7200 Series Managed Switch to use a Remote Authentication Dial-In User Service (RADIUS) server on your network for authentication and accounting.

11.2.1 radius accounting mode

Use this command to enable the RADIUS accounting function.

Default	disabled
Format	radius accounting mode
Mode	Global Config

11.2.1.1 no radius accounting mode

Use this command to disable the RADIUS accounting function.

Format	no radius accounting mode
Mode	Global Config

11.2.2 radius server host

Use this command to configure the RADIUS authentication and accounting server. If you use the *<auth>* parameter, the command configures the IP address to use to connect to a RADIUS authentication server. You can configure up to 3 servers per RADIUS client. If the maximum number of configured servers is reached, the command fails until you remove one of the servers by issuing the "no" form of the command.

If you use the optional *<port>* parameter, the command configures the UDP port number to use when connecting to the configured RADIUS server. The *<port>* number range is 1 - 65535, with 1812 being the default value.

Note: To re-configure a RADIUS authentication server to use the default UDP *<port>*, set the *<port>* parameter to 1812.

If you use the *<acct>* parameter, the command configures the IP address to use for the RADIUS accounting server. You can only configure one accounting server. If an accounting server is currently configured, use the "no" form of the command to remove it from the configuration. The IP address you specify must match that of a previously configured accounting server.

If you use the optional *<port>* parameter, the command configures the UDP port to use when connecting to the RADIUS accounting server. If a *<port>* is already configured for the accounting server, the new *<port>* replaces the previously configured *<port>*. The *<port>* must be a value in the range 1 - 65535, with 1813 being the default.

Note: To re-configure a RADIUS accounting server to use the default UDP <i><port></port></i> , set the <i><port></port></i> parameter to 1813.

Format	<pre>radius server host {auth acct} <ipaddr> [<port>]</port></ipaddr></pre>
Mode	Global Config

11.2.2.1 no radius server host

This command is used to remove the configured RADIUS authentication server or the RADIUS accounting server. If the 'auth' token is used, the previously configured RADIUS authentication server is removed from the configuration. Similarly, if the 'acct' token is used, the previously configured RADIUS accounting server is removed from the configuration. The *ipaddr>* parameter must match the IP address of the previously configured RADIUS authentication / accounting server.

Format	<pre>no radius server host {auth acct} <ipaddress></ipaddress></pre>
Mode	Global Config

11.2.3 radius server key

This command is used to configure the shared secret between the RADIUS client and the RADIUS accounting / authentication server. Depending on whether the 'auth' or 'acct' token is used, the shared secret is configured for the RADIUS authentication or RADIUS accounting server. The IP address provided must match a previously configured server. When this command is executed, the secret is prompted.

Note: The secret must be an alphanumeric value not exceeding 16 characters.

Format	<pre>radius server key {auth acct} <ipaddr></ipaddr></pre>
Mode	Global Config

11.2.4 radius server msgauth

This command enables the message authenticator attribute for a specified server.

Format	<pre>radius server msgauth <ipaddr></ipaddr></pre>
Mode	Global Config

11.2.4.1 no radius server msgauth

This command disables the message authenticator attribute for a specified server.

Format	no radius	server	msgauth	<ipaddr></ipaddr>
Mode	Global Con	fig		

11.2.5 radius server primary

This command is used to configure the primary RADIUS authentication server for this RADIUS client. The primary server is the one that is used by default for handling RADIUS requests. The remaining configured servers are only used if the primary server cannot be reached. A maximum of three servers can be configured on each client. Only one of these servers can be configured as the primary. If a primary server is already configured prior to this command being executed, the server specified by the IP address specified used in this command will become the new primary server. The IP address must match that of a previously configured RADIUS authentication server.

Format	radius	server	primary	<ipaddr></ipaddr>
Mode	Global	Config		

11.2.6 radius server retransmit

This command sets the maximum number of times a request packet is re-transmitted when no response is received from the RADIUS server. The retries value is an integer in the range of 1 to 15.

Default	4
Format	<pre>radius server retransmit <retries></retries></pre>
Mode	Global Config

11.2.6.1 no radius server retransmit

This command sets the maximum number of times a request packet is re-transmitted, to the default value.

Format	no radius server retransmit
Mode	Global Config

11.2.7 radius server timeout

This command sets the timeout value (in seconds) after which a request must be retransmitted to the RADIUS server if no response is received. The timeout value is an integer in the range of 1 to 30.

Default	5
Format	<pre>radius server timeout <seconds></seconds></pre>
Mode	Global Config

11.2.7.1 no radius server timeout

This command sets the timeout value to the default value.

Format	no radius server timeout
Mode	Global Config

11.2.8 show radius

This command is used to display the various RADIUS configuration items for the switch as well as the configured RADIUS servers. Format

	show radius [servers]
Mode	Privileged EXEC
Primary Server IP	
Address	Shows the configured server currently in use for authentication.
Number of configured servers	The configured IP address of the authentication server.
Max number of retransmits	The configured value of the maximum number of times a request packet is retransmitted.
Timeout Duration	The configured timeout value, in seconds, for request re- transmissions.
Accounting Mode	Yes or No.

If you include the optional [servers] parameter, the following information regarding the configured RADIUS servers is displayed.

IP Address	IP Address of the configured RADIUS server.
Port	The port in use by this server.
Туре	Primary or secondary.
Secret Configured	Yes / No.
Message Authenticator	Enables or disables. the message authenticator attribute for the selected server.

11.2.9 show radius accounting

This command is used to display the configured RADIUS accounting mode, accounting server and the statistics for the configured accounting server.

Format	show radius	accounting	[statistics	<ipaddr>]</ipaddr>
Mode	Privileged EX	EC		

If the optional token 'statistics *<ipaddr>*' is not included, then only the accounting mode and the RADIUS accounting server details are displayed.

Mode	Enabled or disabled
IP Address	The configured IP address of the RADIUS accounting server.
Port	The port in use by the RADIUS accounting server.
Secret Configured	Yes or No

If you include the optional [statistics <ipaddr>] parameter, the statistics for the configured RADIUS accounting server are displayed. The IP address parameter must match that of a previously configured RADIUS accounting server. The following information regarding the statistics of the RADIUS accounting server is displayed.

Accounting Server IP Address	IP Address of the configured RADIUS accounting server
Round Trip Time	The time interval in hundredths of a second between the
	most recent Accounting-Response and the Accounting- Request that matched it from the RADIUS accounting server.
Requests	The number of RADIUS Accounting-Request packets sent to this accounting server. This number does not include retransmissions.
Retransmission	The number of RADIUS Accounting-Request packets retransmitted to this RADIUS accounting server.
Responses	The number of RADIUS packets received on the accounting port from this server.
Malformed	
Responses	The number of malformed RADIUS Accounting-Response packets received from this server. Malformed packets include packets with an invalid length. Bad authenticators and unknown types are not included as malformed accounting responses.

Bad Authenticators	The number of RADIUS Accounting-Response packets con- taining invalid authenticators received from this accounting server.
Pending	
Requests	The number of RADIUS Accounting-Request packets sent to this server that have not yet timed out or received a response.
Timeouts	The number of accounting timeouts to this server.
Unknown Types	The number of RADIUS packets of unknown types, which were received from this server on the accounting port.
Packets Dropped	The number of RADIUS packets received from this server on the accounting port and dropped for some other reason.

11.2.10 show radius statistics

This command is used to display the statistics for RADIUS or configured server. To show the configured RADIUS server statistic, the IP Address specified must match that of a previously configured RADIUS server. On execution, the following fields are displayed.

Format	show radius statistics [ipaddr]
Mode	Privileged EXEC

If you do not specify an IP address, then only the Invalid Server Address field is displayed. Otherwise other listed fields are displayed.

Invalid Server Addresses	The number of RADIUS Access-Response packets received from unknown addresses.
Server IP	ID Address of the Commen
Address	IP Address of the Server.
Round Trip Time	The time interval, in hundredths of a second, between the most recent Access-Reply, Access-Challenge and the Access- Request that matched it from the RADIUS authentication server.
Access Requests	The number of RADIUS Access-Request packets sent to this server. This number does not include retransmissions.
Access	
Retransmission	The number of RADIUS Access-Request packets retransmit- ted to this RADIUS authentication server.

Access Accepts	The number of RADIUS Access-Accept packets, including both valid and invalid packets, which were received from this server.
Access Rejects	The number of RADIUS Access-Reject packets, including both valid and invalid packets, which were received from this server.
Access	
Challenges	The number of RADIUS Access-Challenge packets, includ- ing both valid and invalid packets, which were received from this server.
Malformed Access	
Responses	The number of malformed RADIUS Access-Response pack- ets received from this server. Malformed packets include packets with an invalid length. Bad authenticators or signa- ture attributes or unknown types are not included as mal- formed access responses.
Bad	
Authenticators	The number of RADIUS Access-Response packets contain- ing invalid authenticators or signature attributes received from this server.
Pending	
Requests	The number of RADIUS Access-Request packets destined for this server that have not yet timed out or received a response.
Timeouts	The number of authentication timeouts to this server.
Unknown Types	The number of RADIUS packets of unknown types, which were received from this server on the authentication port.
Packets Dropped	The number of RADIUS packets received from this server on the authentication port and dropped for some other reason.

Chapter 12 Port-Channel/LAG (802.3ad) Commands

This section describes the Link Aggregation/Port-Channel (802.3ad) commands available in the 7200 Series Managed Switch CLI. Port channels are also known as link aggregation groups (LAGs). Link aggregation allows you to combine multiple full-duplex Ethernet links into a single logical link. Network devices treat the aggregation as if it were a single link, which increases fault tolerance and provides load sharing. The LAG feature initially load shares traffic based upon the source and destination MAC address.

The Port-Channel/LAG Command section includes the following topics:

- Section 12.1 "Port-Channel Configuration Commands" on page 12-1
- Section 12.2 "Port-Channel Show Commands" on page 12-6

The commands in this section are in one of three functional groups:

- Show commands display switch settings, statistics, and other information.
- Configuration commands configure features and options of the switch. For every configuration command, there is a show command that displays the configuration setting.
- Clear commands clear some or all of the settings to factory defaults.

12.1 Port-Channel Configuration Commands

This section describes the commands you use to configure port-channels. Assign the LAG VLAN membership after you create a LAG. If you do not assign VLAN membership, the LAG might become a member of the management VLAN which can result in learning and switching issues.

12.1.1 addport

This command adds one port to the port-channel (LAG). The first interface is a logical unit, slot and port number of a configured port-channel.

Note: Before adding a port to a port-channel, set the physical mode of the port. For more information, see Section 4.1.11 "speed" on page 4-5.

Format	addport	<logical< th=""><th><pre>slot/port></pre></th></logical<>	<pre>slot/port></pre>
Mode	Interface	Config	

12.1.2 deleteport (Interface Config)

This command deletes the port from the port-channel (LAG). The interface is a logical slot and port number of a configured port-channel.

Format	deleteport	<logical< th=""><th>slot/port></th></logical<>	slot/port>
Mode	Interface Con	nfig	

12.1.3 deleteport (Global Config)

This command deletes all configured ports from the port-channel (LAG). The interface is a logical slot and port number of a configured port-channel.

```
Formatdeleteport {<logical slot/port> | all}ModeGlobal Config
```

12.1.4 port-channel

This command configures a new port-channel and generates a logical slot/port number for the port-channel. The <*name*> field is a character string which allows the dash "-" character as well as alphanumeric characters. Display this number using the **show port channel** command.

Note: Before you include a port in a port-channel, set the port physical mode. For more information, see Section 4.1.11 "speed" on page 4-5.

Format	<pre>port-channel <name< pre=""></name<></pre>	>
Mode	Global Config	

12.1.4.1 no port-channel

This command deletes a port-channel (LAG).

Format	no port-channel	{ <logical< th=""><th><pre>slot/port></pre></th><th>/</th><th>all}</th></logical<>	<pre>slot/port></pre>	/	all}
Mode	Global Config				

12.1.5 clear port-channel

Use this command to clear all configured port channels.

Format	clear port-channel
Mode	Privileged EXEC

12.1.6 port-channel staticcapability

This command enables the support of port-channels (static link aggregations) on the device. By default, the static capability for all port-channels is disabled.

Default	disabled	
Format	port-channel	staticcapability
Mode	Global Config	

12.1.6.1 no port-channel staticcapability

This command disables the support of static port-channels on the device.

Format	no port-channel staticcapability
Mode	Global Config

12.1.7 port lacpmode

This command enables Link Aggregation Control Protocol (LACP) on a port.

Default	enabled
Format	port lacpmode
Mode	Interface Config

12.1.7.1 no port lacpmode

This command disables Link Aggregation Control Protocol (LACP) on a port.

Format	no port lacpmode
Mode	Interface Config

12.1.8 port lacpmode all

This command enables Link Aggregation Control Protocol (LACP) on all ports.

Format	port lacpmode all
Mode	Global Config

12.1.8.1 no port lacpmode all

This command disables Link Aggregation Control Protocol (LACP) on all ports.

Format	no port lacpmode all
Mode	Global Config

12.1.9 port-channel adminmode

This command enables a port-channel (LAG). The option **all** sets every configured portchannel with the same administrative mode setting.

Format	port-channel	adminmode	[all]
Mode	Global Config		

12.1.9.1 no port-channel adminmode

This command disables a port-channel (LAG). The option **all** sets every configured portchannel with the same administrative mode setting.

Formatno port-channel adminmode [all]ModeGlobal Config

12.1.10 port-channel name

This command defines a name for the port-channel (LAG). The interface is a logical slot/ port for a configured port-channel, and *<name>* is an alphanumeric string up to 15 characters.

Format	<pre>port-channel name {<logical port="" slot=""> <name>}</name></logical></pre>	all
Mode	Global Config	

12.1.11 port-channel linktrap

This command enables link trap notifications for the port-channel (LAG). The interface is a logical slot/port for a configured port-channel. The option **all** sets every configured port-channel with the same administrative mode setting.

Default	enabled
Format	<pre>port-channel linktrap {<logical port="" slot=""> all}</logical></pre>
Mode	Global Config

12.1.11.1 no port-channel linktrap

This command disables link trap notifications for the port-channel (LAG). The interface is a logical slot and port for a configured port-channel. The option all sets every configured port-channel with the same administrative mode setting.

Format	no port-channel linktrap { <logical port="" slot=""> , all}</logical>
Mode	Global Config

12.2 Port-Channel Show Commands

This section describes the commands you use to view port-channel status and configuration information.

12.2.1 show port-channel

This command displays the static capability of all port-channels (LAGs) on the device as well as a summary of individual port-channels.

Format	show port-channel
Modes	Privileged EXEC User EXEC
Static Capability	This field displays whether or not the device has static capability enabled.
For each port-channel the for	ollowing information is displayed:
Name	This field displays the name of the port-channel.
Link State	This field indicates whether the link is up or down.
Mbr Ports	This field lists the ports that are members of this port-chan- nel, in <i><slot port=""></slot></i> notation.
Active Ports	This field lists the ports that are actively participating in this port-channel.

12.2.2 show port-channel

This command displays an overview of all port-channels (LAGs) on the switch.

Format	<pre>show port-channel {<logical port="" slot=""> all}</logical></pre>
Modes	Privileged EXEC User EXEC
Logical Interface	Valid slot and port number separated by forward slashes.
Port-Channel	
Name	The name of this port-channel (LAG). You may enter any string of up to 15 alphanumeric characters.
Link State	Indicates whether the Link is up or down.
Admin Mode	May be enabled or disabled. The factory default is enabled

Link Trap Mode	This object determines whether or not to send a trap when link status changes. The factory default is enabled.
STP Mode	The Spanning Tree Protocol Administrative Mode associated with the port or port-channel (LAG). The possible values are: Disable - Spanning tree is disabled for this port. Enable - Spanning tree is enabled for this port.
Mbr Ports	A listing of the ports that are members of this port-channel (LAG), in slot/port notation. There can be a maximum of eight ports assigned to a given port-channel (LAG).
Port Speed	Speed of the port-channel port.
Туре	This field displays the status designating whether a particular port-channel (LAG) is statically or dynamically maintained. Static - The port-channel is statically maintained
	Dynamic - The port-channel is dynamically maintained.
Active Ports	This field lists ports that are actively participating in the port- channel (LAG).

Chapter 13 IGMP Snooping Commands

This section describes the Internet Group Management Protocol (IGMP) snooping commands available in the 7200 Series Managed Switch CLI.

The 7200 Series Managed Switch supports IGMP Versions 1, 2, and 3. The IGMP snooping feature can help conserve bandwidth because it allows the switch to forward IP multicast traffic only to connected hosts that request multicast traffic. IGMPv3 adds source filtering capabilities to IGMP versions 1 and 2.

This section contains the following topics:

- Section 13.1 "IGMP Snooping Configuration Commands" on page 13-1
- Section 13.2 "IGMP Snooping Show Commands" on page 13-6
- Section 13.3 "IGMP Querier Commands" on page 13-9

The commands in this section are in one of two groups:

- Show commands are used to display switch settings, statistics and other information.
- Configuration Commands are used to configure features and options of the switch. For every configuration command there is a show command that will display the configuration setting.

13.1 IGMP Snooping Configuration Commands

This section describes the commands you use to configure IGMP snooping.

13.1.1 ip igmpsnooping

This command enables IGMP Snooping on the system (Global Config Mode) or an interface (Interface Config Mode). This command also enables IGMP snooping on a particular VLAN and can enable IGMP snooping on all interfaces participating in a VLAN.

If an interface has IGMP Snooping enabled and you enable this interface for routing or enlist it as a member of a port-channel (LAG), IGMP Snooping functionality is disabled on that interface. IGMP Snooping functionality is re-enabled if you disable routing or remove port-channel (LAG) membership from an interface that has IGMP Snooping enabled.

The IGMP application supports the following activities:

- Validation of the IP header checksum (as well as the IGMP header checksum) and discarding of the frame upon checksum error.
- Maintenance of the forwarding table entries based on the MAC address versus the IP address.
- Flooding of unregistered multicast data packets to all ports in the VLAN.

Default	disabled
Format	ip igmpsnooping <vlanid></vlanid>
Modes	Global Config
	Interface Config
	VLAN Mode

13.1.1.1 no ip igmpsnooping

This command disables IGMP Snooping on the system.

Format	no ip igmpsnooping <vlanid></vlanid>
Modes	Global Config
	Interface Config
	VLAN Mode

13.1.2 ip igmpsnooping interfacemode

This command enables IGMP Snooping on all interfaces. If an interface has IGMP Snooping enabled and you enable this interface for routing or enlist it as a member of a port-channel (LAG), IGMP Snooping functionality is disabled on that interface. IGMP Snooping functionality is re-enabled if you disable routing or remove port-channel (LAG) membership from an interface that has IGMP Snooping enabled.

Default	disabled
Format	ip igmpsnooping interfacemode
Mode	Global Config

13.1.2.1 no ip igmpsnooping interfacemode

This command disables IGMP Snooping on all interfaces.

Format	no ip igmpsnooping interfacemode
Mode	Global Config

13.1.3 ip igmpsnooping groupmembership-interval

This command sets the IGMP Group Membership Interval time on a VLAN, one interface or all interfaces. The Group Membership Interval time is the amount of time in seconds that a switch waits for a report from a particular group on a particular interface before deleting the interface from the entry. This value must be greater than the IGMPv3 Maximum Response time value. The range is 2 to 3600 seconds.

Default	260 seconds
Format	<pre>ip igmpsnooping groupmembership-interval <vlanid> <2-3600></vlanid></pre>
Modes	Interface Config Global Config VLAN Mode

13.1.3.1 no ip igmpsnooping groupmembership-interval

This command sets the IGMPv3 Group Membership Interval time to the default value.

Format	no ip igmpsnooping groupmembership-interval
Modes	Interface Config
	Global Config
	VLAN Mode

13.1.4 ip igmpsnooping maxresponse

This command sets the IGMP Maximum Response time for the system, on a particular interface or VLAN. The Maximum Response time is the amount of time in seconds that a switch will wait after sending a query on an interface because it did not receive a report for a particular group in that interface. This value must be less than the IGMP Query Interval time value. The range is 1 to 3599 seconds.

Default	10 seconds	
Format	ip igmpsnooping maxresponse	<1-3599>
Modes	Global Config	
	Interface Config	
	VLAN Mode	

13.1.4.1 no ip igmpsnooping maxresponse

This command sets the IGMP Maximum Response time (on the interface or VLAN) to the default value.

Format	no ip igmpsnooping maxresponse
Modes	Global Config
	Interface Config
	VLAN Mode

13.1.5 ip igmpsnooping mcrtexpiretime

This command sets the Multicast Router Present Expiration time. The time is set for the system, on a particular interface or VLAN.

This is the amount of time in seconds that a switch waits for a query to be received on an interface before the interface is removed from the list of interfaces with multicast routers attached. The range is 0 to 3600 seconds. A value of 0 indicates an infinite time-out, i.e. no expiration.

Default	0
Format	<pre>ip igmpsnooping mcrtexpiretime <vlanid> <0-3600></vlanid></pre>
Modes	Global Config Interface Config

13.1.5.1 no ip igmpsnooping mcrtexpiretime

This command sets the Multicast Router Present Expiration time to 0. The time is set for the system, on a particular interface or a VLAN.

Format	no ip igmpsnooping mcrtexpiretime <vlanid></vlanid>
Modes	Global Config
	Interface Config

13.1.6 ip igmp mrouter

This command configures the interface to only forward the snooped IGMP packets that come from VLAN ID ($\langle vlanId \rangle$) to the multicast router mode attached to this interface. The command is not needed most of the time since the switch will automatically detect the presence of a multicast router and forward IGMP packets accordingly. It is only needed when you want to make sure that the multicast router always receives IGMP packets from the switch in a complex network.

Default	Disabled
Format	<pre>ip igmp mrouter <vlanid></vlanid></pre>
Mode	Interface Config

13.1.6.1 no ip igmp mrouter

This command disables the forwarding of IGMP packets to this interface.

Format	<pre>no ip igmp mrouter <vlanid></vlanid></pre>
Mode	Interface Config

13.1.7 ip igmp mrouter interface

This command configures the interface as the one the multicast router is attached to. All IGMP packets snooped by the switch will be forwarded to the multicast router reachable from this interface. The command is not needed most of the time since the switch will automatically detect the presence of multicast router and forward IGMP packet accordingly. It is only needed when you want to make sure the multicast router always receives IGMP packets from the switch in a complex network.

Default	Disabled
Format	ip igmp mrouter interface
Mode	Interface Config

13.1.7.1 no ip igmp mrouter interface

This command disables the forwarding of IGMP packets to a multicast router via this interface.

Format	no ip igmp mrouter interface
Mode	Interface Config

13.1.8 ip igmpsnooping unknown-multicast

This command enables the filtering of unknown multicast packets to the VLAN. Packets with an unknown mulicast address in the destination field will be dropped. This command is mainly used when IGMP snooping is enabled, to prevent flooding of unwanted multicast packets to every port.

Format	ip igmpsnooping unknown-multicast
Mode	Global Config

13.1.8.1 no ip igmpsnooping unknown-mulitcast

This command disables the filtering of unknown multicast packets. Unknown multicast packets will be flooded to all ports in the same VLAN.

Formatno ip igmpsnooping unknown-mulitcastModeGlobal Config

13.2 IGMP Snooping Show Commands

This section describes the commands you use to view IGMP snooping status and information.

13.2.1 show ip igmp

This command displays IGMP Snooping information. Configured information is displayed whether or not IGMP Snooping is enabled.

Format	<pre>show ip igmp [<slot port=""> <vlanid>]</vlanid></slot></pre>
Mode	Privileged EXEC

When the optional arguments <*slot/port>* or <*vlanId>* are not used, the command displays the following information:

Admin Mode	This indicates whether or not IGMP Snooping is active on the switch.
Interfaces Enabled for IGMP Snooping	This is the list of interfaces on which IGMP Snooping is enabled.
Multicast Control Frame Count	This displays the number of multicast control frames that are processed by the CPU.
VLANS Enabled for IGMP Snooping	This is the list of VLANS on which IGMP Snooping is enabled.

When you specify the *<slot/port>* values, the following information appears:

IGMP Snooping Admin Mode	This indicates whether IGMP Snooping is active on the inter-
	face.
Fast Leave Mode	Indicates whether IGMP Snooping Fast-leave is active on the VLAN.
Group Membership	
Interval	Shows the amount of time in seconds that a switch will wait for a report from a particular group on a particular interface, which is participating in the VLAN, before deleting the inter- face from the entry. This value may be configured
Max Response	
Time	Displays the amount of time the switch waits after it sends a query on an interface, participating in the VLAN, because it did not receive a report for a particular group on that inter- face. This value may be configured.
Multicast Router Present Expiration	
Time	Displays the amount of time to wait before removing an interface that is participating in the VLAN from the list of interfaces with multicast routers attached. The interface is removed if a query is not received. This value may be config- ured.

When you specify a value for *<vlanid>*, the following additional information appears:

VLAN AdminModeIndicates whether IGMP Snooping is active on the VLAN.

13.2.2 show ip igmp mrouter interface

This command displays information about statically configured ports.

Format	<pre>show ip igmp mrouter interface <slot port=""></slot></pre>
Mode	Privileged EXEC
Interface	Shows the port on which multicast router information is being displayed.
Multicast Router	
Attached	Indicates whether multicast router is statically enabled on the interface.
VLAN ID	Displays the list of VLANs of which the interface is a mem- ber.

13.2.3 show ip igmp mrouter vlan

This command displays information about statically configured ports.

Format	<pre>show ip igmp mrouter vlan <slot port=""></slot></pre>
Mode	Privileged EXEC
Interface	Shows the port on which multicast router information is being displayed.
VLAN ID	Displays the list of VLANs of which the interface is a mem- ber.

13.2.4 show mac-address-table igmpsnooping

This command displays the IGMP Snooping entries in the MFDB table.

Format	show mac-address-table igmpsnooping
Mode	Privileged EXEC
MAC Address	A multicast MAC address for which the switch has forward- ing or filtering information. The format is two-digit hexadec-
	imal numbers that are separated by colons, for example
	01:23:45:67:89:AB. In an IVL system the MAC address is

	displayed as a MAC address and VLAN ID combination of 8 bytes.
Туре	Displays the type of the entry, which is either static (added by the user) or dynamic (added to the table as a result of a learn- ing process or protocol).
Description	The text description of this multicast table entry.
Interfaces	The list of interfaces that are designated for forwarding (Fwd:) and filtering (Flt:).

13.3 IGMP Querier Commands

A switch configured as a querier will send general queries periodically to request group membership information from an attached network. These queries will invoke client response that can be used to build and refresh the multicast group membership state of systems (snooping entries of MFDB table) on the attached networks. Interested hosts shall respond to these queries by reporting their group membership state and this will result in creation of snooping entry in MFDB table.

The IGMP querier function supports IGMP Version 2.

The IGMP querier function must be enabled on VLAN basis.

IGMP snooping must be enabled on the switch for the querier function to be enabled.

When a VLAN is configured as a querier, IGMP query packets will be sent on every port, which is a member of the VLAN. If a multicast router is attached on a port (either detected dynamically or configured statically by the user) then the IGMP general query packet will not be sent to that port. A physical port on which IGMP query message is to be sent should fulfill the following criteria:

- Multicast router is not attached.
- Must not be the probe port of a mirroring session.
- Must not be a LAG member.
- Must not be enabled for routing.
- Must be in the Forwarding state.

The query packets that are sent periodically will have one of the following IP addresses for the source IP address field:

• VLAN Interface Address (for L3 switches only) 'or'

- IGMP Snooping Querier Address (a configurable globally) 'or'
- Switch Management Interface Address 'or'
- First configured interface address (for L3 switches only)

The switch will check for each of these IP addresses not being 0.0.0.0 in the specified order and choose the first such address. If all these IP addresses are found to be 0.0.00, no query packets are sent.

If multiple IGMP queriers reside on the VLAN the switch with lower IP address will remain active. Note that if the other querier is a multicast router it will continue sending queries and will not back off. The interval for the IGMP queries sent by the switch is configurable. Default is 60 seconds. Valid range shall be 1 to 18000 seconds. If the global querier mode is disabled IGMP querier function shall not be operational on any of the VLANs.

13.3.1 ip igmpsnooping querier

To enable IGMP querier function, use the **ip igmpsnooping querier** command. The command applies to the context in which it is executed (global or per VLAN). The <vlan-id> is the VLAN where IGMP querier will be sent.

Format	[no] ip igmpsnooping querier [<vlan-id>]</vlan-id>
Mode	Global Config, VLAN Database
Default	Disabled

13.3.2 ip igmpsnooping querier ip-address

To configure the IP address *<ipaddr>* used by the IGMP querier function, use the **ip igmpsnooping querier ip-address** command and **no ip igmpsnooping querier ip-address** *<ipaddr>*. The *<ipadr>* cannot be a class D or E address.

Format	ip igmpsnooping querier ip-address ${<}ipaddr{>}$				
	no ip igmpsnooping querier ip-address				
Mode	Global Config				
Default	0.0.0.0				

13.3.3 ip igmpsnooping querier query-interval

To configure the IGMP querier query interval *<interval>* for a VLAN *<vlan-id>*, use the **ip igmpsnooping querier query-interval** command. Valid range for *<interval>* is 1 to 18000 seconds. *<Vlan-id>* must be a defined VLAN.

Format	[no] ip igmpsnooping querier query-interval ${<}vlan-id{>}$ ${<}interval{>}$
Mode	Global Config
Default	interval, 60

13.3.4 show ip igmpsnooping querier

To display IGMP querier configuration information use **show ip igmpsnooping querier** command. To display global querier information use **show ip igmpsnooping querier**. To display VLAN specific querier information with the *<vlan-id>* option,

Format	show ip igmpsnooping querier [<vlan-id>]</vlan-id>
Mode	Privileged EXEC Mode

Chapter 14 Quality of Service (QoS) Commands

This section describes the Quality of Service (QoS) commands available in the 7200 Series Managed Switch CLI.

This section contains the following topics:

- Section 14.1 "Class of Service (CoS) Commands (GSM7248 only)" on page 14-2
- Section 14.2 "Differentiated Services (DiffServ) Commands" on page 14-8
- Section 14.3 "DiffServ Class Commands (GSM7248 only)" on page 14-9
- Section 14.4 "DiffServ Policy Commands (GSM7248 only)" on page 14-17
- Section 14.5 "DiffServ Service Commands (GSM7248 only)" on page 14-23
- Section 14.6 "DiffServ Show Commands" on page 14-25
- Section 14.7 "MAC Access Control List (ACL) Commands (GSM7248 only)" on page 14-31
- Section 14.8 "IP Access Control List (ACL) Commands (GSM7248 only)" on page 14-35

The commands in this section are in one of two functional groups:

- Configuration Commands are used to configure features and options of the switch. For every configuration command there is a show command that will display the configuration setting.
- Show commands are used to display device settings, statistics and other information.

14.1 Class of Service (CoS) Commands (GSM7248 only)

This section describes the commands you use to configure and view Class of Service (CoS) settings for the switch. The commands in this section allow you to control the priority and transmission rate of traffic.

Note: Commands you issue in the Interface Config mode only affect a single interface. Commands you issue in the Global Config mode apply to all interfaces.

14.1.1 classofservice dot1p-mapping

This command maps an 802.1p priority to an internal traffic class. The *<userpriority>* and *<trafficclass>* values can both range from 0-7, although the actual number of available traffic classes depends on the platform. For more information about 802.1p priority, see Section 6.3 "Provisioning (IEEE 802.1p) Commands" on page 6-14.

Format	classofservice ficclass>	dot1p-mapping	<userpriority></userpriority>	<traf-< th=""></traf-<>
Modes	Global Config Interface Config			

14.1.1.1 no classofservice dot1p-mapping

This command maps an 802.1p priority to a default internal traffic class value.

Format	no classofservice dot1p-mapping
Modes	Global Config
	Interface Config

14.1.2 classofservice ip-precedence-mapping

This command maps an IP precedence value to an internal traffic class. The *<ip*-*precedence>* and *<trafficclass>* values can both range from 0-7, although the actual number of available traffic classes depends on the platform.

Format	<pre>classofservice ip-precedence-mapping dence> <trafficclass></trafficclass></pre>	<ip-prece-< th=""></ip-prece-<>
Modes	Global Config Interface Config	

14.1.2.1 no classofservice ip-precedence-mapping

This command maps an IP precedence value to a default internal traffic class value

Format	no classofservice ip-precedence-mapping
Modes	Global Config Interface Config

14.1.3 classofservice ip-dscp-mapping

This command maps an IP DSCP value to an internal traffic class. The *<ipdscp>* value is specified as either an integer from 0 to 63, or symbolically through one of the following keywords: af11, af12, af13, af21, af22, af23, af31, af32, af33, af41, af42, af43, be, cs0, cs1, cs2, cs3, cs4, cs5, cs6, cs7, ef.

The *<trafficclass>* range is from 0-7.

Format	classofservice	ip-dscp-mapping	<ipdscp></ipdscp>	<traffic-< th=""></traffic-<>
	class>			
Mode	Global Config			

14.1.3.1 no classofservice ip-dscp-mapping

This command maps an IP DSCP value to a default internal traffic class value.

Format	no classofservice	ip-dscp-mapping
Mode	Global Config	

14.1.4 classofservice trust

This command sets the class of service trust mode of an interface. You can set the mode to trust one of the Dot1p (802.1p), IP DSCP, or IP Precedence packet markings.

Format	<pre>classofservice dence></pre>	trust	<dot1p< th=""><th>/</th><th>ip-dscp</th><th>/</th><th>ip-prece-</th></dot1p<>	/	ip-dscp	/	ip-prece-
Mode	Global Config Interface Config						

14.1.4.1 no classofservice trust

This command sets the interface mode to untrusted.

Format	no classofservice trust
Modes	Global Config
	Interface Config

14.1.5 cos-queue min-bandwidth

This command specifies the minimum transmission bandwidth guarantee for each interface queue. The total number of queues supported per interface is platform specific. A value from 0-100 (percentage of link rate) must be specified for each supported queue, with 0 indicating no guaranteed minimum bandwidth. The sum of all values entered must not exceed 100.

Format	cos-queue min-bandwidth	<bw-0></bw-0>	<bw-1></bw-1>	•••	<bw-n></bw-n>
Modes	Global Config				
	Interface Config				

14.1.5.1 no cos-queue min-bandwidth

This command restores the default for each queue's minimum bandwidth value.

Format	no cos-queue min-bandwidth
Modes	Global Config
	Interface Config

14.1.6 cos-queue strict

This command activates the strict priority scheduler mode for each specified queue.

Format	<pre>cos-queue strict <queue-id-1> [<queue-id-2> <queue-id-n>]</queue-id-n></queue-id-2></queue-id-1></pre>
Modes	Global Config Interface Config

14.1.6.1 no cos-queue strict

This command restores the default weighted scheduler mode for each specified queue.

Format	<pre>no cos-queue strict <queue-id-1> [<queue-id-2> <queue-id-n>]</queue-id-n></queue-id-2></queue-id-1></pre>
Modes	Global Config Interface Config

14.1.7 traffic-shape

This command specifies the maximum transmission bandwidth limit for the interface as a whole. Also known as rate shaping, traffic shaping has the effect of smoothing temporary traffic bursts over time so that the transmitted traffic rate is bounded.

Format	<pre>traffic-shape <bw></bw></pre>
Modes	Global Config
	Interface Config

14.1.7.1 no traffic-shape

This command restores the interface shaping rate to the default value.

Format	no traffic-shape
Modes	Global Config
	Interface Config

14.1.8 show classofservice dot1p-mapping

This command displays the current Dot1p (802.1p) priority mapping to internal traffic classes for a specific interface. The unit/slot/port parameter is optional and is only valid on platforms that support independent per-port class of service mappings. If specified, the 802.1p mapping table of the interface is displayed. If omitted, the most recent global configuration settings are displayed. For more information, see Section 6.3 "Provisioning (IEEE 802.1p) Commands" on page 6-14.

Format	show classofservice dot1p-mapping	[unit/slot/port]
Mode	Privileged EXEC	

The following information is repeated for each user priority.

User Priority	The 802.1p user priority value.
Traffic Class	The traffic class internal queue identifier to which the user
	priority value is mapped.

14.1.9 show classofservice ip-precedence-mapping

This command displays the current IP Precedence mapping to internal traffic classes for a specific interface. The unit/slot/port parameter is optional and is only valid on platforms that support independent per-port class of service mappings. If specified, the IP Precedence mapping table of the interface is displayed. If omitted, the most recent global configuration settings are displayed.

Format	<pre>show classofservice ip-precedence-mapping [unit/ slot/port]</pre>
Mode	Privileged EXEC
The following information is repeated for each user priority.	
IP Precedence	The IP Precedence value.
Traffic Class	The traffic class internal queue identifier to which the IP Pre- cedence value is mapped.

Note: This command is only supported on the GSM7248.

14.1.10 show classofservice ip-dscp-mapping

This command displays the current IP DSCP mapping to internal traffic classes for the global configuration settings.

Format	show classofservice	ip-dscp-mapping
Mode	Privileged EXEC	

The following information is repeated for each user priority.

IP DSCP	The IP DSCP value.
Traffic Class	The traffic class internal queue identifier to which the IP
	DSCP value is mapped.

14.1.11 show classofservice trust

This command displays the current trust mode setting for a specific interface. The unit/ slot/port parameter is optional and is only valid on platforms that support independent perport class of service mappings. If specified, the port trust mode of the interface is displayed. If omitted, the most recent global configuration settings are displayed.

Format	<pre>show classofservice trust [unit/slot/port]</pre>	
Mode	Privileged EXEC	
Non-IP Traffic		
Class	The traffic class used for non-IP traffic. This is only dis-	
	played when the COS trust mode is set to trust ip-precedence.	
Untrusted Traffic Class

The traffic class used for all untrusted traffic. This is only displayed when the COS trust mode is set to 'untrusted'.

14.1.12 show interfaces cos-queue

This command displays the class-of-service queue configuration for the specified interface. The unit/slot/port parameter is optional and is only valid on platforms that support independent per-port class of service mappings. If specified, the class-of-service queue configuration of the interface is displayed. If omitted, the most recent global configuration settings are displayed.

<pre>show interfaces cos-queue [unit/slot/port]</pre>
Privileged EXEC
An interface supports n queues numbered 0 to (n-1). The spe- cific n value is platform dependent.
The minimum transmission bandwidth guarantee for the queue, expressed as a percentage. A value of 0 means bandwidth is not guaranteed and the queue operates using best-effort. This is a configured value.
Indicates whether this queue is scheduled for transmission using a strict priority or a weighted scheme. This is a config- ured value.
The queue depth management technique used for this queue (tail drop).
the following information also appears:
This displays the unit/slot/port of the interface. If displaying the global configuration, this output line is replaced with a Global Config indication.
The maximum transmission bandwidth limit for the interface as a whole. It is independent of any per-queue maximum bandwidth value(s) in effect for the interface. This is a con- figured value.

14.2 Differentiated Services (DiffServ) Commands

This section describes the commands you use to configure QOS Differentiated Services (DiffServ).

You configure DiffServ in several stages by specifying three DiffServ components:

- 1. Class
 - Creating and deleting classes.
 - Defining match criteria for a class.
- 2. Policy
 - Creating and deleting policies
 - Associating classes with a policy
 - Defining policy statements for a policy/class combination
- 3. Service
 - Adding and removing a policy to/from an inbound interface

The DiffServ class defines the packet filtering criteria. The attributes of a DiffServ policy define the way the switch processes packets. You can define policy attributes on a perclass instance basis. The switch applies these attributes when a match occurs.

Packet processing begins when the switch tests the match criteria for a packet. The switch applies a policy to a packet when it finds a class match within that policy.

The following rules apply when you create a DiffServ class:

- Each class can contain a maximum of one referenced (nested) class
- Class definitions do not support hierarchical service policies

A given class definition can contain a maximum of one reference to another class. You can combine the reference with other match criteria. The referenced class is truly a reference and not a copy since additions to a referenced class affect all classes that reference it. Changes to any class definition currently referenced by any other class must result in valid class definitions for all derived classes, otherwise the switch rejects the change. You can remove a class reference from a class definition.

The only way to remove an individual match criterion from an existing class definition is to delete the class and re-create it.



Note: The mark possibilities for policing include CoS, IP DSCP, and IP Precedence. While the latter two are only meaningful for IP packet types, CoS marking is allowed for both IP and non-IP packets, since it updates the 802.1p user priority field contained in the VLAN tag of the layer 2 packet header.

14.2.1 diffserv

This command sets the DiffServ operational mode to active. While disabled, the DiffServ configuration is retained and can be changed, but it is not activated. When enabled, Diffserv services are activated.

Format	diffserv
Mode	Global Config

14.2.1.1 no diffserv

This command sets the DiffServ operational mode to inactive. While disabled, the DiffServ configuration is retained and can be changed, but it is not activated. When enabled, Diffserv services are activated.

Format	no diffserv
Mode	Global Config

14.3 DiffServ Class Commands (GSM7248 only)

Use the DiffServ class commands to define traffic classification. To classify traffic, you specify Behavior Aggregate (BA), based on DSCP and Multi-Field (MF) classes of traffic (name, match criteria)

This set of commands consists of class creation/deletion and matching, with the class match commands specifying Layer 3, Layer 2, and general match criteria. The class match criteria are also known as class rules, with a class definition consisting of one or more rules to identify the traffic that belongs to the class.

Note: Once you create a class match criterion for a class, you cannot change or delete the criterion. To change or delete a class match criterion, you must delete and re-create the entire class.

The CLI command root is class-map.

14.3.1 class-map

This command defines a DiffServ class of type match-all. When used without any match condition, this command enters the class-map mode. The *<class-map-name>* is a case sensitive alphanumeric string from 1 to 31 characters uniquely identifying an existing DiffServ class.

Note: The class-map-name 'default' is reserved and must not be used.

The class type of match-all indicates all of the individual match conditions must be true for a packet to be considered a member of the class.

Note: The CLI mode is changed to Class-Map Config when this command is successfully executed.

Format	class-map match-all	<class-map-name></class-map-name>
Mode	Global Config	

14.3.1.1 no class-map

This command eliminates an existing DiffServ class. The *<class-map-name>* is the name of an existing DiffServ class (The class name 'default' is reserved and is not allowed here). This command may be issued at any time; if the class is currently referenced by one or more policies or by any other class, the delete action fails.

Format	no class-map <class-map-name></class-map-name>
Mode	Global Config

14.3.2 class-map rename

This command changes the name of a DiffServ class. The *<class-map-name>* is the name of an existing DiffServ class. The *<new-class-map-name>* parameter is a case-sensitive alphanumeric string from 1 to 31 characters uniquely identifying the class (The *<class-map-name>* 'default' is reserved and must not be used here).

 Format
 class-map rename <class-map-name> <new-class-map-name>

 name>
 Global Config

14.3.3 match ethertype

This command adds to the specified class definition a match condition based on the value of the ethertype. The <ethertype> value is specified as one of the following keywords: appletalk, arp, ibmsna, ipv4, ipv6, ipx, mplsmcast, mplsucast, netbios, novell, pppoe, rarp or as a custom ethertype value in the range of 0x0600-0xFFF.

Format	match ethertype { <keyword>/custom <0x0600-</keyword>
	0xFFFF>}
Mode	Class-Map Config

14.3.4 match any

This command adds to the specified class definition a match condition whereby all packets are considered to belong to the class.

Format	match any
Mode	Class-Map Config

14.3.5 match class-map

This command adds to the specified class definition the set of match conditions defined for another class. The *<refclassname>* is the name of an existing DiffServ class whose match conditions are being referenced by the specified class definition.

Format	match class-map	<refclassname></refclassname>
Mode	Class-Map Config	

The following ruules apply to this command:

- The parameters <refclassname> and <class-map-name> can not be the same.
- Only one other class may be referenced by a class.

- Any attempts to delete the <refclassname> class while the class is still referenced by any <class-map-name> fails.
- The combined match criteria of <*class-map-name*> and <*refclassname*> must be an allowed combination based on the class type.
- Any subsequent changes to the *<refclassname>* class match criteria must maintain this validity, or the change attempt fails.
- The total number of class rules formed by the complete reference class chain (including both predecessor and successor classes) must not exceed a platform-specific maximum. In some cases, each removal of a refclass rule reduces the maximum number of available rules in the class definition by one.

14.3.5.1 no match class-map

This command removes from the specified class definition the set of match conditions defined for another class. The *<refclassname>* is the name of an existing DiffServ class whose match conditions are being referenced by the specified class definition.

Format	<pre>no match class-map <refclassname></refclassname></pre>
Mode	Class-Map Config

14.3.6 match cos

This command adds to the specified class definition a match condition for the Class of Service value (the only tag in a single tagged packet or the first or outer 802.1Q tag of a double VLAN tagged packet). The value may be from 0 to 7.

Default	none
Format	match $\cos < 0.7 >$
Mode	Class-Map Config

14.3.7 match destination-address mac

This command adds to the specified class definition a match condition based on the destination MAC address of a packet. The <macaddr> parameter is any layer 2 MAC address formatted as six, two-digit hexadecimal numbers separated by colons (e.g., 00:11:22:dd:ee:ff). The <macmask> parameter is a layer 2 MAC address bit mask, which need not be contiguous, and is formatted as six, two-digit hexadecimal numbers separated by colons (e.g., ff:07:23:ff:fe:dc).

Default	none
Format	match destination-address mac $<\!macaddr\!><\!mac-mask\!>$
Mode	Class-Map Config

14.3.8 match dstip

This command adds to the specified class definition a match condition based on the destination IP address of a packet. The *<ipaddr>* parameter specifies an IP address. The *<ipmask>* parameter specifies an IP address bit mask and must consist of a contiguous set of leading 1 bits.

Format	<pre>match dstip <ipaddr> <ipmask></ipmask></ipaddr></pre>
Mode	Class-Map Config

14.3.9 match dstl4port

This command adds to the specified class definition a match condition based on the destination layer 4 port of a packet using a single keyword or numeric notation.

To specify the match condition as a single keyword, the value for <portkey> is one of the supported port name keywords. The currently supported <portkey> values are: domain, echo, ftp, ftpdata, http, smtp, snmp, telnet, tftp, www. Each of these translates into its equivalent port number. To specify the match condition using a numeric notation, one layer 4 port number is required. The port number is an integer from 0 to 65535.

Format	<pre>match dstl4port {portkey <0-65535>}</pre>
Mode	Class-Map Config

14.3.10 match ip dscp

This command adds to the specified class definition a match condition based on the value of the IP DiffServ Code Point (DSCP) field in a packet, which is defined as the high-order six bits of the Service Type octet in the IP header (the low-order two bits are not checked). The *<dscpval>* value is specified as either an integer from 0 to 63, or symbolically through one of the following keywords: af11, af12, af13, af21, af22, af23, af31, af32, af33, af41, af42, af43, be, cs0, cs1, cs2, cs3, cs4, cs5, cs6, cs7, ef.



Class-Map Config

14.3.11 match ip precedence

Mode

This command adds to the specified class definition a match condition based on the value of the IP Precedence field in a packet, which is defined as the high-order three bits of the Service Type octet in the IP header (the low-order five bits are not checked). The precedence value is an integer from 0 to 7.

	Note:	e: The ip dscp, ip precedence, and ip tos match conditions are alternative ways to specify a match criterion for the same Service Type field in the I header, but with a slightly different user notation.	
For	mat	<pre>match ip precedence <0-7></pre>	

Mode

match ip precedence <0-7>
Class-Map Config

14.3.12 match ip tos

This command adds to the specified class definition a match condition based on the value of the IP TOS field in a packet, which is defined as all eight bits of the Service Type octet in the IP header. The value of <tosbits> is a two-digit hexadecimal number from 00 to ff. The value of <tosmask> is a two-digit hexadecimal number from 00 to ff. The <tosmask> denotes the bit positions in <tosbits> that are used for comparison against the IP TOS field in a packet. For example, to check for an IP TOS value having bits 7 and 5 set and bit 1 clear, where bit 7 is most significant, use a <tosbits> value of a0 (hex) and a <tosmask> of a2 (hex).



	Note: This "free form" version of the IP DSCP/Precedence/TOS match specification gives the user complete control when specifying which bits of the IP Service Type field are checked.
_	

Format	match ip	tos	<tosbits></tosbits>	<tosmask></tosmask>
Mode	Class-Map	Con	fig	

14.3.13 match protocol

This command adds to the specified class definition a match condition based on the value of the IP Protocol field in a packet using a single keyword notation or a numeric value notation.

To specify the match condition using a single keyword notation, the value for <protocolname> is one of the supported protocol name keywords. The currently supported values are: icmp, igmp, ip, tcp, udp. A value of ip is matches all protocol number values.

To specify the match condition using a numeric value notation, the protocol number is a standard value assigned by IANA and is interpreted as an integer from 0 to 255.



Format	<pre>match protocol {protocol-name <0-</pre>	-255>}
Mode	Class-Map Config	

14.3.14 match source-address mac

This command adds to the specified class definition a match condition based on the source MAC address of a packet. The <address>parameter is any layer 2 MAC address formatted as six, two-digit hexadecimal numbers separated by colons (e.g., 00:11:22:dd:ee:ff). The <macmask> parameter is a layer 2 MAC address bit mask, which may not be contiguous, and is formatted as six, two-digit hexadecimal numbers separated by colons (e.g., ff:07:23:ff:fe:dc).

Default	none
Format	match source-address mac <address <macmask=""></address>
Mode	Class-Map Config

14.3.15 match srcip

This command adds to the specified class definition a match condition based on the source IP address of a packet. The *<ipaddr>* parameter specifies an IP address. The *<ipmask>* parameter specifies an IP address bit mask and must consist of a contiguous set of leading 1 bits.

Format	match srcip	<ipaddr></ipaddr>	<ipmask></ipmask>
Mode	Class-Map Con	nfig	

14.3.16 match srcl4port

This command adds to the specified class definition a match condition based on the source layer 4 port of a packet using a single keyword or numeric notation.

To specify the match condition as a single keyword notation, the value for *<portkey>* is one of the supported port name keywords (listed below).

The currently supported *<portkey>* values are: domain, echo, ftp, ftpdata, http, smtp, snmp, telnet, tftp, www. Each of these translates into its equivalent port number, which is used as both the start and end of a port range.

To specify the match condition as a numeric value, one layer 4 port number is required. The port number is an integer from 0 to 65535.

Format	<pre>match srcl4port {portkey <0-65535>}</pre>
Mode	Class-Map Config

14.3.17 match vlan

This command adds to the specified class definition a match condition based on the value of the layer 2 VLAN Identifier field (the only tag in a single tagged packet or the first or outer tag of a double VLAN tagged packet). The VLAN ID is an integer from 1 to 4095.

Default	none
Format	match vlan <1-4095>
Mode	Class-Map Config

14.4 DiffServ Policy Commands (GSM7248 only)

Use the DiffServ policy commands to specify traffic conditioning actions, such as policing and marking, to apply to traffic classes

Use the policy commands to associate a traffic class that you define by using the class command set with one or more QoS policy attributes. Assign the class/policy association to an interface to form a service. Specify the policy name when you create the policy.

Each traffic class defines a particular treatment for packets that match the class definition. You can associate multiple traffic classes with a single policy. When a packet satisfies the conditions of more than one class, preference is based on the order in which you add the classes to the policy. The first class you add has the highest precedence. This set of commands consists of policy creation/deletion, class addition/removal, and individual policy attributes.

Note: The only way to remove an individual policy attribute from a class instance within a policy is to remove the class instance and re-add it to the policy. The values associated with an existing policy attribute can be changed without removing the class instance.

The CLI command root is policy-map.

To enter "Config-policy-map" mode, use the **policy-map** policy-name> in command
from Global Config mode.

To enter "Config-policy-classmap" mode, use the **class** <*class-name*> command from "Config-policy-map" mode.

14.4.1 policy-map

This command establishes a new DiffServ policy. The *<policyname>* parameter is a casesensitive alphanumeric string from 1 to 31 characters uniquely identifying the policy. The type of policy is specific to the inbound traffic direction as indicated by the in parameter.

Note: The policy type dictates which of the individual policy attribute commands are valid within the policy definition.



Mode

policy-map <policyname> in
Global Config

14.4.1.1 no policy-map

This command eliminates an existing DiffServ policy. The *<policyname>* parameter is the name of an existing DiffServ policy. This command may be issued at any time. If the policy is currently referenced by one or more interface service attachments, this delete attempt fails.

Format	no policy-map	<policyname></policyname>
Mode	Global Config	

14.4.2 assign-queue

This command modifies the queue id to which the associated traffic stream is assigned. The queueid is an integer from 0 to n-1, where n is the number of egress queues supported by the device.

Format	assign-queue	<queueid></queueid>
Mode	Policy-Class-M	lap Config
Incompatibilities	Drop	

14.4.3 drop

This command specifies that all packets for the associated traffic stream are to be dropped at ingress.

Format	drop
Mode	Policy-Class-Map Config
Incompatibilities	Assign Queue, Mark (all forms), Police

14.4.4 conform-color

This command is used to enable color-aware traffic policing and define the conform-color class map. Used in conjunction with the police command where the fields for the conform level are specified. The *<class-map-name>* parameter is the name of an existing Diffserv class map.

Note: This command may only be used after specifying a police command for the policy-class instance.

Format	conform-color	<class-map-name></class-map-name>
Mode	Policy-Class-Ma	p Config

14.4.5 class

This command creates an instance of a class definition within the specified policy for the purpose of defining treatment of the traffic class through subsequent policy attribute statements. The *<classname>* is the name of an existing DiffServ class.

Note: This command causes the specified policy to create a reference to the class definition.

Note: The CLI mode is changed to Policy-Class-Map Config when this command is successfully executed.

Format Mode

 \rightarrow

class <classname> Policy-Map Config

14.4.5.1 no class

This command deletes the instance of a particular class and its defined treatment from the specified policy. *<classname>* is the names of an existing DiffServ class.

Note: This command removes the reference to the class definition for the specified policy.

Format	no class <classname></classname>
Mode	Policy-Map Config

14.4.6 mark cos

This command marks all packets for the associated traffic stream with the specified class of service value in the priority field of the 802.1p header (the only tag in a single tagged packet or the first or outer 802.1Q tag of a double VLAN tagged packet). If the packet does not already contain this header, one is inserted. The CoS value is an integer in the range of 0 to 7.

Default	1
Format	mark-cos <0-7>
Mode	Policy-Class-Map Config
Incompatibilities	Drop, Mark IP DSCP, IP Precedence, Police

14.4.7 mark ip-dscp

This command marks all packets for the associated traffic stream with the specified IP DSCP value.

The *<dscpva1>* value is specified as either an integer from 0 to 63, or symbolically through one of the following keywords: af11, af12, af13, af21, af22, af23, af31, af32, af33, af41, af42, af43, be, cs0, cs1, cs2, cs3, cs4, cs5, cs6, cs7, ef.

Format	<pre>mark ip-dscp <dscpval></dscpval></pre>
Mode	Policy-Class-Map Config
Incompatibilities	Drop, Mark CoS, Mark IP Precedence, Police

14.4.8 mark ip-precedence

This command marks all packets for the associated traffic stream with the specified IP Precedence value. The IP Precedence value is an integer from 0 to 7.

Format	mark ip-precedence <0-7>
Mode	Policy-Class-Map Config
Policy Type	In
Incompatibilities	Drop, Mark CoS, Mark IP DSCP, Police

14.4.9 police-simple

This command is used to establish the traffic policing style for the specified class. The simple form of the police command uses a single data rate and burst size, resulting in two outcomes: conform and violate. The conforming data rate is specified in kilobits-per-second (Kbps) and is an integer from 1 to 4294967295. The conforming burst size is specified in kilobytes (KB) and is an integer from 1 to 128.

For each outcome, the only possible actions are drop, set-cos-transmit, set-dscp-transmit, set-prec-transmit, or transmit. In this simple form of the police command, the conform action defaults to transmit and the violate action defaults to drop.

For set-dscp-transmit, a *<dscpval>* value is required and is specified as either an integer from 0 to 63, or symbolically through one of the following keywords: af11, af12, af13, af21, af22, af23, af31, af32, af33, af41, af42, af43, be, cs0, cs1, cs2, cs3, cs4, cs5, cs6, cs7, ef.

For set-prec-transmit, an IP Precedence value is required. It is an integer from 0-7.

For set-cos-transmit an 802.1p priority value is required. It is an integer from 0-7.

Format	<pre>police-simple {<1-4294967295> <1-128> conform- action {drop set-prec-transmit <0-7> set-dscp- transmit <0-63> set-cos-transmit <0-7> trans- mit} [violate-action {drop set-prec-transmit <0- 7> set-dscp-transmit <0-63> set-cos-transmit <0-7> transmit}]}</pre>	
Mode	Policy-Class-Map Config	
Incompatibilities	Drop, Mark (all forms)	

14.4.10 policy-map rename

This command changes the name of a DiffServ policy. The *<policyname>* is the name of an existing DiffServ class. The *<newpolicyname>* parameter is a case-sensitive alphanumeric string from 1 to 31 characters uniquely identifying the policy.

Formatpolicy-map rename <policyname> <newpolicyname>ModeGlobal Config

14.5 DiffServ Service Commands (GSM7248 only)

Use the DiffServ service commands to assign a DiffServ traffic conditioning policy, which you specified by using the policy commands, to an interface in the incoming direction

The service commands attach a defined policy to a directional interface. You can assign only one policy at any one time to an interface in the inbound direction. DiffServ is not used in the outbound direction.

This set of commands consists of service addition/removal.

The CLI command root is **service-policy**.

14.5.1 service-policy

This command attaches a policy to an interface in the inbound direction. The *<policyname>* parameter is the name of an existing DiffServ policy; it is defined by the **Policy-Map** command. This command causes a service to create a reference to the policy.

Note: This command effectively enables DiffServ on an interface in the inbound direction. There is no separate interface administrative 'mode' command for DiffServ.



Format	<pre>service-policy in <policyname></policyname></pre>
Modes	Global Config
	Interface Config



14.5.1.1 no service-policy

This command detaches a policy from an interface in the inbound direction. The *<policyname>* parameter is the name of an existing DiffServ policy; it is defined by the **Policy-Map** command.

Note: This command causes a service to remove its reference to the policy. This
command effectively disables DiffServ on an interface in the inbound
direction. There is no separate interface administrative 'mode' command
for DiffServ.

Format	<pre>no service-policy in <policyname></policyname></pre>
Modes	Global Config
	Interface Config

14.6 DiffServ Show Commands

Use the DiffServ show commands to display configuration and status information for classes, policies, and services. You can display DiffServ information in summary or detailed formats. The status information is only shown when the DiffServ administrative mode is enabled.

14.6.1 show class-map (GSM7248 only)

This command displays all configuration information for the specified class. The *<class-name>* is the name of an existing DiffServ class.

Format	<pre>show class-map <class-name></class-name></pre>
Modes	Privileged EXEC
	User EXEC

If the class-name is specified the following fields are displayed:

Class Name	The name of this class.
Class Type	A class type of 'all' means every match criterion defined for the class is evaluated simultaneously and must all be true to indicate a class match.
Match Criteria	The Match Criteria fields are only displayed if they have been configured. They are displayed in the order entered by the user. The fields are evaluated in accordance with the class type. The possible Match Criteria fields are: Destination IP Address, Destination Layer 4 Port, Every, IP DSCP, IP Prece- dence, IP TOS, Protocol Keyword, Reference Class, Source IP Address, and Source Layer 4 Port.
Values	This field displays the values of the Match Criteria.

If you do not specify the Class Name, this command displays a list of all defined DiffServ classes. The following fields are displayed:

Class Name	The name of this class. (Note that the order in which classes are displayed is not necessarily the same order in which they were created.)
Class Type	A class type of 'all' means every match criterion defined for the class is evaluated simultaneously and must all be true to indicate a class match.

Ref Class Name The name of an existing DiffServ class whose match conditions are being referenced by the specified class definition.

14.6.2 show diffserv

This command displays the DiffServ General Status Group information, which includes the current administrative mode setting as well as the current and maximum number of rows in each of the main DiffServ private MIB tables. This command takes no options.

Format	show diffserv
Mode	Privileged EXEC
DiffServ Admin mode	The current value of the DiffServ administrative mode.
Class Table Size	The current number of entries (rows) in the Class Table.
Class Table Max	The maximum allowed entries (rows) for the Class Table.
Class Rule Table Size	The current number of entries (rows) in the Class Rule Table.
Class Rule Table Max	The maximum allowed entries (rows) for the Class Rule Table.
Policy Table Size	The current number of entries (rows) in the Policy Table.
Policy Table Max	The maximum allowed entries (rows) for the Policy Table.
Policy Instance Table Size	Current number of entries (rows) in the Policy Instance Table.
Policy Instance Table Max	Maximum allowed entries (rows) for the Policy Instance Table.
Policy Attribute Table Size	Current number of entries (rows) in the Policy Attribute Table.
Policy Attribute Table Max	Maximum allowed entries (rows) for the Policy Attribute Table.
Service Table Size	The current number of entries (rows) in the Service Table.

Service Table	
Max	The maximum allowed entries (rows) for the Service Table.

14.6.3 show policy-map (GSM7248 only)

This command displays all configuration information for the specified policy. The *<policyname>* is the name of an existing DiffServ policy.

Format	show policy-map	[policyname]
Mode	Privileged EXEC	

If the Policy Name is specified the following fields are displayed:

Policy Name	The name of this policy.
Туре	The policy type (Only inbound policy definitions are supported for this platform.)

The following information is repeated for each class associated with this policy (only those policy attributes actually configured are displayed):

Assign Queue	Directs traffic stream to the specified QoS queue. This allows a traffic classifier to specify which one of the sup- ported hardware queues are used for handling packets belonging to the class.
Class Name	The name of this class.
Committed Burst Size (KB)	This field displays the committed burst size, used in simple policing.
Committed Rate (Kbps)	This field displays the committed rate, used in simple polic-
Conform Action	The current setting for the action taken on a packet consid- ered to conform to the policing parameters. This is not dis- played if policing is not in use for the class under this policy.
Conform COS	This field shows the CoS mark value if the conform action is set-cos-transmit.
Conform DSCP Value	This field shows the DSCP mark value if the conform action is set-dscp-transmit.

Conform IP	
Precedence	
Value	This field shows the IP Precedence mark value if the conform action is set-prec-transmit.
Drop	Drop a packet upon arrival. This is useful for emulating access control list operation using DiffServ, especially when DiffServ and ACL cannot co-exist on the same interface.
Mark CoS	Denotes the class of service value that is set in the 802.1p header of inbound packets. This is not displayed if the mark cos was not specified.
Mark IP DSCP	Denotes the mark/re-mark value used as the DSCP for traffic matching this class. This is not displayed if mark ip description is not specified.
Mark IP	
Precedence	Denotes the mark/re-mark value used as the IP Precedence for traffic matching this class. This is not displayed if mark ip precedence is not specified.
Non-Conform	
Action	The current setting for the action taken on a packet consid- ered to not conform to the policing parameters. This is not displayed if policing not in use for the class under this policy.
Non-Conform	
COS	This field displays the CoS mark value if the non-conform action is set-cos-transmit.
Non-Conform	
DSCP Value	This field displays the DSCP mark value if the non-conform action is set-dscp-transmit.
Non-Conform IP Precedence	
Value	This field displays the IP Precedence mark value if the non- conform action is set-prec-transmit.
Policing Style	This field denotes the style of policing, if any, used (simple).
Redirect	Forces a classified traffic stream to a specified egress port (physical port). This can occur in addition to any marking or policing action. It may also be specified along with a QoS queue assignment.

If the Policy Name is not specified this command displays a list of all defined DiffServ policies. The following fields are displayed:

Policy Name	The name of this policy. (The order in which the policies are displayed is not necessarily the same order in which they were created.)
Policy Type	The policy type (Only inbound is supported).
Class Members	List of all class names associated with this policy.

14.6.4 show diffserv service (GSM7248 only)

This command displays policy service information for the specified interface and direction. The *<unit/slot/port>* parameter specifies a valid unit/slot/port number for the system.

Format	<pre>show diffserv service <unit port="" slot=""> in</unit></pre>
Mode	Privileged EXEC
DiffServ Admin	
Mode	The current setting of the DiffServ administrative mode. An attached policy is only in effect on an interface while Diff-Serv is in an enabled mode.
Interface	Valid slot and port number separated by forward slashes.
Direction	The traffic direction of this interface service.
Operational	
Status	The current operational status of this DiffServ service interface.
Policy Name	The name of the policy attached to the interface in the indi- cated direction.
Policy Details	Attached policy details, whose content is identical to that described for the show policy-map <policymapname> command (content not repeated here for brevity).</policymapname>

14.6.5 show diffserv service brief (GSM7248 only)

This command displays all interfaces in the system to which a DiffServ policy has been attached. The inbound direction parameter is optional.

Format	show diffserv service brief [i	n]
Mode	Privileged EXEC	

DiffServ Mode	The current setting of the DiffServ administrative mode. An
	attached policy is only active on an interface while DiffServ
	is in an enabled mode.

The following information is repeated for interface and direction (only those interfaces configured with an attached policy are shown):

Interface	Valid slot and port number separated by forward slashes.
Direction	The traffic direction of this interface service.
OperStatus	The current operational status of this DiffServ service interface.
Policy Name	The name of the policy attached to the interface in the indicated direction.

14.6.6 show policy-map interface (GSM7248 only)

This command displays policy-oriented statistics information for the specified interface and direction. The *<unit/slot/port>* parameter specifies a valid interface for the system.

Note: This command is only allowed while the DiffServ administrative mode is enabled.

Format	<pre>show policy-map interface <unit port="" slot=""> [in]</unit></pre>
Mode	Privileged EXEC
Interface	Valid slot and port number separated by forward slashes.
Direction	The traffic direction of this interface service.
Operational Status	The current operational status of this DiffServ service inter- face.
Policy Name	The name of the policy attached to the interface in the indi- cated direction.

The following information is repeated for each class instance within this policy:

Class Name	The name of this class instance.
In Discarded	
Packets	A count of the packets discarded for this class instance for
	any reason due to DiffServ treatment of the traffic class.

14.6.7 show service-policy (GSM7248 only)

This command displays a summary of policy-oriented statistics information for all interfaces in the specified direction.

Format	show service-policy in
Mode	Privileged EXEC

The following information is repeated for each interface and direction (only those interfaces configured with an attached policy are shown):

Interface	Valid slot and port number separated by forward slashes.
Operational Status	The current operational status of this DiffServ service inter- face.
Policy Name	The name of the policy attached to the interface.

14.7 MAC Access Control List (ACL) Commands (GSM7248 only)

This section describes the commands you use to configure MAC ACL settings. MAC ACLs ensure that only authorized users have access to specific resources and block any unwarranted attempts to reach network resources.

The following rules apply to MAC ACLs:

- The maximum number of ACLs you create is 100, regardless of type.
- The system supports only Ethernet II frame types.
- The maximum number of rules per IP ACL is hardware dependent.
- If you configure an IP ACL on an interface, you cannot configure a MAC ACL on the same interface.

14.7.1 mac access-list extended

This command creates a MAC Access Control List (ACL) identified by <name>, consisting of classification fields defined for the Layer 2 header of an Ethernet frame. The <name> parameter is a case-sensitive alphanumeric string from 1 to 31 characters uniquely identifying the MAC access list.

If a MAC ACL by this name already exists, this command enters Mac-Access-List config mode to allow updating the existing MAC ACL.

Note: The CLI mode changes to Mac-Access-List Config mode when you successfully execute this command.

Formatmac access-list extended <name>ModeGlobal Config

14.7.1.1 no mac access-list extended

This command deletes a MAC ACL identified by <name> from the system.

Format	no mac access-list extended	<name></name>
Mode	Global Config	

14.7.2 mac access-list extended rename

This command changes the name of a MAC Access Control List (ACL). The *<name>* parameter is the name of an existing MAC ACL. The *<newname>* parameter is a case-sensitive alphanumeric string from 1 to 31 characters uniquely identifying the MAC access list.

This command fails if a MAC ACL by the name <newname> already exists.

Format	mac a	access-list	extended	rename	<name></name>	<newname></newname>
Mode	Globa	ıl Config				

14.7.3 {deny|permit}

This command creates a new rule for the current MAC access list. Each rule is appended to the list of configured rules for the list.

Note: The 'no' form of this command is not supported since the rules within a MAC ACL cannot be deleted individually. Instead, you must delete and respecify the entire MAC ACL.



 \rightarrow

Note: An implicit 'deny all' MAC rule always terminates the access list.

A rule may either deny or permit traffic according to the specified classification fields. At a minimum, the source and destination MAC value must be specified, each of which may be substituted using the keyword any to indicate a match on any value in that field. The remaining command parameters are all optional, but the most frequently used parameters appear in the same relative order as shown in the command format.

You can specify the Ethertype value as either a keyword or a four-digit hexadecimal value from 0x0600-0xFFFF. The currently supported *<ethertypekey>* values are: appletalk, arp, ibmsna, ipv4, ipv6, ipx, mplsmcast, mplsucast, netbios, novell, pppoe, rarp. Each of these translates into its equivalent Ethertype value(s), as shown in Table 14-1.

Ethertype Keyword	Corresponding Value
appletalk	0x809B
arp	0x0806
ibmsna	0x80D5
ipv4	0x0800
ip∨6	0x86DD
ірх	0x8037
mplsmcast	0x8848
mplsucast	0x8847
netbios	0x8191
novell	0x8137, 0x8138
рррое	0x8863, 0x8864
rarp	0x8035

Table 14-1. Ethertype Keyword and 4-digit Hexadecimal Value

The vlan and cos parameters refer to the VLAN identifier and 802.1p user priority fields, respectively, of the VLAN tag. For packets containing a double VLAN tag, this is the first (or outer) tag.

The assign-queue parameter allows specification of a particular hardware queue for handling traffic that matches this rule. The allowed <queue-id> value is 0-(n-1), where n is the number of user configurable queues available for the hardware platform. The assign-queue parameters are only valid for a 'permit' rule.



Note: The special command form {deny|permit} any any is used to match all Ethernet layer 2 packets, and is the equivalent of the IP access list "match every" rule.

Format	{deny permit} { <srcmac> any} {<dstmac> any} [<ethertypekey> <0x0600-0xFFFF>] [vlan {eq <0- 4095>}] [cos <0-7>] [assign-queue <queue-id>]</queue-id></ethertypekey></dstmac></srcmac>
Mode	Mac-Access-List Config

14.7.4 mac access-group

This command attaches a specific MAC Access Control List (ACL) identified by *<name>* to an interface in a given direction. The *<name>* parameter must be the name of an existing MAC ACL.

An optional sequence number may be specified to indicate the order of this mac access list relative to other mac access lists already assigned to this interface and direction. A lower number indicates higher precedence order. If a sequence number is already in use for this interface and direction, the specified mac access list replaces the currently attached mac access list using that sequence number. If the sequence number is not specified for this command, a sequence number that is one greater than the highest sequence number currently in use for this interface and direction is used.

This command specified in 'Interface Config' mode only affects a single interface, whereas the 'Global Config' mode setting is applied to all interfaces. The 'Interface Config' mode command is only available on platforms that support independent per-port class of service queue configuration.

Format	<pre>mac access-group <name> in [sequence <1 4294967295>]</name></pre>	L —
Modes	Global Config	
	Interface Config	

14.7.4.1 no mac access-group

This command removes a MAC ACL identified by *<name>* from the interface in a given direction.

Format	<pre>no mac access-list <name> in</name></pre>
Modes	Global Config
	Interface Config

14.7.5 show mac access-lists

This command displays a MAC access list and all of the rules that are defined for the MAC ACL. The [name] parameter is used to identify a specific MAC ACL to display.

Format	<pre>show mac access-lists [name]</pre>
Mode	Privileged EXEC
Rule Number	The ordered rule number identifier defined within the MAC ACL.
Action	Displays the action associated with each rule. The possible values are Permit or Deny.
Source MAC Address	Displays the source MAC address for this rule.
Destination MAC Address	Displays the destination MAC address for this rule.
Ethertype	Displays the Ethertype keyword or custom value for this rule.
VLAN ID	Displays the VLAN identifier value or range for this rule.
COS	Displays the COS (802.1p) value for this rule.
Assign Queue	Displays the queue identifier to which packets matching this rule are assigned.
Redirect Interface	Displays the unit/slot/port to which packets matching this rule are forwarded.

14.8 IP Access Control List (ACL) Commands (GSM7248 only)

This section describes the commands you use to configure IP ACL settings. IP ACLs ensure that only authorized users have access to specific resources and block any unwarranted attempts to reach network resources.

The following rules apply to IP ACLs:

- The 7200 Series Managed Switch does not support IP ACL configuration for IP packet fragments.
- The maximum number of ACLs you can create is 100, regardless of type.
- The maximum number of rules per IP ACL is hardware dependent.
- If you configure a MAC ACL on an interface, you cannot configure an IP ACL on the same interface.

• Wildcard masking for ACLs operates differently from a subnet mask. A wildcard mask is in essence the inverse of a subnet mask. With a subnet mask, the mask has ones (1's) in the bit positions that are used for the network address, and has zeros (0's) for the bit positions that are not used. In contrast, a wildcard mask has (0's) in a bit position that must be checked. A '1' in a bit position of the ACL mask indicates the corresponding bit can be ignored.

14.8.1 access-list

This command creates an IP Access Control List (ACL) that is identified by the ACL number.

The IP ACL number is an integer from 1 to 99 for an IP standard ACL and from 100 to 199 for an IP extended ACL.

The IP ACL rule is specified with either a *permit or deny* action.

The protocol to filter for an IP ACL rule is specified by giving the protocol to be used like *icmp,igmp,ip,tcp,udp*.

The command specifies a source IP address and source mask for match condition of the IP ACL rule specified by the *srcip* and *srcmask* parameters.

The source layer 4 port match condition for the IP ACL rule is specified by the *port value* parameter. The range of values is from 0 to 65535.

The *<portvalue>* parameter uses a single keyword notation and currently has the values of *domain*, *echo*, *ftp*, *ftpdata*, *http*, *smtp*, *snmp*, *telnet*, *tftp*, and *www*. Each of these values translates into its equivalent port number, which is used as both the start and end of a port range.

The command specifies a destination IP address and destination mask for match condition of the IP ACL rule specified by the *dstip* and *dstmask* parameters.

The command specifies the TOS for an IP ACL rule depending on a match of precedence or DSCP values using the parameters *dscp*, *precedence*, *tos/tosmask*.

The command specifies the assign-queue which is the queue identifier to which packets matching this rule are assigned.

Default	none
IP Standard ACL:	
Format	<pre>access-list <1-99> {deny permit} {every <srcip></srcip></pre>
	<srcmask>} [assign-queue <queue-id>]</queue-id></srcmask>
Mode	Global Config

IP Extended ACL:	
Format	<pre>access-list <100-199> {deny permit} {every {{icmp igmp ip tcp udp <number>} <srcip> <srcmask>[{eq {<portkey> <portvalue>} <dstip> <dstmask> [{eq {<portkey> <portvalue>}] [prece- dence <precedence> tos <tos> <tosmask> dscp <dscp>] [assign-queue <queue-id>]</queue-id></dscp></tosmask></tos></precedence></portvalue></portkey></dstmask></dstip></portvalue></portkey></srcmask></srcip></number></pre>
Mode	Global Config

14.8.1.1 no access-list

This command deletes an IP ACL that is identified by the parameter <accesslistnumber> from the system.

Format	no access-list <accesslistnumber></accesslistnumber>
Mode	Global Config

14.8.2 ip access-group

This command attaches a specified IP ACL to one interface or to all interfaces.

An optional sequence number may be specified to indicate the order of this IP access list relative to other IP access lists already assigned to this interface and direction. A lower number indicates higher precedence order. If a sequence number is already in use for this interface and direction, the specified access list replaces the currently attached IP access list using that sequence number. If the sequence number is not specified for this command, a sequence number that is one greater than the highest sequence number currently in use for this interface and direction is used.

Default	none
Format	<pre>ip access-group <accesslistnumber> in [sequence <1-4294967295>]</accesslistnumber></pre>
Modes	Interface Config Global Config

14.8.2.1 no ip access-group

This command removes a specified IP ACL from an interface.

Default	none
Format	<pre>no ip access-group <accesslistnumber> in</accesslistnumber></pre>
Mode	Interface Config

14.8.3 show ip access-lists

This command displays an IP ACL <accesslistnumber> is the number used to identify the IP ACL.

Format	<pre>show ip access-lists <accesslistnumber></accesslistnumber></pre>
Mode	Privileged EXEC
Rule Number	This displays the number identifier for each rule that is defined for the IP ACL.
Action	This displays the action associated with each rule. The possible values are Permit or Deny.
Protocol	This displays the protocol to filter for this rule.
Source IP	
Address	This displays the source IP address for this rule.
Source IP Mask	This field displays the source IP Mask for this rule.
Source Ports	This field displays the source port for this rule.
Destination IP Address	This displays the destination IP address for this rule.
Destination IP	This field displays the destination IP Mask for this rule
Nask Destinction Dorts	This field displays the destination in Wask for this rule.
	This field displays the destination port for this rule.
Service Type Field Match	This field indicates whether an IP DSCP, IP Precedence, or IP TOS match condition is specified for this rule.
Service Type Field	
Value	This field indicates the value specified for the Service Type Field Match (IP DSCP, IP Precedence, or IP TOS).

14.8.4 show access-lists

This command displays IP ACLs and MAC access control lists information for a designated interface and direction.

Format	<pre>show access-lists interface <unit port="" slot=""> in</unit></pre>
Mode	Privileged EXEC
ACL Type	Type of access list (IP or MAC).

ACL ID	Access List name for a MAC access list or the numeric iden- tifier for an IP access list.
Sequence	
Number	An optional sequence number may be specified to indicate the order of this access list relative to other access lists already assigned to this interface and direction. A lower num- ber indicates higher precedence order. If a sequence number is already in use for this interface and direction, the specified access list replaces the currently attached access list using that sequence number. If the sequence number is not speci- fied by the user, a sequence number that is one greater than the highest sequence number currently in use for this inter- face and direction is used. Valid range is (1 to 4294967295).

Chapter 15 System Maintenance Commands

This section describes the system maintenance commands available in the 7200 Series Managed Switch CLI.

The System Maintenance Commands section includes the following subsections:

- Section 15.1 "System Information and Statistics Commands" on page 15-1
- Section 15.2 "System Utility Commands" on page 15-17
- Section 15.3 "Logging Commands" on page 15-22
- Section 15.4 "CLI Command Logging Command" on page 15-27
- Section 15.5 "Configuration Scripting Commands" on page 15-28

The commands in this section are in one of four functional groups:

- Show commands display switch settings, statistics, and other information.
- Configuration commands configure features and options of the switch. For every configuration command, there is a show command that displays the configuration setting.
- Copy commands transfer or save configuration and informational files to and from the switch.
- Clear commands clear some or all of the settings to factory defaults.

15.1 System Information and Statistics Commands

This section describes the commands you use to view information about system features, components, and configurations.

15.1.1 show arp switch

This command displays connectivity between the switch and other devices. The Address Resolution Protocol (ARP) cache identifies the MAC addresses of the IP stations communicating with the switch.

Format	show arp switch
Mode	Privileged EXEC
MAC Address	A unicast MAC address for which the switch has forwarding and/or filtering information. The format is 6 two-digit hexa- decimal numbers that are separated by colons, for example 01:23:45:67:89:AB
IP Address	The IP address assigned to each interface.
Interface	Valid slot and port number separated by forward slashes.

15.1.2 show eventlog

This command displays the event log, which contains error messages from the system. The event log is not cleared on a system reset. The [unit] is the switch identifier.

Format	<pre>show eventlog [unit]</pre>	
Mode	Privileged EXEC	
File	The file in which the event originated.	
Line	The line number of the event	
Task Id	The task ID of the event.	
Code	The event code.	
Time	The time this event occurred.	
Unit	The unit for the event.	

Note: Event log information is retained across a switch reset.

15.1.3 show hardware

This command displays inventory information for the switch.

Format	show hardware
Mode	Privileged EXEC
Switch	
-----------------------	--
Description	Text used to identify the product name of this switch.
Machine Type	Specifies the machine model as defined by the Vital Product Data.
Machine Model	Specifies the machine model as defined by the Vital Product Data.
Serial Number	The unique box serial number for this switch.
FRU Number	The field replaceable unit number.
Part Number	Manufacturing part number.
Maintenance Level	Indicates hardware changes that are significant to software.
Manufacturer	Manufacturer descriptor field.
Burned in MAC	-
Address	Universally assigned network address.
Software Version	The release.version.revision number of the code currently running on the switch.
Operating System	The operating system currently running on the switch.
Network Processing	
Device	The type of the processor microcode.
Additional	
Packages	This displays the additional packages incorporated into this system.

15.1.4 show interface

This command displays a summary of statistics for a specific interface or a count of all CPU traffic based upon the argument.

Format	<pre>show interface {<slot port=""> switchport ether- net}</slot></pre>
Mode	Privileged EXEC



Note: For information about the format and output for show interface ethernet, see Section 15.1.5 "show interface ethernet" on page 15-5.

	•
Packets Received Without Error	The total number of packets (including broadcast packets and multicast packets) received by the processor.
Packets Received With Error	The number of inbound packets that contained errors prevent- ing them from being deliverable to a higher-layer protocol.
Broadcast Packets Received	The total number of packets received that were directed to the broadcast address. Note that this does not include multicast packets.
Packets Transmitted Without Error	Total number of packets transmitted out the interface.
Transmit Packets Errors	Number of outbound packets that could not be transmitted because of errors.
Collisions Frames	Best estimate of the total number of collisions on this Ether- net segment.
Time Since Counters Last Cleared	Elapsed time, in days, hours, minutes, and seconds since the statistics for this port were last cleared.
If you use the switchport	parameter, the following information appears:

The display parameters, when the argument is *<slot/port>*, is as follows:

Packets Received Without Error	The total number of packets (including broadcast packets and multicast packets) received by the processor.
Broadcast Packets	
Received	The total number of packets received that were directed to the broadcast address. Note that this does not include multicast packets.
Packets Received	
With Error	The number of inbound packets that contained errors prevent- ing them from being deliverable to a higher-layer protocol.

Packets Transmitted Without Error	Total number of packets transmitted out the interface.
Broadcast Packets	
Transmitted	The total number of packets that higher-level protocols requested to be transmitted to the Broadcast address, includ- ing those that were discarded or not sent.
Transmit Packet Errors	The number of outbound packets that could not be transmit- ted because of errors.
Address Entries	
Currently In Use	The total number of Forwarding Database Address Table entries now active on the switch, including learned and static entries.
VI AN Entries	
Currently In Use	The number of VLAN entries presently occupying the VLAN table.
Time Since Counters Last	
Cleared	The elapsed time, in days, hours, minutes, and seconds since the statistics for this switch were last cleared.

15.1.5 show interface ethernet

This command displays detailed statistics for a specific interface or for all CPU traffic based upon the argument.

Format	<pre>show interface ethernet {<slot port=""> switchport}</slot></pre>
Mode	Privileged EXEC

The display parameters, when the argument is <*slot/port>*, are as follows:

nclud-
luding
S)
e of
ether-
ed

before and after a common interval. The result of this equation is the value Utilization which is the percent utilization of the Ethernet segment on a scale of 0 to 100 percent.

Packets Received < 64 Octets - The total number of packets (including bad packets) received that were < 64 octets in length (excluding framing bits but including FCS octets).

Packets Received 64 Octets - The total number of packets (including bad packets) received that were 64 octets in length (excluding framing bits but including FCS octets).

Packets Received 65-127 Octets - The total number of packets (including bad packets) received that were between 65 and 127 octets in length inclusive (excluding framing bits but including FCS octets).

Packets Received 128-255 Octets - The total number of packets (including bad packets) received that were between 128 and 255 octets in length inclusive (excluding framing bits but including FCS octets).

Packets Received 256-511 Octets - The total number of packets (including bad packets) received that were between 256 and 511 octets in length inclusive (excluding framing bits but including FCS octets).

Packets Received 512-1023 Octets - The total number of packets (including bad packets) received that were between 512 and 1023 octets in length inclusive (excluding framing bits but including FCS octets).

Packets Received 1024-1518 Octets - The total number of packets (including bad packets) received that were between 1024 and 1518 octets in length inclusive (excluding framing bits but including FCS octets).

Packets Received 1519-1522 Octets - The total number of packets (including bad packets) received that were between 1519 and 1522 octets in length inclusive (excluding framing bits but including FCS octets).

Packets Received > 1522 Octets - The total number of packets received that were longer than 1522 octets (excluding framing bits, but including FCS octets) and were otherwise well formed.

Packets Received Successfully	Total - The total number of packets received that were without errors.
	Unicast Packets Received - The number of subnetwork-uni- cast packets delivered to a higher-layer protocol.
	Multicast Packets Received - The total number of good packets received that were directed to a multicast address. Note that this number does not include packets directed to the broadcast address.
	Broadcast Packets Received - The total number of good packets received that were directed to the broadcast address. Note that this does not include multicast packets.
Packets Received	
with MAC Errors	Total - The total number of inbound packets that contained errors preventing them from being deliverable to a higher-layer protocol.
	Jabbers Received - The total number of packets received that were longer than 1518 octets (excluding framing bits, but including FCS octets), and had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error). Note that this definition of jabber is dif- ferent than the definition in IEEE-802.3 section 8.2.1.5 (10BASE5) and section 10.3.1.4 (10BASE2). These docu- ments define jabber as the condition where any packet exceeds 20 ms. The allowed range to detect jabber is between 20 ms and 150 ms.
	Fragments/Undersize Received - The total number of packets received that were less than 64 octets in length (excluding framing bits but including FCS octets).
	Alignment Errors - The total number of packets received that had a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, but had a bad Frame Check Sequence (FCS) with a non-integral num- ber of octets.
	Rx FCS Errors - The total number of packets received that had a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, but had a

bad Frame Check Sequence (FCS) with an integral number of octets

Overruns - The total number of frames discarded as this port was overloaded with incoming packets, and could not keep up with the inflow.

Received Packets Not Forwarded

Total - A count of valid frames received which were discarded (in other words, filtered) by the forwarding process.

Local Traffic Frames - The total number of frames dropped in the forwarding process because the destination address was located off of this port.

802.3x Pause Frames Received - A count of MAC Control frames received on this interface with an opcode indicating the PAUSE operation. This counter does not increment when the interface is operating in half-duplex mode.

Unacceptable Frame Type - The number of frames discarded from this port due to being an unacceptable frame type.

VLAN Membership Mismatch - The number of frames discarded on this port due to ingress filtering.

VLAN Viable Discards - The number of frames discarded on this port when a lookup on a particular VLAN occurs while that entry in the VLAN table is being modified, or if the VLAN has not been configured.

Multicast Tree Viable Discards - The number of frames discarded when a lookup in the multicast tree for a VLAN occurs while that tree is being modified.

Reserved Address Discards - The number of frames discarded that are destined to an IEEE 802.1 reserved address and are not supported by the system.

Broadcast Storm Recovery - The number of frames discarded that are destined for FF:FF:FF:FF:FF:FF when Broadcast Storm Recovery is enabled.

CFI Discards - The number of frames discarded that have CFI bit set and the addresses in RIF are in non-canonical format. **Upstream Threshold** - The number of frames discarded due to lack of cell descriptors available for that packet's priority level.

Packets	
Transmitted Octets	Total Bytes - The total number of octets of data (including those in bad packets) received on the network (excluding framing bits but including FCS octets). This object can be used as a reasonable estimate of Ethernet utilization. If greater precision is desired, the etherStatsPkts and etherStatsOctets objects should be sampled before and after a common interval
	Packets Transmitted 64 Octets - The total number of packets (including bad packets) received that were 64 octets in length (excluding framing bits but including FCS octets).
	Packets Transmitted 65-127 Octets - The total number of packets (including bad packets) received that were between 65 and 127 octets in length inclusive (excluding framing bits but including FCS octets).
	Packets Transmitted 128-255 Octets - The total number of packets (including bad packets) received that were between 128 and 255 octets in length inclusive (excluding framing bits but including FCS octets).
	Packets Transmitted 256-511 Octets - The total number of packets (including bad packets) received that were between 256 and 511 octets in length inclusive (excluding framing bits but including FCS octets).
	Packets Transmitted 512-1023 Octets - The total number of packets (including bad packets) received that were between 512 and 1023 octets in length inclusive (excluding framing bits but including FCS octets).
	Packets Transmitted 1024-1518 Octets - The total number of packets (including bad packets) received that were between 1024 and 1518 octets in length inclusive (excluding framing bits but including FCS octets).
	Packets Transmitted 1519-1522 Octets - The total number of packets (including bad packets) received that were between 1519 and 1522 octets in length inclusive (excluding framing bits but including FCS octets).

	Max Info - The maximum size of the Info (non-MAC) field that this port will receive or transmit.
Packets Transmitted	
Successfully	Total - The number of frames that have been transmitted by this port to its segment
	Unicast Packets Transmitted - The total number of packets that higher-level protocols requested be transmitted to a sub- network-unicast address, including those that were discarded or not sent.
	Multicast Packets Transmitted - The total number of packets that higher-level protocols requested be transmitted to a Multicast address, including those that were discarded or not sent.
	Broadcast Packets Transmitted - The total number of packets that higher-level protocols requested be transmitted to the Broadcast address, including those that were discarded or not sent.
Transmit Errors	Total Errors - The sum of Single, Multiple, and Excessive Collisions.
	Tx FCS Errors - The total number of packets transmitted that had a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, but had a bad Frame Check Sequence (FCS) with an integral number of octets
	Oversized - The total number of frames that exceeded the max permitted frame size. This counter has a max increment rate of 815 counts per sec. at 10 Mb/s.
	Underrun Errors - The total number of frames discarded because the transmit FIFO buffer became empty during frame transmission.
Transmit	
Discards	Total Discards - The sum of single collision frames dis- carded, multiple collision frames discarded, and excessive frames discarded.
	Single Collision Frames - A count of the number of successfully transmitted frames on a particular interface for which transmission is inhibited by exactly one collision.

	Multiple Collision Frames - A count of the number of suc-
	cessfully transmitted frames on a particular interface for
	which transmission is inhibited by more than one consion.
	Excessive Collisions - A count of frames for which transmis-
	sion on a particular interface fails due to excessive collisions.
	Port Membership - The number of frames discarded on
	egress for this port due to egress filtering being enabled.
	VLAN Viable Discards - The number of frames discarded
	on this port when a lookup on a particular VLAN occurs
	while that entry in the VLAN table is being modified, or if
	the VLAN has not been configured.
Protocol	
Statistics	BPDU's received - The count of BPDU's (Bridge Protocol Data Units) received in the spanning tree layer.
	BPDU's Transmitted - The count of BPDU's (Bridge Proto-
	col Data Units) transmitted from the spanning tree layer.
	802.3x Pause Frames Received - A count of MAC Control
	frames received on this interface with an opcode indicating
	the PAUSE operation. This counter does not increment when
	the interface is operating in half-duplex mode.
	GVRP PDU's Received - The count of GVRP PDU's
	received in the GARP layer.
	GVRP PDU's Transmitted - The count of GVRP PDU's
	transmitted from the GARP layer.
	GVRP Failed Registrations - The number of times
	attempted GVRP registrations could not be completed.
	GMRP PDU's received - The count of GMRP PDU's
	received in the GARP layer.
	GMRP PDU's Transmitted - The count of GMRP PDU's
	transmitted from the GARP layer.
	GMRP Failed Registrations - The number of times
	attempted GMRP registrations could not be completed.
	STP BPDUs Transmitted - Spanning Tree Protocol Bridge
	Protocol Data Units sent
	STP BPDUs Received - Spanning Tree Protocol Bridge Pro-
	tocol Data Units received
	RST BPDUs Transmitted - Rapid Spanning Tree Protocol
	Bridge Protocol Data Units sent

Dot1x Statistics	 RSTP BPDUs Received - Rapid Spanning Tree Protocol Bridge Protocol Data Units received MSTP BPDUs Transmitted - Multiple Spanning Tree Protocol Bridge Protocol Data Units sent MSTP BPDUs Received - Multiple Spanning Tree Protocol Bridge Protocol Data Units received EAPOL Frames Received - The number of valid EAPOL frames of any type that have been received by this authentica- tor. EAPOL Frames Transmitted - The number of EAPOL frames of any type that have been transmitted by this authen- 	
	ticator.	
Time Since Counters Last Cleared	The elapsed time, in days, hours, minutes, and seconds since the statistics for this port were last cleared.	
If you specify the <i>switchport</i> value, the following information appears:		
	Octets Received - The total number of octets of data received by the processor (excluding framing bits but including FCS octets).	
	Total Packets Received Without Error - The total number of packets (including broadcast packets and multicast pack- ets) received by the processor.	
	Unicast Packets Received - The number of subnetwork-uni- cast packets delivered to a higher-layer protocol.	
	Multicast Packets Received - The total number of packets received that were directed to a multicast address. Note that this number does not include packets directed to the broadcast address.	
	Broadcast Packets Received - The total number of packets received that were directed to the broadcast address. Note that this does not include multicast packets.	
	Receive Packets Discarded - The number of inbound packets which were chosen to be discarded even though no errors had been detected to prevent their being deliverable to a higher-layer protocol. A possible reason for discarding a packet could be to free up buffer space.	

Octets Transmitted - The total number of octets transmitted out of the interface, including framing characters.

Packets Transmitted without Errors - The total number of packets transmitted out of the interface.

Unicast Packets Transmitted - The total number of packets that higher-level protocols requested be transmitted to a subnetwork-unicast address, including those that were discarded or not sent.

Multicast Packets Transmitted - The total number of packets that higher-level protocols requested be transmitted to a Multicast address, including those that were discarded or not sent.

Broadcast Packets Transmitted - The total number of packets that higher-level protocols requested be transmitted to the Broadcast address, including those that were discarded or not sent.

Transmit Packets Discarded - The number of outbound packets which were chosen to be discarded even though no errors had been detected to prevent their being deliverable to a higher-layer protocol. A possible reason for discarding a packet could be to free up buffer space.

Most Address Entries Ever Used - The highest number of Forwarding Database Address Table entries that have been learned by this switch since the most recent reboot.

Address Entries in Use - The number of Learned and static entries in the Forwarding Database Address Table for this switch.

Maximum VLAN Entries - The maximum number of Virtual LANs (VLANs) allowed on this switch.

Most VLAN Entries Ever Used - The largest number of VLANs that have been active on this switch since the last reboot.

Static VLAN Entries - The number of presently active VLAN entries on this switch that have been created statically.

Dynamic VLAN Entries - The number of presently active VLAN entries on this switch that have been created by GVRP registration.

	have been created and then deleted since the last reboot.
Time Since	
Counters Last	
Cleared	The elapsed time, in days, hours, minutes, and seconds, since
	the statistics for this switch were last cleared.

VLAN Deletes - The number of VLANs on this switch that

15.1.6 show logging

This command displays the trap log that the switch maintains. The trap log contains a maximum of 256 entries that wrap.

Note: Trap log information is not retained across a switch reset.

Format	show logging		
Mode	Privileged EXEC		
Number of Traps since last reset	The number of traps that have occurred since the last reset.		
Number of Traps since log last			
displayed	The number of traps that have occurred since the traps were last displayed. Getting the traps by any method (terminal interface display, Web display, upload file from switch etc.) sets the counter to 0.		
Log	The sequence number of this trap.		
System Up Time	The relative time since the last reboot of the switch at which this trap occurred.		
Trap	The relevant information of this trap.		

15.1.7 show mac-addr-table

This command displays the forwarding database entries. If the command is entered with no parameter, the entire table is displayed. This is the same as entering the optional all parameter. Alternatively, the administrator can enter a MAC Address to display the table entry for the requested MAC address and all entries following the requested MAC address.

Format	<pre>show mac-addr-table [<macaddr> all]</macaddr></pre>
Mode	Privileged EXEC
Mac Address	A unicast MAC address for which the switch has forwarding and or filtering information. The format is 6 or 8 two-digit hexadecimal numbers that are separated by colons, for exam- ple 01:23:45:67:89:AB. In an IVL system the MAC address will be displayed as 8 bytes.
Interface	The port which this address was learned.
Interface Index	This object indicates the ifIndex of the interface table entry associated with this port.
Status	The status of this entry. The meanings of the values are:
Static	The value of the corresponding instance was added by the system or a user when a static MAC filter was defined. It cannot be relearned.
Learned	The value of the corresponding instance was learned by observing the source MAC addresses of incoming traffic, and is currently in use.
Management	The value of the corresponding instance (system MAC address) is also the value of an existing instance of dot1dStaticAddress. It is identified with port number one and is currently used when enabling VLANs for routing.
Self	The value of the corresponding instance is the address of one of the switch's physical interfaces (the system's own MAC address).
GMRP Learned	The value was learned via GMRP and applies to Multicast.
Other	The value of the instance does not fall into one of the other categories.

15.1.8 clear mac-addr-table

This command clears the dynamically learned MAC addresses of the switch.

Format	clear mac-addr-table
Mode	Privileged EXEC

15.1.9 show running-config

Use this command to display/capture the current setting of different protocol packages supported on the switch. This command displays/captures commands with settings/ configurations that differ from the default value. To display/capture the commands with settings/configurations that are equal to the default value, include the [all] option.

The output is displayed in script format, which can be used to configure another switch with the same configuration. If the optional *<scriptname>* is provided with a file name extension of ".scr", the output is redirected to a script file.

If option *<changed>* is used, this command displays/capture commands with settings/ configurations that differ from the defaul value.

Format	<pre>show running-config [a.</pre>	11 /	<scriptname></scriptname>	/	changed]
Mode	Privileged EXEC				

15.1.10 terminal length

This command controls the number of lines to be displayed when running the **show** running-config command.

Format	terminal length $<\!l$ -24>
Mode	Privileged EXEC

15.1.10.1 terminal no length

This command resets the number of lines displayed when running the **show running-config** command to the default value (18).

Format	terminal no length
Mode	Privileged EXEC

15.1.11 show sysinfo

This command displays switch information.

Format	show sysinfo
Mode	Privileged EXEC
Switch	
Description	Text used to identify this switch.

System Name	Name used to identify the switch. The factory default is blank. To configure the system name, see Section 10.1.1 "snmp- server" on page 10-1.
System Location	Text used to identify the location of the switch. The factory default is blank. To configure the system location, see Section 10.1.1 "snmp-server" on page 10-1.
System Contact	Text used to identify a contact person for this switch. The fac- tory default is blank. To configure the system location, see Section 10.1.1 "snmp-server" on page 10-1.
System ObjectID	The base object ID for the switch's enterprise MIB.
System Up Time	The time in days, hours and minutes since the last switch reboot.
MIBs Supported	A list of MIBs supported by this agent.

15.2 System Utility Commands

This section describes the commands you use to help troubleshoot connectivity issues and to restore various configurations to their factory defaults.

15.2.1 traceroute

Use the traceroute command to discover the routes that packets actually take when traveling to their destination through the network on a hop-by-hop basis. The *ipaddr>* value should be a valid IP address. The [port] value should be a valid decimal integer in the range of 0(zero) to 65535. The default value is 33434.

The optional port parameter is the UDP port used as the destination of packets sent as part of the traceroute. This port should be an unused port on the destination system.

Format	traceroute	<ipaddr></ipaddr>	[port]
Mode	Privileged E	XEC	

15.2.2 clear config

This command resets the configuration to the factory defaults without powering off the switch. When you issue this command, a prompt appears to confirm that the reset should proceed. When you enter y, you automatically reset the switch.

Format	clear config
Mode	Privileged EXEC

15.2.3 clear counters

This command clears the statistics for a specified *<slot/port>*, for all the ports, or for the entire switch based upon the argument.

Format	<pre>clear counters {<slot port=""> all}</slot></pre>
Mode	Privileged EXEC

15.2.4 clear igmpsnooping

This command clears the tables managed by the IGMP Snooping function and attempts to delete these entries from the Multicast Forwarding Database.

Format	clear igmpsnooping
Mode	Privileged EXEC

15.2.5 clear pass

This command resets all user passwords to the factory defaults without powering off the switch. You are prompted to confirm that the password reset should proceed.

Format	clear pass
Mode	Privileged EXEC

15.2.6 enable passwd

This command prompts you to change the Privileged EXEC password.

Format	enable passwd
Mode	User EXEC

15.2.7 clear port-channel

This command clears all por	rt-channels (LAGs).
-----------------------------	---------------------

Format	clear port-channel
Mode	Privileged EXEC

15.2.8 clear traplog

This command clears the trap log.

Format	clear traplog
Mode	Privileged EXEC

15.2.9 clear vlan

This command resets VLAN configuration parameters to the factory defaults.

Format	clear vlan
Mode	Privileged EXEC

15.2.10 copy

The **copy** command uploads and downloads files to and from the switch. You can upload and download files from a server by using TFTP, Xmodem, Ymodem, or Zmodem.

Format	<pre>copy <source/></pre>	<destination></destination>
Mode	Global Config	

Replace the *<source>* and *<destination>* parameters with the options in Table 15-1. For the *<url>* source or destination, use one of the following values:

```
xmodem | ymodem | zmodem | tftp://<ipaddr>/<filepath>/<filename>
```

For TFTP, the <*ipaddr*> parameter is the IP address of the server, <*filepath*> is the path to the file, and <*filename*> is the name of the file you want to upload or download.

Table 15-1. Copy Parameters

Source	Destination	Description
nvram:clibanner	<url></url>	Copies the CLI banner to a server.
nvram:errorlog	<url></url>	Copies the error log file to a server.
nvram:log	<url></url>	Copies the log file to a server.
nvram:script <scriptname></scriptname>	<url></url>	Copies a specified configuration script file to a server.

Source	Destination	Description
nvram:startup-config	<url></url>	Copies the startup configuration to a server.
nvram:traplog	<url></url>	Copies the trap log file to a server.
system:running-config	nvram:startup-config	Saves the running configuration to nvram.
<url></url>	nvram:clibanner	Downloads the CLI banner to the system.
<url></url>	nvram:script <destfilename></destfilename>	Downloads a configuration script file to the system. During the download of a configuration script, the copy command validates the script. In case of any error, the command lists all the lines at the end of the validation process and prompts you to confirm before copying the script file.
<url></url>	nvram:sshkeydsa	Downloads an SSH key file. For more information, see Section 3.5 "Secure Shell (SSH) Command" on page 3-15.
<url></url>	nvram:sshkeyrsal	Downloads an SSH key file.
<url></url>	nvram:sshkeyrsal	Downloads an SSH key file.
<url></url>	nvram:sslpemroot	Downloads an HTTP secure-server certificate. For more information, see Section 3.6 "Hypertext Transfer Protocol (HTTP) Commands" on page 3-17.
<url></url>	nvram:sslpemserver	Downloads an HTTP secure-server certificate.
<url></url>	nvram:sslpemdhweak	Downloads an HTTP secure-server certificate.
<url></url>	nvram:sslpemdhstron g	Downloads an HTTP secure-server certificate.
<url></url>	nvram:startup-config	Downloads the startup configuration file to the system.
<url></url>	system:image	Downloads a code image to the system.

Table 15-1. Copy Parameters (continued)

15.2.11 logout

This command closes the current telnet connection or resets the current serial connection.

Note: Save configuration changes before logging out.

Format	logout
Mode	Privileged EXEC

15.2.12 ping

This command checks if another computer is on the network and listens for connections. To use this command, configure the switch for network (in-band) connection. The source and target devices must have the ping utility enabled and running on top of TCP/IP. You can ping the switch from any IP workstation the switch is connected to through the default VLAN (VLAN 1), as long as there is a physical path between the switch and the workstation. The terminal interface sends three pings to the target station.

Format	<pre>ping <ipaddr></ipaddr></pre>
Modes	Privileged EXEC, User EXEC

15.2.13 reload

This command resets the switch without powering it off. Reset means that all network connections are terminated and the boot code executes. The switch uses the stored configuration to initialize the switch. You are prompted to confirm that the reset should proceed. The LEDs on the switch indicate a successful reset.

Format	reload
Mode	Privileged EXEC

15.3 Logging Commands

This section describes the commands you use to configure system logging, and to view logs and the logging settings.

15.3.1 logging buffered

This command enables logging to an in-memory log that keeps up to 128 logs.

Default	disabled; critical
Format	logging buffered
Mode	Global Config

15.3.1.1 no logging buffered

This command disables logging to in-memory log.

Format	no logging buffered
Mode	Global Config

15.3.2 logging buffered wrap

This command enables wrapping of in-memory logging when the log file reaches full capacity. Otherwise when the log file reaches full capacity, logging stops.

Default	enabled
Format	logging buffered wrap
Mode	Privileged EXEC

15.3.2.1 no logging wrap

This command disables wrapping of in-memory logging and configures logging to stop when the log file capacity is full.

Format	no	logging	buffered	wrap
Mode	Priv	vileged E	XEC	

15.3.3 logging console

This command enables logging to the console. You can specify the *severitylevel>* value as either an integer from 0 to 7 or symbolically through one of the following keywords: emergency (0), alert (1), critical (2), error (3), warning (4), notice (5), informational (6), or debug (7).

Default	disabled; critical
Format	logging console [severitylevel]
Mode	Global Config

15.3.3.1 no logging console

This command disables logging to the console.

Format	no logging console
Mode	Global Config

15.3.4 logging host

This command enables logging to a host. You can configure up to eight hosts. The <*ipaddr>* is the IP address of the logging host. The <*port>* value is a port number from 1 to 65535. You can specify the <*severitylevel>* value as either an integer from 0 to 7 or symbolically through one of the following keywords: emergency (0), alert (1), critical (2), error (3), warning (4), notice (5), informational (6), or debug (7).

Default	port - 514; level - critical;
Format	<pre>logging host <ipaddr> [<port>][<severitylevel>]</severitylevel></port></ipaddr></pre>
Mode	Global Config

15.3.5 logging host remove

This command disables logging to host. See Section 15.3.11 "show logging hosts" on page 15-26 for a list of host indexes.

Format	logging host remove	<hostindex></hostindex>
Mode	Global Config	

15.3.6 logging port

This command sets the local port number of the LOG client for logging messages. The *<portid>* can be in the range from 1 to 65535.

Default	514
Format	<pre>logging port <portid></portid></pre>
Mode	Global Config

15.3.6.1 no logging port

This command resets the local logging port to the default.

Format	no logging port
Mode	Global Config

15.3.7 logging syslog

This command enables syslog logging.

Default	disabled; local0
Format	logging syslog
Mode	Global Config

15.3.7.1 no logging syslog

This command disables syslog logging.

Format	no logging syslog
Mode	Global Config

15.3.8 show logging

This command displays logging.

Format	show logging
Mode	Privileged EXEC
Client Local Port	The port on the collector/relay to which syslog messages are sent.
Console Logging Administrative Mode	The mode for console logging.

Console Logging Severity Filter	The minimum severity to log to the console log. Messages with an equal or lower numerical severity are logged.
Buffered Logging Administrative Mode	The mode for buffered logging.
Buffered Logging Severity Filter	The minimum severity to log to the buffered log. Messages with an equal or lower numerical severity are logged.
Historical Logging Administrative Mode	The mode for historical logging.
Historical Logging Severity Filter	The minimum severity to log to the historical log. Messages with an equal or lower numerical severity are logged.
Syslog Logging Administrative Mode	The mode for logging to configured syslog hosts. If set to disable logging stops to all syslog hosts.
Log Messages Received	The number of messages received by the log process. This includes messages that are dropped or ignored
Log Messages Dropped	The number of messages that could not be processed.

15.3.9 show logging buffered

This command displays buffered logging (system startup and system operation logs).

Format	show logging buffered
Mode	Privileged EXEC
Admin Status	The current state of the in-memory log.
Component Filter	The component(s) from which received messages are to be logged to the in memory log. Either a single component id or "all components" may be specified.
Wrapping	
Behavior	The behavior of the In Memory log when faced with a log full situation.
Log Count	The count of valid entries in the buffered log.

15.3.10 clear logging buffered

This command clears the messages maintained in the system log.

Format	clear logging buffered
Mode	Privileged EXEC

15.3.11 show logging hosts

This command displays all configured logging hosts.

Format	show logging hosts
Mode	Privileged EXEC
Host Index	(Used for deleting hosts)
Severity Level	The minimum severity to log to the specified address.
Port	Displays the server port number, which is the port on the local host from which syslog messages are sent.
Host Status	The state of logging to configured syslog hosts. If the status is disable, no logging occurs.

15.3.12 show logging traplogs

This command displays SNMP trap events and statistics.

Format	show logging traplogs
Mode	Privileged EXEC
Number of Traps Since Last Reset	Shows the number of traps since the last boot.
Trap Log Capacity	Shows the number of traps the system can retain.
Number of Traps Since Log Last	
Viewed	Shows the number of new traps since the command was last executed.
Log	Shows the log number.
System Time Up	Shows how long the system had been running at the time the trap was sent.
Тгар	Shows the text of the trap message.

15.4 CLI Command Logging Command

This section describes the commands you use to configure CLI Command Logging.

15.4.1 logging cli-command

This command enables the CLI command logging feature, which enables the 7200 Series Managed Switch software to log all CLI commands issued on the system.

Default	enabled
Format	logging cli-command
Mode	Global Config

15.4.1.1 no logging cli-command

This command disables the CLI command Logging feature.

Format	no logging cli-command
Mode	Global Config

15.5 Configuration Scripting Commands

Configuration Scripting allows you to generate text-formatted script files representing the current configuration of a system. You can upload these configuration script files to a PC or UNIX system and edit them. Then, you can download the edited files to the system and apply the new configuration. You can apply configuration scripts to one or more switches with no or minor modifications.

Use the show running-config command (see Section 15.1.9 "show running-config" on page 15-16) to capture the running configuration into a script. Use the copy command (see Section 15.2.10 "copy" on page 15-19) to transfer the configuration script to or from the switch.

You should use scripts on systems with default configuration; however, you are not prevented from applying scripts on systems with non-default configurations.

Scripts must conform to the following rules:

- Script files are not distributed across the stack, and only live in the unit that is the master unit at the time of the file download.
- The file extension must be ".scr".
- A maximum of ten scripts are allowed on the switch.
- The combined size of all script files on the switch shall not exceed 2048 KB.
- The maximum number of configuration file command lines is 2000.

You can type single-line annotations at the command prompt to use when you write test or configuration scripts to improve script readability. The exclamation point (!) character flags the beginning of a comment. The comment flag character can begin a word anywhere on the command line, and all input following this character is ignored. Any command line that begins with the "!" character is recognized as a comment line and ignored by the parser.

The following lines show an example of a script:

```
! Script file for displaying the ip interface
! Display information about interfaces
show ip interface 1/0/1 !Displays the information about the first
interface
! Display information about the next interface
show ip interface 1/0/2
! End of the script file
```

15.5.1 script apply

This command applies the commands in the script to the switch. The *scriptname* parameter is the name of the script to apply.

Format	<pre>script apply <scriptname></scriptname></pre>
Mode	Global Config

15.5.2 script delete

This command deletes a specified script where the *<scriptname>* parameter is the name of the script to delete. The *<all>* option deletes all the scripts present on the switch.

Format	<pre>script delete {<scriptname> a.</scriptname></pre>	11}
Mode	Global Config	

15.5.3 script list

This command lists all scripts present on the switch as well as the remaining available space.

Format	script list
Mode	Global Config
Configuration	
Script	Name of the script.
Size	Size of the script.

15.5.4 show script

This command displays the contents of a script file, which is named <scriptname>.

Format	<pre>show script <scriptname></scriptname></pre>		
Mode	Global Config		
Output Format	<pre>line <number>: <line contents=""></line></number></pre>		

15.5.5 script validate

This command validates a script file by parsing each line in the script file where <*scriptname>* is the name of the script to validate. The validate option is intended to be used as a tool for script development. Validation identifies potential problems. It might not identify all problems with a given script on any given device.

Formatscript validate <scriptname>ModeGlobal Config

15.6 Packet Capture

Packet capture commands assist in troubleshooting protocol-related problems with the management CPU. The packets to and from the management CPU can be captured in an internally allocated buffer area for export to a PC host for protocol analysis. Public domain packet analysis tools like Ethereal can be used to decode and review the packets in detail. Capturing can be performed in a variety of modes, either transmit-side only, receive-side only, or both. The number of packets captured will depend on the size of the captured packets.

15.6.1 capture transmit packet

This command enables the capturing of transmit packets.

Format	capture	transmit	packet
Mode	Global C	onfig	

15.6.1.1 no capture transmit packet

This command disables the capturing of transmit packets.

Format	no capture	transmit	packet
Mode	Global Conf	ig	

15.6.2 capture receive packet

This command enables the capturing of receive packets.

Format	capture receive packet
Mode	Global Config

15.6.2.1 no capture transmit packet

This command disables the capturing of transmit packets.

Format	no capture receive packet
Mode	Global Config

15.6.3 capture all packets

This command enables the capturing of both transmit and receive packets.

Format	capture all packets
Mode	Global Config

15.6.3.1 no capture all packets

This command disables the capturing of transmit and receive packets.

Format	no capture all packets
Mode	Global Config

15.6.4 capture wrap

This command enables the Buffer Wrapping configuration. Once the capture buffer is full, writes to the buffer will wrap around to allow continuous packet caputure.

Format	capture wrap
Mode	Global Config
Default	Enabled

15.6.4.1 no capture all packets

This command disables the Buffer Wrapping configuration.

Format	no capture wrap
Mode	Global Config

15.6.5 show capture packets

This command displays packets being captured from the buffer. The output of the show command can be redirected to a text file. The resultant text file can be fed to the **text2pcap** utility or the Ethereal public domain packet analyzer, which can then be translated to a cap file

Format	show capture packets
Mode	Global Config

15.7 Dumping System Information

The **show tech-support** command dumps all major system information into a file that can be sent to NETGEAR product support for debugging purposes. The command output is not displayed on the console. Use the **copy** command to transfer the dumped file to the host PC.

Format	show tech-support
Mode	Global Config

15.8 Setting the Output Length of show running-config

By default, the output of the **show running-config** command pauses after every 18 lines of output. If you do not want the output to pause or you want to change the number of lines displayed, the following commands are provided to control output behavior.

15.8.1 terminal length

This command specifies how many lines of output to display on the console before pausing. When the value of 0 is used, the output will not pause.

Format	terminal	length	<0-24>
Mode	Global Co	nfig	

15.8.2 terminal no length

This command resets the number of lines displayed by the **show running-config** command before pausing to the default value of 18.

Format	terminal no length
Mode	Global Config

Appendix A Command Changes from Release 3 to Release 5

The following table summarizes the release 3.x.x.x commands that are changed on rlease 5.x.x.x.

3.0.3.4 Command	5.0.1.9 (or newer) Equivalent Command
show igmpsnooping	show mac-address-table igmpsnooping
show ip brief	show ip
show ip interface brief	show ip interface
show ip ospf interface brief	show ip ospf interface
show ip ospf neighbor brief <unit port="" slot=""></unit>	show ip ospf neighbor <unit port="" slot=""></unit>
show ip ospf neighbor brief all	show ip ospf neighbor all
show ip ospf virtual-link brief	show ip ospf virtual-link
show ip vrrp interface brief	show ip vrrp interface
show monitor	show monitor session
shiow msglog	show logging buferred
show port-channel brief	show port-channel
show remotecon	show telnet
show service-policy	show service-policy in
show vlan brief	show vlan
copy nvram:msglog <url></url>	copy nvram:log <url></url>
remotecon maxsessions <0-5>	telnetcon maxsessions <0-5>
remotecon timeout <0-160>	telnetcon timeout <0-160>
vlan static <1-4094>	vlan makestatic
bootdhcprelay cidoptmode	ip dhcp relay information option
boothcprelay disable	no boothcprelay
set igmp	ip igmpsnooping
set igmp groupmembership-interval <2-3600>	ip igmpsnooping groupmembership-interval <2- 3600>
set igmp interfacemode all	ip igmpsnooping interfacemode all

3.0.3.4 Command	5.0.1.9 (or newer) Equivalent Command
set igmp maxresponse <1-3599>	ip igmpsnooping maxresponse <1-3599>
set igmp mctrexpiretime <0-3600>	ip igmpsnooping minresponse <1-3599>
snmp-server enable traps	snmp-server traps
snmp-server enable traps bcaststorm	snmp-server traps bcaststorm
snmp-server enable traps linkmode	snmp-server traps linkmode
snmp-server enable traps multiusers	snmp-server traps multiusers
snmp-server enable traps stpmode	snmp-server traps stpmode
speed all 1000 full-duplex	(replaced by interface range command)
set igmp	ip igmpsnooping