

Installation

NETGEAR®


AC1750 WiFi Cable Modem Router

Model C6300

Package Contents



Modem router



Ethernet cable



Power adapter


1. Connect a coaxial cable.

Use a coaxial cable that is provided by your cable company to connect the cable port on the modem router to a cable wall outlet or a line splitter.

Note: If Charter is your cable Internet provider, Charter recommends connecting your modem router directly to a cable wall outlet. If you must use a splitter, use a splitter that is rated at 3.5 dBmv.

2. Connect the power adapter.


Connect the power adapter to the modem router and plug the power adapter into an electrical outlet.

The Power LED  lights green. If the Power LED does not light, press the **Power On/Off** button.

3. Connect a computer to the modem router.

Use an Ethernet cable to connect a computer to the Ethernet port on the modem router.

You can also connect with WiFi. Use the WiFi network name and password on the product label.



4. Log in to the modem router.

Launch a web browser.
The modem router menu displays.

If you do not see the modem router menu, enter **http://routerlogin.net** or **http://192.168.0.1** in the address field of the web browser.
When prompted, enter **admin** for the user name and **password** for the password.

5. Set up your Internet service.

For information about how to set up your Internet service, see the other side of this installation guide.

6. Get the genie app.

Download the free genie app from www.NETGEAR.com/genie.

Easily share media, files, and printers on the network from your smartphone, tablet, or laptop.

Set Up Your Internet Service

1. Contact your cable Internet provider and inform them that you are installing a new modem router that you bought from a retail store.

Provide your cable Internet provider with the modem router's model number, which is C6300.

Note: The modem router is certified by all major cable Internet providers.

You can also visit your cable Internet provider's website and follow the onscreen instructions to set up your Internet service.

Cable Internet Provider	Contact Information
Cablevision	www.cablevision.com www.optimum.com/contactus.jsp
Charter	1-888-438-2427 https://install.charter.com
Comcast	1-800-COMCAST (1-800-266-2278) https://www.comcast.com/activate
Cox	1-877-891-2899 www.cox.com
Optimum	http://play.optimum.net https://www.optimum.net/support/phone-list
Time Warner Cable	1-800-892-2253 http://www.timewarnercable.com

Note: Your cable Internet provider's contact information might change. You can also find the contact number in your monthly Internet service billing statement.

2. When asked, provide the modem router's serial number and MAC address on the product label.
3. Wait for your cable Internet provider to confirm that your modem router is active.
4. If you do not have an Internet connection with the modem router, ask your cable Internet provider to look for your modem router online, then do one of the following depending on what your cable Internet provider tells you about your modem router:
 - If the modem router is not visible, your cable Internet provider can give you instructions to verify why the modem router does not connect with your high-speed Internet service.
 - If the modem router is visible to your cable Internet provider, reboot the modem router. Try checking your online status again.

Join the Modem Router's WiFi Network

To connect your computer or WiFi device (such as a smartphone or gaming device) to your modem router's WiFi network, you can use either the manual method or Wi-Fi Protected Setup (WPS) method.

Manual Method

1. Open the software utility that manages your WiFi connections on the computer or WiFi device that you want to connect to your modem router.

This utility scans for all wireless networks in your area.
2. Find and select your modem router's WiFi network name (SSID).

The SSID is on the product label.
3. Enter the modem router's password (or your custom password if you changed it) and click the **Connect** button.

The password is on the product label.
4. Repeat Step 1 through Step 3 to add other computers or WiFi devices.

WPS Method

If your computer or WiFi device supports WPS, you can use WPS to join the modem router's WiFi network. For help with the **WPS** button on your computer or WiFi device, check the instructions or online help that came with that computer or WiFi device. Some older equipment cannot use WPS.

Note: WPS does not support WEP security. If you are using WEP security, use the manual method.

1. Press the **WPS** button on the modem router.
2. Within two minutes, on your computer or WiFi device, press its **WPS** button or click its onscreen **WPS** button.

The WPS LED on the modem router lights solid green and the computer or WiFi device connects to your modem router.
3. Repeat this process to add other computers or WiFi devices.

Support

Thank you for purchasing this NETGEAR product. After installing your device, locate the serial number on the label of your product and use it to register your product at <https://my.netgear.com>.

You must register your product before you can use NETGEAR telephone support. NETGEAR recommends registering your product through the NETGEAR website. For product updates and web support, visit <http://support.netgear.com>. NETGEAR recommends that you use only the official NETGEAR support resources.

For regulatory compliance information, visit <http://www.netgear.com/about/regulatory/>. See the regulatory compliance document before connecting the power supply.

Customer-owned modem routers might not be compatible with certain cable networks. Check with your cable Internet provider to confirm this NETGEAR modem router is allowed on your cable network.

NETGEAR, the NETGEAR logo, and Connect with Innovation are trademarks and/or registered trademarks of NETGEAR, Inc. and/or its subsidiaries in the United States and/or other countries. Information is subject to change without notice. © NETGEAR, Inc. All rights reserved.



201-17081-02

March 2014

NETGEAR, Inc.
350 East Plumeria Drive
San Jose, CA 95134, USA