


To download the user manual, scan the QR code below or visit https://www.downloads.netgear.com/files/GDC/MR6400/MR6400_UM_EN.pdf.



What's in the box


- Nighthawk® M6 Pro 5G Mobile Router
- Battery cover
- Battery
- USB Type C cable
- AC adapter

Get to know your mobile router



Install the battery


1. Verify the SIM orientation as shown on the product label.
2. Insert the nano SIM card.
The nano SIM card must have an active data plan with your operator.



3. Insert the battery.
4. Install the back cover.
5. To charge the battery, connect the USB cable to the mobile router and then plug it into either:
 - A wall socket, using the AC adapter (faster charge option).
 - A USB port on your laptop.


Set up your mobile router

1. Press and hold the **Power** button for 2 seconds.




To better safeguard your network, the first time you turn on your mobile router, you are asked to set up your login credentials.

2. Follow the onscreen instructions to customize your mobile router settings.



LCD home screen

The home screen displays your mobile router's WiFi network name and password, and the mobile network signal strength and connection type.



Use the battery or AC power

This mobile router can operate on battery when you're away from your home or the office. The Power Manager settings allow you to further optimize battery life.

This mobile router can also operate without a battery using the supplied AC adapter. For extended periods on AC power, we recommend removing the battery to extend the battery life.

NETGEAR, Inc.
350 East Plumeria Drive
San Jose, CA 95134, USA



April 2022


© NETGEAR, Inc., NETGEAR and the NETGEAR Logo are trademarks of NETGEAR, Inc. Any non-NETGEAR trademarks are used for reference purposes only.

Connect to the Internet

The mobile router LCD screen goes dark to save power. A quick press and release of the **Power** button wakes the screen.

QR code connect from a smartphone

1. Tap the QR code icon on the mobile router's LCD home screen.



A QR code displays.

2. Point your phone's camera to the QR code.
Your phone connects to the mobile router WiFi network.

On your laptop or other WiFi-capable device

1. Open your WiFi network manager.
2. Find your mobile router's WiFi network name (NTGR_XXXX) and connect.
3. Enter your mobile router's WiFi password.


NOTE: To reduce power consumption and extend the battery life, this mobile router by default has **Ethernet** disabled. **2.5G Ethernet** port can only be enabled when the battery is removed. You can go to **Power Manager** to change to custom profile settings.

LCD WiFi Manager

You can manage the WiFi network and change the WiFi settings from the LCD screen.


Change the WiFi network name and password

1. On the home screen, tap the **WiFi** tile.



2. Tap **WiFi** and select an available WiFi network.
3. Tap **WiFi Name**, enter your changes, and tap **Done**.
4. Tap **WiFi Password**, enter your changes, and tap **Done**.

If your device is not connecting to this mobile router, we suggest enabling **Dual-Band (2.4 & 5 GHz)** in WiFi Band settings.




NOTE: To reduce power consumption and extend the battery life, this mobile router is default set to the WiFi **5 GHz Only** band.

LCD Settings

View or change the settings

On the home screen, tap the **Settings** tile.



From the Settings page, tap **Airplane Mode**, **Security**, **Mobile**, or **Screen** to view or change the settings. Tap **More** to view Device Information. Tap **Software** to check for software updates to ensure your device is always up to date.

Support and Community

From the Web Admin Portal home page, click the three-dot icon in the upper-right corner to access help and support files.

Direct all calls and support for PINs, SIM card registration, account and billing information, network services, and other general enquiries to Dish at 800-333-3474.

See your warranty card for warranty and service information.

For additional information, visit netgear.com/support to access the user manual and to download firmware updates.

You can also check out our NETGEAR Community for helpful advice at community.netgear.com.

Regulatory and Legal

For regulatory compliance information, visit <https://www.netgear.com/about/regulatory/>.

See the regulatory compliance document before connecting the power supply.

For NETGEAR's Privacy Policy, visit <https://www.netgear.com/about/privacy-policy>.


By using this device, you are agreeing to NETGEAR's Terms and Conditions at <https://www.netgear.com/about/terms-and-conditions>. If you do not agree, return the device to your place of purchase within your return period.

Web Admin Portal

You can use a web browser to view and change more advanced mobile router settings.

Log In

1. To find the URL for the Web Admin Portal, on your mobile router, tap **Settings > More > Device Information**.
The URL displays. It is either <http://mywebui.net> or <http://192.168.1.1>
2. On a WiFi-capable device that is connected to your mobile router, type the URL in the browser bar.
3. Log in as administrator.




NOTE: The default administrator login is printed on the mobile router label, which is inside the battery compartment.

Manage settings using the NETGEAR Mobile app



Use the NETGEAR Mobile app to change your WiFi network name and password. You can also use it to play and share media, and access advanced mobile router features.

1. Make sure your mobile device is connected to the Internet.
2. To download the NETGEAR Mobile app, scan a QR code below or visit netgear.com/mobileapps.



Android



iOS