

NETGEAR RangeMax™ 240 Wireless Notebook Adapter WPNT511

These setup instructions assume that you will connect to an access point or wireless router.
Estimated Completion 10 minutes.

Windows XP Installation

1. First, install the WPNT511 software.


Insert the NETGEAR CD. If the CD main page does not appear, double click **autorun.exe** on the CD.

- a. Click the **Install Software** link and the Smart Wizard starts.
- b. Follow the Wizard steps, and click **Next** to continue.
- c. When the Installation Complete message appears, click **Next**.



2. Now, insert the wireless notebook adapter.


When prompted, insert your wireless notebook adapter.



3. Use the Smart Wizard to set up your wireless notebook adapter.

- a. Choose to set up your wireless adapter either with the NETGEAR Smart Wizard (recommended) or the Windows configuration utility.

Note: If you choose the Windows Zero Configuration option, then you must read the Windows XP documentation for instructions.



- b. Click **Next** to accept the NETGEAR Smart Wizard.
- c. You will be prompted to let the wizard help you connect to a network (recommended).
- d. Click **Next** to accept.




- e. Select the wireless network from the drop-down list, and the wizard records your choice.

Note: Hidden networks do not broadcast the Network Name (SSID). These networks are included in the drop-down list, but the Network Name (SSID) is blank.

If the network uses security, then the Smart Wizard detects it.






- f. Follow the Wizard steps for Security (if used) and for saving a Profile.
- g. After you have reviewed the settings, click **Finish**.

The WPNT511 icon  appears in the system tray and on the desktop; and the Settings page opens. The wizard initiates your wireless connection. It could take up to a minute for your wireless connection to be established.

4. Use the status bar to verify your wireless connectivity.

The status bar is located at the bottom of the Settings page.



- The connection status indicator  and the WPNT511 icon  show the status of the connection.
- For details about the icons in the status bar, the WPNT511 LEDs, and troubleshooting tips, see the *User Manual* on the NETGEAR CD.
- The Internet/Router connection indicator shows the progress of your connection.



| Connection Indicator | Description |
|-------------------------------------|---|
| Connected to Internet | Wireless Internet connection OK. |
| Connected to Router | Wireless connection to router OK but no Internet connection at router. |
| ____.____.____.____ or 169.254..x.x | Wireless connection to a router OK but problem with the router. See the online help or <i>User Manual</i> for troubleshooting tips. |

Windows 2000 SP4 Installation

1. First, install the WPNT511 software.


Insert the NETGEAR CD. If the CD main page does not appear, double click **autorun.exe** on the CD.

- a. Click the **Install Software** link and the Smart Wizard starts.
- b. Follow the Wizard steps, and click **Next** to continue.
- c. When the Installation Complete message appears, click **Next**.



2. Now, insert the wireless notebook adapter.

When prompted, insert your wireless notebook adapter.



3. Use the Smart Wizard to set up your WPNT511.

- a. You will be prompted to let the wizard help you select a network (recommended).

Click **Next** to accept.




- b. Select the wireless network from the drop-down list, and the wizard records your choice.

Note: Hidden networks do not broadcast the Network Name (SSID). These networks are included in the drop-down list, but the Network Name (SSID) is blank.




If the network uses security, then the Smart Wizard detects it.



- c. Follow the Wizard steps for Security (if used) and for saving a Profile.
- d. After you have reviewed the settings, click **Finish**.

The WPNT511 icon  appears in the system tray and on the desktop; and the Settings page opens. The wizard initiates your wireless connection. It could take up to a minute for your wireless connection to be established.

4. Use the status bar to verify your wireless connectivity.

The status bar is located at the bottom of the Settings page.




- The connection status indicator  and the WPNT511 icon  show the status of the connection.
- For details about the icons in the status bar, the WPNT511 LEDs, and troubleshooting tips, see the *User Manual* on the NETGEAR CD.
- The Internet/Router connection indicator shows the progress of your connection.



| Connection Indicator | Description |
|------------------------------------|---|
| Connected to Internet | Wireless Internet connection OK. |
| Connected to Router | Wireless connection to router OK but no Internet connection at router. |
| _____._____._____. or 169.254..x.x | Wireless connection to a router OK but problem with the router. See the online help or <i>User Manual</i> for troubleshooting tips. |

Technical Support

Thank you for selecting NETGEAR products. After completing the Smart Wizard configuration assistant, locate the serial number on the bottom label of your product and use it to register your product at <http://www.NETGEAR.com/register>. Registration on the Web site or over the phone is required before you can use our telephone support service. The phone numbers for worldwide regional customer support centers are on the Warranty and Support Information card that came with your product. Go to <http://kbserver.netgear.com> for product updates and Web support.

 This symbol was placed in accordance with the European Union Directive 2002/96 on the Waste Electrical and Electronic Equipment (the WEEE Directive). If disposed of within the European Union, this product should be treated and recycled in accordance with the laws of your jurisdiction implementing the WEEE Directive.

© 2005 by NETGEAR, Inc. All rights reserved. NETGEAR is a registered trademark of NETGEAR, Inc. in the United States and/or other countries. Other brand and product names are trademarks or registered trademarks of their respective holders. Information is subject to change without notice.



201-10657-01

October 26, 2005