

N600 Wireless Dual Band Router WNDR3400v3

Package Contents



Ethernet cable



Power adapter



Router stand
(two pieces)




N600 Wireless Router
(with stand attached)

Attach the stand to the router:

1. Position the router so that the Power button is at the bottom and the USB port is at the top.
2. Snap each piece of the stand onto a bottom corner of the router.




Step 1:
Unplug the power
to turn off your modem.



Step 4:
Connect the power adapter to the
router, then plug it into an outlet.
Wait for the 2.4 GHz LED ()
to turn on.

If none of the LEDs light, make sure the
Power On/Off button is in the on position
(pushed in).

Step 2:
Connect one end of the yellow
Ethernet cable () to your modem, and
and the other end to the Internet port
on your router.



Step 5:
Connect your computer
to the router ().

Use another Ethernet cable to establish
a wired connection as shown in this diagram.

Optionally, connect wirelessly by using
the preset wireless security settings
located on the bottom label.

Step 3:
Plug in, then turn on your modem.



Wait approximately 2 minutes
until your modem turns on.

If your modem has a battery backup,
first remove and reinsert the battery
before connecting your
modem to power.


Step 6:
Open a browser.

If the web page doesn't display,
close and reopen the browser and
enter <http://routerlogin.net> in the
address bar. The user name and
password are on the product label.
You can also check the
“Troubleshooting” section on the
back of this installation guide.

Preset Wireless Security

This product has a unique WiFi network name (SSID) and network key (password). The default SSID and password are uniquely generated for every device (like a serial number), to protect and maximize your wireless security. This information is on the product label.

NETGEAR recommends that you do not change the preset SSID or password. If you do change the settings, the information on the product label does not apply.



Find the preset wireless settings on your router and record them here:

WiFi network name (SSID) _____

Network key (password) _____

If you change the preset wireless settings, record them here:

Wireless network name (SSID) _____

Network key (password) _____

If necessary to retrieve or update your password, type <http://www.routerlogin.net> in a web browser and log in using the default user name (**admin**) and password (**password**).

Select **Wireless Settings** to locate your wireless password.

Connect Wireless Devices to Your Router

Choose either the manual or Wi-Fi Protected Setup (WPS) method to add wireless computers and other devices to your wireless network.

Manual Method

1. Open the software utility that manages your wireless connections on the wireless device that you want to connect to your router (iPhone, laptop, computer, gaming device). This utility scans for all wireless networks in your area.
2. Look for the preset NETGEAR wireless network name (SSID), and select it. The preset SSID is on the product label on the bottom of the router.

Note: If you changed the name of your network during the setup process, look for that network name.

3. Enter the preset password (or your custom password if you changed it), and click **Connect**.
4. Repeat steps 1–3 to add other wireless devices.

WPS Method

If your wireless device supports WPS (Wi-Fi Protected Setup)—NETGEAR calls this method Push 'N' Connect—you might be prompted to press the WPS button on the router instead of entering a password. If you are prompted:

1. Press the **WPS** button on the router.
2. Within 2 minutes, press the **WPS** button on the client device, or follow the WPS instructions that came with your wireless device to complete the WPS process. The device is then connected to your router.
3. Repeat this process to add other WPS wireless devices.

Note: WPS does not support WEP security. If you try to connect a WEP client to your network using WPS, it does not work.

Troubleshooting

The browser cannot display the web page.

- Make sure that the computer is connected to one of the four LAN Ethernet ports, or wirelessly to the router.
- Make sure that the router has full power and that the WiFi LED is lit. Its wireless LED should turn on.
- Close and reopen the browser to make sure that the browser does not cache the previous page.
- Browse to <http://routerlogin.net>.
- If the computer is set to a static or fixed IP address (this is uncommon), change it to obtain an IP address automatically from the modem router.

After installing your device, locate the serial number on the label of your product and use it to register your product at <https://my.netgear.com>.

You must register your product before you can use NETGEAR telephone support. NETGEAR recommends registering your product through the NETGEAR website. For product updates and web support, visit <http://support.netgear.com>.

NETGEAR recommends that you use only the official NETGEAR support resources.

For the free Live Parental Controls centralized Internet site filtering software for your router, visit <http://www.netgear.com/lpc>.

For additional features, including traffic metering, ReadySHARE, guest access, and others, log in to your router at <http://www.routerlogin.net>.

You can get the user manual online at <http://downloadcenter.netgear.com> or through a link in the product's user interface.

For the current EU Declaration of Conformity, visit http://support.netgear.com/app/answers/detail/a_id/11621/.

NETGEAR, the NETGEAR logo, and Connect with Innovation are trademarks and/or registered trademarks of NETGEAR, Inc. and/or its subsidiaries in the United States and/or other countries. Information is subject to change without notice. © NETGEAR, Inc. All rights reserved. Intended for indoor use only in all EU member states, EFTA states, and Switzerland.



201-16616-04

December 2012