

Installation

NETGEAR ProSAFE Dual Band Wireless AC

Access Point

WAC720

WAC730



Package Contents

Unpack the box and verify the contents:

- ProSAFE Dual Band Wireless AC Access Point
- Category 5e Ethernet cable
- Ceiling mount kit

Set Up the Access Point

Before mounting the access point in a high location, first set up and test the unit to verify wireless network connectivity.

Note: The access point uses a DHCP client that is enabled by default. If a DHCP server exists in your network, the access point obtains an IP address from the DHCP server. If a DHCP server is not detected in your network, the access point sets its IP address to a static IP address of 192.168.0.100.

➤ To cable your access point:

1. If a DHCP server is not connected to your network, configure a computer with a static IP address of 192.168.0.210 and a subnet mask of 255.255.255.0.
2. Connect an Ethernet cable from a LAN port on the access point to a LAN port on a PoE switch.



3. Connect an Ethernet cable from the PoE switch to a Ethernet port on the computer.
4. Check the LEDs to verify that the access point is set up correctly.

LED	Description
 Power LED	<ul style="list-style-type: none">•Off. Power is off.•Solid green. Power is on.•Amber, then blinking green. A self-test is running or software is being loaded. During startup, the LED is first steady amber, then goes off, and then blinks green before turning steady green after about 45 seconds. If after one minute the LED remains amber or continues to blink green, it indicates a system fault.

LED	Description
 Activity LED	<ul style="list-style-type: none">•Off. No link is detected.•Blinking green. There is network traffic through the access point.
 LAN port LED	<ul style="list-style-type: none">•Off. 10 Mbps link is detected or no link is detected.•Solid green. 1000 Mbps link is detected.•Solid amber. 100 Mbps link is detected.
 2.4G WLAN LED	<ul style="list-style-type: none">•Off. The wireless interface is off.•Solid green. The wireless interface is on.•Blinking green. Wireless activity is detected on the 2.4G band.
 5G WLAN LED	<ul style="list-style-type: none">•Off. The wireless interface is off.•Solid green. The wireless interface is on.•Blinking green. Wireless activity is detected on the 5G band.

➤ To configure your access point for your network:

1. Connect to the access point by opening your browser and entering the access point's IP address
If a DHCP server is not installed in your network, the default IP address is **192.168.0.100**.
A login window displays.
2. Enter **admin** for the user name and **password** for the password, both in lower case letters.
The access point user interface displays.
3. Select **Configuration > System > Basic > General** from the menu.
4. Complete the **Access Point Name** field and select your Country/Region of operation from the drop-down list.

- Select **Configuration > IP > IP Settings** from the menu and configure the IP settings for your network.

Note: If you use DHCP, reserve an IP address (based on the access point's MAC address) on the DHCP server. You can then use that address to log in to the access point.

- Select **Configuration > Wireless > Basic > Wireless Settings** and configure the wireless settings for your network.

For more information about wireless settings, see the reference manual.

- Select **Configuration > Security > Profile Settings** and configure security profiles for your network.

For more information about security profile settings, see the reference manual.

Deploy the Access Point

The best location for your access point is elevated such as wall or ceiling mounted, at the center of your wireless coverage area, and within line of sight of all mobile devices.

➤ To deploy your access point:

- Disconnect your access point and position it where you will deploy it.
- Connect an ethernet cable from your access point to a LAN port on your PoE switch.
- Using a wireless device, verify connectivity by using a browser to connect to the Internet.

Troubleshooting Tips

This section provides some tips for correcting simple problems that you might encounter. For more troubleshooting information, see the troubleshooting chapter in the reference manual.

Problem	Cause	Possible Solution
No LEDs are lit on the access point.	The access point has no power.	<ul style="list-style-type: none"> • Make sure that the access point is securely connected to the PoE switch. • Make sure that the PoE switch is connected to a power source.
The LAN port LED is off.	A hardware connection problem exists.	<ul style="list-style-type: none"> • Make sure that the cable connectors are securely plugged into the access point and to the network switch. Make sure that the network switch is turned on.
The WLAN LEDs are off.	The wireless connection does not work.	<ul style="list-style-type: none"> • Make sure the powered device is providing sufficient power to the access point. • Log in to the access point and verify that the radio or radios are turned on. • Contact NETGEAR if the WLAN LEDs remain off.
You cannot configure the access point from a browser.	Multiple possible causes.	<ul style="list-style-type: none"> • Make sure that the access point is correctly installed, it is powered on, and that the LAN LED is lit. • Make sure that your computer is using an IP address in the same range as the access point. The access point default IP address is 192.168.0.100, and the default subnet mask is 255.255.255.0. • Quit the browser, clear the cache, delete the cookies, and launch the browser again.
You cannot access the Internet or the LAN from a wireless device.	A configuration problem exists.	<ul style="list-style-type: none"> • Make sure that the SSID and wireless security settings of the wireless device are the same as those of the access point. • The wireless device might not have the correct TCP/IP settings to communicate with the network. Restart the wireless device and check that TCP/IP is set up correctly for that network. • The access point default values might not work with your network. Check the access point default configuration against the configuration of other devices in your network. For information about changing the default values of the access point, see the reference manual.

Support

Thank you for selecting NETGEAR products. After installing your device, locate the serial number on the label of your product and use it to register your product at <https://my.netgear.com>.

You must register your product before you can use NETGEAR telephone support. NETGEAR recommends registering your product through the NETGEAR website. For product updates and web support, visit <http://support.netgear.com>.

NETGEAR recommends that you use only the official NETGEAR support resources.

For the current EU Declaration of Conformity, visit http://support.netgear.com/app/answers/detail/a_id/11621/.

For regulatory compliance information, visit <http://www.netgear.com/about/regulatory/>.

See the regulatory compliance document before connecting the power supply.

