

Getting Started

Does your WiFi router have a WPS button?

Wi-Fi Protected Setup (WPS) is an easy way to connect WiFi devices. The button might look like one of these:



Yes

1. Attach the antennas.

Remove the antenna caps. Attach the antennas to the antenna connector by turning the antennas clockwise. Bend and rotate the antennas into position. Double check that the antennas are properly tightened.

2. Turn on your extender.

Place the extender close to your WiFi router. Plug the extender into an electrical outlet. Press the **Power** button if necessary.

3. Connect to your WiFi router.

Press the **WPS** button on the extender. The Link Rate LEDs and Device to Extender LED blink green.

Within two minutes, press the **WPS** button on your WiFi router. After a few seconds, the 2.4 GHz Link Rate LED lights green, indicating a good connection between your WiFi router and your extender. If the 2.4 GHz Link Rate LED does not light, or the LED is blinking amber, try again. If the LED still does not light, follow the instructions for *No (or not sure)* on the right.

4. Add a WiFi band.

If your WiFi router supports the 5 GHz band (not all routers do), and you want to extend that band, repeat Step 3 and check that the 5 GHz Link Rate LED lights solid green to confirm the connection.

5. Choose a location and check the signal strength.

Now that the extender is connected to your WiFi router, you can move it to a location that will boost your WiFi range. The location you choose must be within the range of your existing WiFi router network.

The Link Rate LEDs help you choose a spot where the extender-to-router connection is optimal. See *Indicator LEDs* on the back of this card to learn how the LEDs show the best connection.

If you get no connection or a poor connection, move the extender closer to your WiFi router and try again until the 2.4 GHz or 5 GHz Link Rate LED lights green.

6. Connect your WiFi devices.

Take your WiFi device to the location with poor WiFi router coverage. Find the new extender network name:

Existing network name. MyNetworkName
New extended network name. MyNetworkName_2GEXT
or
MyNetworkName_5GEXT

Select the new network and use your WiFi router password to connect. You are now using your extended WiFi network.

No (or not sure)

1. Attach the antennas.

Remove the antenna caps. Attach the antennas to the connectors and turn them clockwise to tighten. Bend and rotate the antennas into position. Double-check that the antennas are properly tightened.

2. Turn on your extender.

Place the extender close to your WiFi router. Plug the extender into an electrical outlet. Press the **Power** button if necessary.

3. Connect to the extender.

On a computer, tablet, or smartphone, open the WiFi connection manager and connect to the extender network called **NETGEAR_EXT**. When you are connected to the extender, the Device to Extender LED lights solid green.

4. Set up with a web browser.

Launch a web browser. You are automatically taken to a login page. If a login page does not display, visit **www.mywifiext.net**.

To set up your extender, do the following:

- Click the **NEW EXTENDER SETUP** button.
- Complete the Create an Accounts page and click the **NEXT** button.
- Click the **WiFi RANGE EXTENDER** button.
- Select a WiFi network to extend and click the **NEXT** button. If you do not want to extend both WiFi bands, clear the **2.4GHz WiFi Networks** or the **5GHz WiFi Networks** check box.
- In the **Password (network key)** field, type the existing WiFi network password and click the **NEXT** button.
- Set the network name (SSID) and password for your extender and click the **NEXT** button.
- Use a WiFi network manager on the computer or WiFi device to connect to the new extended WiFi network.

5. Choose a location and check the signal strength.

Now that the extender is connected to your WiFi router, you can move it to a location that will boost your WiFi range. The location you choose must be within the range of your existing WiFi router network.

The Link Rate LEDs help you choose a spot where the extender-to-router connection is optimal. See *Indicator LEDs* on the back of this card to learn how the LEDs show the best connection.


If you get no connection or a poor connection, move the extender closer to your WiFi router and try again until the 2.4 GHz or 5 GHz Link Rate LED lights green.

AC1200 WiFi Range Extender


Model EX6200
Quick Start Guide

Hardware


Front Panel and Side Panel



Rear Panel



Indicator LEDs



2.4 GHz Link Rate LED

This LED indicates the 2.4 GHz WiFi connection between the extender and the router.


Solid green. Best connection
Solid amber. Good connection
Solid red. Poor connection
Off. No connection



5 GHz Link Rate LED

This LED indicates the 5 GHz WiFi connection between the extender and the router.

Solid green. Best connection
Solid amber. Good connection
Solid red. Poor connection
Off. No connection



Device to Extender LED

Solid green. The extender and device are connected.



Ethernet ports 1-5 LEDs

Solid green. The Ethernet port has detected an Ethernet link with the extender.



USB LEDs

Solid green. A USB device is connected to the extender.

Support

For information about using the extender in access point mode, see the *Do More* booklet that came in the package with your extender.

After installing your extender, locate the serial number on the label and use it to register your product at <https://my.netgear.com>. You must register your product before you can use NETGEAR telephone support. We recommend registering your product through the NETGEAR website. For product updates and web support, visit <http://support.netgear.com>.

You can get the user manual online at <http://downloadcenter.netgear.com> or through a link in the product's user interface. We recommend that you use only the official NETGEAR support resources.

For the current EU Declaration of Conformity, visit: http://support.netgear.com/app/answers/detail/a_id/11621/.

For regulatory compliance information, visit <http://www.netgear.com/about/regulatory/>.

See the regulatory compliance document before connecting the power supply.

NETGEAR, Inc. 350 East Plumeria Drive, San Jose, CA 95134 USA