

## Support and Community

Get your questions answered and access the latest downloads at [NETGEAR.com/support](https://NETGEAR.com/support), and check out our NETGEAR Community at [community.NETGEAR.com](https://community.NETGEAR.com).

Si ce produit est vendu au Canada, vous pouvez accéder à ce document en français canadien à [NETGEAR.com/support/download/](https://NETGEAR.com/support/download/). (If this product is sold in Canada, you can access this document in Canadian French at [NETGEAR.com/support/download/](https://NETGEAR.com/support/download/).)

## Regulatory and Legal

For regulatory compliance information including the EU Declaration of Conformity, visit [NETGEAR.com/about/regulatory](https://NETGEAR.com/about/regulatory). See the regulatory compliance document before connecting the power supply. For NETGEAR's Privacy Policy, visit [NETGEAR.com/about/privacy-policy](https://NETGEAR.com/about/privacy-policy).

Where permitted by law, by using this device, you are agreeing to NETGEAR's Terms and Conditions at [NETGEAR.com/about/terms-and-conditions](https://NETGEAR.com/about/terms-and-conditions). If you do not agree, return the device to your place of purchase within your return period.

For 6 GHz devices not designed for outdoor use: Only use the device indoors. The operation of 6 GHz devices is prohibited on oil platforms, cars, trains, boats, and aircraft, except that operation of this device is permitted in large aircraft while flying above 10,000 feet. Operation of transmitters in the 5.925-7.125 GHz band is prohibited for control of or communications with unmanned aircraft systems.

**NETGEAR, Inc.**  
**NETGEAR INTERNATIONAL LTD**

© NETGEAR, Inc., NETGEAR and the NETGEAR Logo are trademarks of NETGEAR, Inc. Any non-NETGEAR trademarks are used for reference purposes only.

**NETGEAR®**

July 2025



201-31900-02

## Let's get started



### Nighthawk app setup

If you have an iOS or Android mobile device, you can download the Nighthawk app and connect to your extender's default WiFi network to complete setup.



- 1 On your mobile device, scan the QR code to download the Nighthawk app.
- 2 Plug in your extender.
- 3 Connect your mobile device to the NETGEAR\_EXT WiFi network.
- 4 Open the Nighthawk app and follow the step-by-step instructions to set up your extender.

### Alternate setup methods

If you don't have a Nighthawk app compatible mobile device, or you prefer to use a different setup method like Wi-Fi Protected Setup (WPS) or the extender web interface, see the next page.


# Alternate setup methods



## WPS push-button setup

If your router has a WPS or Sync button, Wi-Fi Protected Setup (WPS) connects your extender to your existing network with the press of a button.

- 1 Plug in your extender and wait for the Power LED to light solid green.
- 2 Locate the WPS button on your extender and router.



- 3 Press the WPS button on your extender.
- 4 Within two minutes, press the WPS or Sync button on your router to connect the first WiFi band.
- 5 After the Router Link LED lights solid green, repeat steps 3 and 4 to connect the second WiFi band.
- 6 Join your WiFi network and visit <http://mywifiext.local> to register your device, set up a NETGEAR account, and get the latest updates. Setup is complete!




## Web user interface & additional help



For detailed instructions on web user interface setup and additional help for all installation methods, scan the QR code or visit [NETGEAR.com/extendersetup](http://NETGEAR.com/extendersetup).

# Device Overview

- |          |               |  |
|----------|---------------|--|
| <b>A</b> | WPS button    | Press to search for a WPS connection with another WPS device.  |
| <b>B</b> | Reset button  | Press and hold for seven seconds to reset to factory settings. |
| <b>C</b> | Ethernet port | Use to connect a wired Ethernet LAN device to your network.    |



- |          |                 |  |
|----------|-----------------|--|
| <b>1</b> | Power LED       | <b>Blinking amber:</b> Extender resetting.<br><b>Solid amber:</b> Extender booting.<br><b>Solid green:</b> Extender powered on.<br><b>Off:</b> Extender powered off. |
| <b>2</b> | Router Link LED | <b>Solid green:</b> Best connection.<br><b>Solid amber:</b> Good connection.<br><b>Solid red:</b> Poor connection.<br><b>Off:</b> No connection.                     |
| <b>3</b> | Client Link LED | <b>Solid green:</b> Best connection.<br><b>Solid amber:</b> Good connection.<br><b>Solid red:</b> Poor connection.<br><b>Off:</b> No connection.                     |
| <b>4</b> | WPS LED         | <b>Blinking green:</b> WPS connection in process.<br><b>Solid green:</b> Connected via WPS or passcode.<br><b>Off:</b> Not connected via WPS or passcode.            |