

Verifying Wireless Activation

Note: The wireless antenna is contained inside the 7500 gateway. An external antenna is not necessary for full wireless coverage.

In order to verify that the wireless feature is activated, simply start your browser and enter the IP address of your gateway, which is:

http://192.168.1.1

Then, find the “Wireless” links to view or change the wireless operation of your gateway.

Stand your gateway on its side or lay it down, as shown below.



READ FIRST before activating wireless connections!

For initial wireless networking, you must enter the Model 7500's ESSID and WEP Key into each of your wireless networking devices.

Optional: Model 7500 is compatible with WiFi Protected Setup (WPS) functionality, but before using this feature, you must activate it by changing the Wireless Security settings. After activation, simply press the WPS button on the top of the 7500 to synchronize your wireless device(s). Be sure to see your device's User Guide for more details on WPS.

For wireless security, each Model 7500 has its own unique identity. To make use of its unique identity, first refer to the label which is located on the bottom panel of the gateway. Next, find both the Serial Number (S/N) and Wireless Encryption Privacy (WEP) KEY, and then record them in the blank lines provided on page 2. Keep this information for future reference.

If you require additional gateway technical information, refer to the full User Guide on the CD-ROM provided with your kit.

